



TO ORDER: USE RD PREFIX
WITH PART NUMBER

PARTS LIST

RD #	DESCRIPTION	RD #	DESCRIPTION	RD #	DESCRIPTION
0041	Drive Gear Washer	1362	Drag Programmer	2293	Drive Gear Bushing
0064	Click Gear	1397	Fightin' Drag II Lever	2294	Drive Gear
0071	Rotor Nut	1442	Handle Screw Cap	2298	Spacer
0345	Anti-Reverse Lever Screw	1504	Bail Spring Cover Screw	2299	Oscillating Slider Bushing
0543	Side Cover Screw	1506	Multi Purpose Screw	2300	Oscillating Pawl
0544	Drag Washer "C2" (white)	1509	Bail Spring	2305	Main Shaft
0549	Eared Washer "B"	1888	Anti-Reverse Lock Out Spring	2306	Pinion Gear
0551	"O" Ring	1890	Bushing Washer	2307	Worm Shaft
0553	Hold Click Spring	1891	Bearing Retainer Screw	2309	Slider Retainer Screw
0555A	Fightin' Pressure Screw Washer	1974	Drag Coil Spring	2310	Oscillating Slider Retainer
0560	Lever Hold Spring	2271	Quick-Fire II Trigger	2311	Oscillating Slider
0562	Drag Programmer Screw	2272	Rotor Side Cover	2313	Drag Click
0773	Handle Knob	2275	Bail Spring Guide (B)	2314	Pressure Screw
0774	Handle Knob Screw	2277	Bail Spring Cover	2315	Lever Click Gear
0784	Line Roller Washer	2278	Bail Trip Lever	2380	Drag Shaft
0787	Nut Lock Screw	2279	Anti-Reverse Ratchet	2852	Handle Screw Lock
0930	Ball Bearing	2280	Anti-Reverse Lock Out	2856	Bail Spring Guide (A)
0940	Bail Trip Cam Screw	2281	Bearing Retainer	2857	Trigger Cam
0949	Trigger Screw	2283	Anti-Reverse Pawl Screw	2858	Bail Arm
1008	Handle Lock Washer	2284	Anti-Reverse Pawl	2909	Spool Assembly
1021	Handle Assembly	2285	Anti-Reverse Pawl Spring	3103	Rotor
1038	SiC Ceramic Roller	2286	Anti-Reverse Cam	3125	Drag Click Screw
1302	Line Roller Screw	2287	Anti-Reverse Cam Spring	3136	Bail Assembly
1355	Drag Washer "C1" (white)	2288	Worm Bearing	3148	Side Cover
1356	Eared Washer "Bf"	2290	Idle Gear	3149	Body
1360	Fightin' Pressure Screw	2292	Anti-Reverse Lever		