

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0071	Rotor Nut	7991	Handle Screw Cap	9391	Eared Washer
0574	Drag Washer	8553	Ball Bearing	9392	Key Washer
0642	Screw	8978	Anti-Reverse Lever	9393	Drag Coil Spring
0848	Washer	9365	Bail Spring Guide	9394	Pressure Screw
1008	Handle Lock Washer	9366	Bail Spring	9395	Drag Programmer B1
3125	Screw	9367	Line Roller Bushing	9396	Drag Programmer B2
3747	Screw	9368	Line Roller	9400	Drag Programmer A
4049	Washer	9369	Line Roller Washer	9669	Handle Assembly
4150	Screw	9370	Bail Arm	9742	Bail Spring Cover
5269	Drag Washer	9372	Bail Trip Lever	9770	Rear Protector
5690	Screw	9374	Bail Assembly	11146	Washer
5996	Locking Spring	9376	Pinion Gear	13194	Handle Screw Lock
6289	Screw	9377	Anti-Reverse Cam	13428	Rotor
6486	Screw	9378	Drive Gear	13429	Bail Hold Support Guard
6684	Line Roller Spacer	9379	Screw	13676	Push Button Collar
7290	Push Button	9382	Oscillating Slider Retainer	13677	Spool Assembly
7469	Screw	9383	Oscillating Slider	13678	Main Shaft
7792	Screw	9384	Oscillating Gear	13679	Side Cover
7800	Rotor Ring	9385	Hold Click Spring	13680	Body
7844	Anti-Reverse Cam Spring	9386	Drag Click	13758	Roller Clutch Assembly
7869	Screw	9389	Drag Shaft		