
www.reelschematic.com

SHIMAN

1997 Repair Supplem



SOLSTACE
2000FB 97

SO2000FB

Part #	Description	Part #	Description	Part #	Description
RD 0026	Ball Bearing	RD 3402	Cover Screw	RD 3708	Counterbalance Cover
RD 0041	Drive Gear Washer	RD 3410	Bail Trip Lever	RD 3869	Anti-Reverse Lockout Spring
RD 0050	Anti-Reverse Lever Screw	RD 3451	Spool Assembly (Graph.)	RD 4051	Bail Spring
RD 0071	Rotor Nut	RD 3455	Spool Washer	RD 4160	Trigger Cam
RD 0540	Multi-Purpose Screw	RD 3471	Anti-Rverse Cam Spring	RD 4163	Line Roller Bushing
RD 0642	Side Cover Screw	RD 3646	Main Shaft	RD 4364	Quickfire II Trigger
RD 0779	Bail Hold Support Screw	RD 3651	Bail Spring Guide (A)	RD 4366	Bail Arm
RD 0786	Trigger Screw	RD 3652	Bail Spring Guide (B)	RD 4367	Line Roller Screw
RD 0787	Nut Lock Screw	RD 3656	Anti-Reverse Ratchet	RD 4370	Bail Assembly
RD 0792	Bearing Retainer Screw	RD 3657	Pinion Gear	RD 4421	Handle Screw Cap
RD 0930	Ball Bearing	RD 3658	Anti-Reverse Pawl	RD 4454	Handle Assembly
RD 1008	Handle Lock Washer	RD 3659	Anti-Reverse Pawl Spring	RD 4553	Line Roller
RD 1427	Spool Support	RD 3660	Anti-Reverse Cam	RD 4885	Drag Knob
RD 1890	Bushing Washer	RD 3662	Drive Gear	RD 4890	Anti-Reverse Lever
RD 1891	Bail Spring Cover Screw	RD 3664	Oscillating Gear	RD 4893	Spool Assembly (Aluminum)
RD 2280	Anti-Reverse Lockout	RD 3665	Slider Retainer Screw	RD 4914	Side Cover
RD 2283	Anti-Reverse Pawl Screw	RD 3673	Oscillating Gear	RD 4916	Body
RD 2852	Handle Screw Lock	RD 3702	Bail Spring Cover		
RD 3359	Line Roller Washer	RD 3706	Rotor		