
www.reelschematic.com

SOLSTACE® 2000FE 00



Part No.	Description
RD 0026	Ball Bearing
RD 0041	Drive Gear Washer
RD 0050	Anti-Reverse Lever Screw
RD 0071	Rotor Nut
RD 0540	Multi-Purpose Screw
RD 0642	Side Cover Screw (long)
RD 0779	Bail Hold Support Screw
RD 0786	Trigger Screw
RD 0787	Nut Lock Screw
RD 0792	Bearing Retainer Screw
RD 0930	Ball Bearing
RD 1008	Handle Lock Washer
RD 1083	Slider Retainer Screw
RD 1427	Spool Support
RD 1890	Bushing Washer
RD 1891	Bail Spring Cover Screw
RD 2280	Anti-Reverse Lock Out
RD 2283	Anti-Reverse Pawl Screw
RD 2852	Handle Screw Lock

Part No.	Description
RD 3309	Line Roller Screw
RD 3359	Line Roller Washer
RD 3396	Bail Spring Guide (A)
RD 3397	Bail Spring
RD 3398	Bail Spring Guide (B)
RD 3402	Cover Screw
RD 3455	Spool Washer
RD 3471	Anti-Reverse Cam Spring
RD 3656	Anti-Reverse Ratchet
RD 3658	Anti-Reverse Pawl
RD 3659	Anti-Reverse Pawl Spring
RD 3673	Oscillating Gear
RD 3869	Anti-Reverse Lock Out Spring
RD 4160	Trigger Cam
RD 4364	Quick-Fire II Trigger
RD 4366	Bail Arm
RD 5180	Drag Knob
RD 5190	Anti-Reverse Lever
RD 5194	Spool Assembly (aluminum)

Part No.	Description
RD 5465	Anti-Reverse Cam
RD 5468	Spool Assembly (graphite)
RD 5471	Bail Trip Lever
RD 5547	Handle Assembly
RD 5625	Line Roller Spacer
RD 5628	Line Roller Collar
RD 5629	Line Roller Bushing
RD 5630	Line Roller
RD 6596	Side Cover Screw (short)
RD 6621	Main Shaft
RD 6625	Pinion Gear
RD 6626	Drive Gear
RD 6627	Handle Screw Cap
RD 6628	Oscillating Slider
RD 6632	Bail Assembly
RD 6645	Body Assembly
RD 6646	Rotor Assembly

(110819)