
www.reelschematic.com

SHIMAN

1997 Repair Supplem



SOLSTACE 4000FB 97

SO-4000FB

Part #	Description	Part #	Description	Part #	Description
RD 0026	Ball Bearing	RD 3452	Spool Assembly (Graphite)	RD 3713	Counterbalance Cover
RD 0041	Drive Gear Washer	RD 3503	Spool Washer	RD 3869	Anti-Reverse Lockout Spring
RD 0050	Anti-Reverse Lever Screw	RD 3665	Slider Retainer Screw	RD 4161	Trigger Cam
RD 0071	Rotor Nut	RD 3677	Main Shaft	RD 4163	Line Roller Bushing
RD 0540	Multi-Purpose Screw	RD 3681	Bail Spring Guide (A)	RD 4362	Side Cover Screw Large
RD 0642	Side Cover Screw	RD 3682	Bail Spring	RD 4367	Line Roller Screw
RD 0779	Bail Hold Support Screw	RD 3683	Bail Spring Guide (B)	RD 4373	Quick Fire II Trigger
RD 0786	Trigger Screw	RD 3685	Bail Trip Lever	RD 4374	Bail Assembly
RD 0787	Nut Lock Screw	RD 3687	Anti-Reverse Ratchet	RD 4375	Bail Arm
RD 0792	Bearing Retainer Screw	RD 3688	Anti-Reverse Lock-Out	RD 4421	Handle Screw Cap
RD 0930	Ball Bearing	RD 3689	Bushing Washer	RD 4460	Handle Assembly
RD 1008	Handle Lock Washer	RD 3690	Pinion Gear	RD 4553	Line Roller
RD 1511	Lever Spring	RD 3691	Anti-Reverse Pawl	RD 4890	Anti-Reverse Lever
RD 1520	Anti-Reverse Cam Spring	RD 3692	Anti-Reverse Pawl Spring	RD 4897	Drag Knob
RD 2516	Spool Support	RD 3693	Anti-Reverse Cam	RD 4898	Spool Assembly Aluminum
RD 2541	Anti-Reverse Pawl Screw	RD 3694	Drive Gear	RD 4917	Side Cover Flange
RD 2852	Handle Screw Lock	RD 3695	Oscillating Gear	RD 4918	Side Cover
RD 2934	Flange Screw	RD 3696	Oscillating Slider	RD 4919	Body
RD 3359	Line Roller Washer	RD 3710	Rotor		
RD 3402	Cover Screw	RD 3712	Bail Spring Cover		