
www.reelschematic.com

SOLSTACE® 4000FE 00



Part No.	Description
RD 0026	Ball Bearing
RD 0041	Drive Gear Washer
RD 0050	Anti-Reverse Lever Screw
RD 0071	Rotor Nut
RD 0540	Multi-Purpose Screw
RD 0779	Bail Hold Support Screw
RD 0786	Trigger Screw
RD 0787	Nut Lock Screw
RD 0930	Ball Bearing
RD 1008	Handle Lock Washer
RD 1083	Slider Retainer Screw
RD 1511	Lever Spring
RD 1520	Anti-Reverse Cam Spring
RD 2329	Bearing Retainer Screw
RD 2516	Spool Support
RD 2541	Anti-Reverse Pawl Screw
RD 2852	Handle Screw Lock
RD 3309	Line Roller Screw
RD 3359	Line Roller Washer

Part No.	Description
RD 3402	Cover Screw
RD 3418	Bail Spring Guide (A)
RD 3419	Bail Spring
RD 3503	Spool Washer
RD 3507	Bail Spring Guide (B)
RD 3687	Anti-Reverse Ratchet
RD 3688	Anti-Reverse Lock Out
RD 3689	Bushing Washer
RD 3692	Anti-Reverse Pawl Spring
RD 3869	Anti-Reverse Lock Out Spring
RD 4161	Trigger Cam
RD 4362	Side Cover Screw (long)
RD 4373	Quick-Fire II Trigger
RD 5199	Drag Knob
RD 5200	Spool Assembly (aluminum)
RD 5208	Anti-Reverse Lever
RD 5213	Oscillating Gear
RD 5474	Spool Assembly (graphite)
RD 5477	Bail Arm

Part No.	Description
RD 5479	Bail Trip Lever
RD 5481	Anti-Reverse Pawl
RD 5548	Handle Assembly
RD 5625	Line Roller Spacer
RD 5628	Line Roller Collar
RD 5629	Line Roller Bushing
RD 5630	Line Roller
RD 6627	Handle Screw Cap
RD 6635	Main Shaft
RD 6636	Bail Assembly
RD 6637	Pinion Gear
RD 6638	Drive Gear
RD 6639	Side Cover Screw (short)
RD 6640	Oscillating Slider
RD 6647	Body Assembly
RD 6648	Rotor Assembly
RD 6649	Anti-Reverse Cam

(110819)