


SOLSTACE 4000RG 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2541	Anti-Reverse Pawl Screw	5209	Drive Gear
0041	Drive Gear Washer	2852	Handle Screw Lock	5213	Oscillating Gear
0050	Anti-Reverse Lever Screw	3125	Drag Click Screw	5477	Bail Arm
0071	Rotor Nut	3309	Line Roller Screw	5479	Bail Trip Lever
0540	Multi-Purpose Screw	3359	Line Roller Washer	5481	Anti-Reverse Pawl
0579	Eared Washer “B”	3402	Cover Screw	5515	Main Shaft
0586	Fightin’ Pressure Screw Washer	3418	Bail Spring Guide (A)	5517	Oscillating Slider
0642	Side Cover Screw (medium)	3419	Bail Spring	5518	Drag Shaft (A)
0779	Bail Hold Support Screw	3507	Bail Spring Guide (B)	5519	Drag Shaft (B)
0786	Trigger Screw	3687	Anti-Reverse Ratchet	5520	Fightin’ Drag Lever
0787	Nut Lock Screw	3688	Anti-Reverse Lock Out	5521	Drag Programmer
0930	Ball Bearing	3692	Anti-Reverse Pawl Spring	5548	Handle Assembly
1008	Handle Lock Washer	3744	Drag Click	5625	Line Roller Spacer
1370	Lever Click Gaer	3747	Slider Retainer Screw	5628	Line Roller Collar
1371	Fightin’ Pressure Screw	3764	Hold Click Spring	5629	Line Roller Bushing
1511	Lever Spring	3767	Oscillating Slider Retainer	5630	Line Roller
1520	Anti-Reverse Cam Spring	3792	Lever Hold Spring	6627	Handle Screw Cap
2016	Drag Washer “H” (cloth)	3794	Drag Programmer Screw	6636	Bail Assembly
2017	Drag Coil Spring	3869	Anti-Reverse Lock Out Spring	6637	Pinion Gear
2257	Drag Washer “H” (blue)	3871	Bushing Washer	6639	Side Cover Screw (short)
2329	Bearing Retainer Screw	4161	Trigger Cam	6648	Rotor Assembly
2346	Drag Washer “C” (cloth)	4362	Side Cover Screw (long)	7103	Spool Assembly (aluminum)
2347	Click Gear	4373	Quick-Fire II Trigger	7104	Spool Assembly (graphite)
2348	Drag Washer “C” (blue)	4551	Pressure Screw	7168	Anti-Reverse Cam
2349	Eared Washer “BF”	4552	“O” Ring	7172	Body Assembly
2351	Drag Spring Washer	5208	Anti-Reverse Lever		

(120926)