



TO ORDER: USE RD PREFIX  
WITH PART NUMBER-SP-3000-F

**PARTS LIST**

RD #	DESCRIPTION	RD #	DESCRIPTION	RD #	DESCRIPTION
0026	Ball Bearing	2299	Oscillating Slider Bushing	2867	Bushing
0041	Drive Gear Washer	2300	Oscillating Pawl	2868	Worm Bearing
0071	Rotor Nut	2321	Rotor Cover Screw	2869	Idle Gear
0345	Anti-Reverse Lever Screw	2323	Line Roller Bushing	2870	Worm Shaft
0540	Bearing Retainer Screw	2324	Bail Spring Guide (B)	2871	Worm Shaft Retainer
0787	Nut Lock Screw	2329	Bail Trip Lever Screw	2872	Oscillating Pawl cover
0930	Ball Bearing	2331	Anti-Reverse Lock Out	2887	Pinion Gear
1008	Handle Lock Washer	2332	Bearing Retainer	2969	Bail Trip Lever
1302	Line Roller Screw	2340	Drive Gear	3081	Side Cover Screw
1442	Handle Screw Cap	2356	Key Washer	3087	Bail Trip Cam Screw
1506	Bail Spring Cover Screw	2357	Drag Washer	3164	Drag Knob
1509	Bail Spring	2358	Eared Washer	3165	Seal Plate Screw
1511	Lever Spring	2360	Main Shaft	3166	Spool Assembly
1520	Anti-Reverse Cam Spring	2361	Spool Washer	3167	Rotor
1596	Bushing Washer	2362	Spool Support	3168	Bail Spring Cover
1712	Anti-Reverse Pawl Screw	2364	Bail Assembly	3169	Anti-Reverse Ratchet
1888	Anti-Reverse Lock Out Spring	2365	Line Roller	3170	Anti-Reverse Pawl
1890	Bushing Washer	2366	Bail Arm	3171	Anti-Reverse Cam
1932	Anti-Reverse Pawl Spring	2404	Idle Gear Retainer	3172	Side Cover
2048	Line Roller Washer	2409	Worm Shaft Spacer	3173	Oscillating Slider
2057	Seal Plate	2852	Handle Screw Lock	3174	Body
2292	Anti-Reverse Lever	2860	Bail Spring Guide (A)	3175	Handle Assembly
2296	Slider Retainer Screw	2864	Pinion Idle Gear Washer		
2298	Spacer	2865	Pinion Idle Gear		

Prices and specifications subject to change without notice