
SHIMANO

STELLA SA-RB

STL-4000XG



＊(18735) Please send the equipment out to after-sales service for replacement of the roller clutch assembly.
Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(51SF14H043X)

Part No.	Description		Part No.	Description		Part No.	Description	
RD 2110	Screw		RD16478	Screw				
RD 2409	Spacer	***	RD16479	Worm Shaft Retainer		RD18764	Handle Screw Cap	
RD 3538	Spool Support		RD16480	O Ring		RD18966	Drag Washers Retainer	
RD 3561	Screw		RD16587	Key Washer		RD18968	Spool Washer	
RD 4831	Ball Bearing	**	RD16603	Ball Bearing	**	RD18969	Rotor Brim	
RD 6008	Set Screw		RD16616	Oscillating Pawl Cover		RD18970	Bail Arm	
RD 6920	Spacer	**	RD16618	Oscillating Pawl	***	RD18971	Bail Spring Cover	
RD 8013	Screw	****	RD16665	Line Roller Support	****	RD18972	Rotor Assembly	
RD 8074	Bearing Water Proof		RD16838	Main Shaft Spacer		RD18973	Bail Trip Lever	
RD 8165	Washer		RD17467	Bail Spring		RD18975	Bail Hold Support Guard	
RD 8759	Click Pin		RD17468	Bail Spring Guide B		RD18977	Washer	**
RD 9833	Ratchet Spring		RD17750	Bearing Housing		RD18978	Oscillating Guide A	
RD 9847	Screw		RD17751	Ball Bearing		RD18979	Idle Gear	*
RD 9849	Screw		RD17752	Washer		RD18981	Side Cover Assembly	
RD 9856	Washer	***	RD17760	Idle Gear B Shaft		RD18982	Handle Shaft Cover B	
RD 9903	O Ring		RD18160	Bearing Spacer	****	RD18985	Handle Knob Seal	
RD 9908	Drag Washer		RD18358	Washer	**	RD18986	Handle Knob I.D. Plate	
RD 9909	Eared Washer		RD18448	Line Roller Set (With Bearing)	****	RD18988	Oscillating Slider Bushing	
RD 9910	Key Washer		RD18709	Drag Knob Assembly		RD18989	Main Shaft Assembly	
RD 9912	Bearing Retainer		RD18711	Drag Click		RD18990	Rear Protector	
RD 9931	Click Spring		RD18717	Screw		RD18991	Worm Shaft	***
RD 9968	O Ring	***	RD18720	Screw		RD18992	Oscillating Guide B	
RD11018	Ball Bearing	***	RD18724	Spring Guide A Support		RD18993	Idle Gear (Small)	*
RD11568	Screw		RD18725	Bail Spring Guide A		RD18996	Spool Assembly	
RD11578	Ball Bearing	***	RD18726	Bail Spring Guide A Bush		RD18997	Pinion Gear	*
RD11646	Drag Click Ratchet		RD18728	Bail Trip Cam Bushing		RD18998	Drive Gear	*
RD13241	Ball Bearing	**	RD18729	Screw		RD18999	Handle Shank Assembly	
RD13269	Ball Bearing		RD18731	Rotor Side Cover		RD19000	Handle Assembly	
RD13274	Ball Bearing	**	RD18732	Rotor Ring		RD19001	Idle Gear (Large)	*
RD13381	Ball Bearing		RD18733	Friction Ring		RD19002	Body Assembly	
RD14279	Washer		RD18734	Screw		RD19025	Handle Knob	
RD14300	Bearing Bushing		RD18735	Roller Clutch Assembly		RD19029	Washer	
RD14780	Screw		RD18736	O Ring		RD19061	Bail Assembly	
RD15489	Drag Click Spring		RD18737	Roller Clutch Inner		RD19224	Washer	****
RD15718	Screw	**	RD18738	Bearing Retainer				
RD15991	Rotor Nut Lock Plate		RD18739	Washer	*/**	RD 9811	Reel Seat Spacer	(accessory)
RD15992	Rotor Nut		RD18746	Bail Trip Strike				
RD16423	Drag Washer		RD18747	Flange Water Proof		PK 0456	Gear Set	*
RD16426	Screw		RD18751	Handle Knob Pipe		PK 0477	Bearing Set	**
RD16451	Screw		RD18758	Washer	***	PK 0455	Oscillation Set	***
RD16465	Handle Shaft Seal		RD18762	Washer	*	PK 0476	Line Roller Set	****

(181011)_002