
SHIMANO

STELLA SA-RB

STL-SW18000HG



Please note that the number of adjusting washers may not always be the same as shown in the exploded views.

(51SF24X182X) Please note that your actions take full responsibility when you take it apart.

Part No.	Description	Part No.	Description	Part No.	Description	
RD 2110	Screw	RD16259	Ratchet	RD20826	Rotor	
RD 2296	Screw	RD16426	Screw	RD20828	Bail Arm	
RD 3561	Screw	RD16974	O Ring	RD20829	Bail Spring Cover	
RD 7915	Ball Bearing	RD16975	Clutch Water Proof Cover	RD20830	Bail Hold Support Guard	
RD 7919	Click Spring	RD16980	Clutch Cover Water Proof	RD20831	Rotor Nut	
RD 8008	Click Pin	RD16996	O Ring	RD20832	Bail Spring Guide B	
RD 8059	Screw	RD18570	Screw	RD20833	Bearing Water Proof	
RD 8144	Screw	RD18758	Washer	RD20835	Spacer	
RD 8174	Screw	RD19522	Drag Click Assembly	RD20836	Retainer	
RD 8227	Screw	RD19559	Collar	RD20840	Rotor Brim	
RD 8291	O Ring	RD19562	Line Roller Seal	RD20841	Bail Spring	
RD 8292	Bearing Retainer	RD19569	Bail Spring Guide A	RD20843	Bearing Retainer	
RD 8325	Friction Ring	RD19570	Spring Guide A Support Collar	RD20848	Spool Support B	
RD 9968	O Ring	RD19571	Collar	RD20849	Stopper	
RD10299	Retainer	RD19583	Collar	RD20850	Bearing Housing	
RD10424	Ball Bearing	RD19586	Bushing	RD20852	Body Flange Ring	
RD10473	Ball Bearing	RD19588	Bearing Water Proof	RD20853	Oscillating Guide	
RD11018	Ball Bearing	RD19598	Screw	RD20855	Idle Gear	
RD11111	Ball Bearing	RD19615	Washer	RD20856	Worm Shaft	
RD11633	Screw	RD19638	O Ring	RD20858	Body Seal	
RD11694	Ball Bearing	RD19643	Spring Holder	RD20860	Handle Shaft	
RD11706	Ball Bearing	RD19652	Line Roller	RD20863	Idle Gear Shaft	
RD11960	Screw	RD19656	Line Roller Plate	RD20865	Pinion Gear Collar	
RD12344	Screw	RD19657	Bushing	RD20866	Worm Shaft Retainer	
RD12372	Handle Knob Seal	RD19661	Handle Knob	RD20867	Rear Protector	
RD12418	Retainer	RD19712	Screw	RD20870	Idle Gear (Small)	
RD12419	Screw	RD19713	Set Screw	RD20871	Bushing	
RD12420	Screw	RD19714	Spool Ring Pin	RD20874	Rotor Guard A	
RD12438	Stopper Cover	RD19715	Bail Spring Guide A Bush	RD20875	Rotor Guard B	
RD12439	Collar	RD19744	Washer	RD20876	Washer	
RD12440	Screw	RD19745	Washer	RD20951	Screw	
RD12459	Oscillating Pawl	RD19750	Washer	RD20952	Screw	
RD12469	O Ring	RD19752	Spool Washer A	RD20953	Screw	
RD12481	Waterproof Sheet	RD20436	Washer	RD20954	O Ring	
RD12482	Ball Bearing	RD20617	Screw	RD20960	Stopper Spring	
RD12483	Bearing Bushing	RD20787	Spool Assembly	RD20965	Roller Clutch Inner	
RD12485	Key Washer	RD20788	Drive Gear Assembly	RD20966	Washer	
RD12487	Eared Washer	RD20789	Body Assembly	RD20967	Washer	
RD12488	Drag Washer B	RD20790	Handle Assembly	RD20975	O Ring	
RD12489	Drag Disk A	RD20791	Handle Shaft Cover Assembly			
RD12494	O Ring	RD20792	O Ring			
RD12504	Spool Support A	RD20794	Spool Ring			
RD12508	Washer	RD20795	Collar			
RD12533	Oscillating Pawl Cover	RD20796	Pinion Gear			
RD13188	Ball Bearing	RD20798	Handle Screw Cap			
RD14101	Ball Bearing	RD20800	Idle Gear (Large)			
RD15710	Body Flange Seal	RD20802	Drag Knob Assembly			
RD15718	Screw	RD20804	Drag Cover Assembly			
RD15721	Screw	RD20805	Bail Assembly			
RD15722	Screw	RD20808	Main Shaft Assembly			
RD15770	Drag Washer A	RD20809	Side Cover Assembly			
RD15785	Nut Water Proof	RD20810	Handle Shank Assembly			
RD15793	Collar	RD20813	Roller Clutch Assembly			
RD15798	Line Roller Support	RD20814	Roller Clutch Waterproof Assembly			
RD15815	Washer	RD20817	Drag Disk B			
RD15820	Screw	RD20820	Drag Washer C			
RD15848	Handle Knob ID Plate	RD20821	Bearing Bushing			
RD15904	Bail Trip Lever	RD20822	Bearing Support	RD15935	Belt (L)	(accessory)
RD15932	Collar	RD20823	Heat Sink	RD20861	Handle Shaft (Right)	(accessory)