
www.reelschematic.com

SHIMANO®

1991 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718



STRADIC 1000F

TO ORDER: USE RD PREFIX WITH PART NUMBER

PARTS LIST

RD #	DESCRIPTION
0041	Drive Gear Washer
0050	Anti-Reverse Lever Screw
0071	Rotor Nut
0540	Multi Purpose Screw
0779	Bail Trip Cam Screw
0784	Line Roller Washer
0786	Trigger Screw
0787	Nut Lock Screw
0930	Ball Bearing
1008	Handle Lock Washer
1038	SiC Ceramic Roller
1426	Spool Washer
1427	Spool Support
1509	Bail Spring
1888	Anti-Reverse Lock Out Spring
1890	Bushing Washer
1891	Multi Purpose Screw
2269	Main Shaft
2275	Bail Spring Guide (B)
2278	Bail Trip Lever
2279	Anti-Reverse Ratchet
2280	Anti-Reverse Lock Out

RD #	DESCRIPTION
2283	Anti-Reverse Pawl Screw
2284	Anti-Reverse Pawl
2285	Anti-Reverse Pawl Spring
2286	Anti-Reverse Cam
2287	Anti-Reverse Cam Spring
2296	Slider Retainer Screw
2298	Spacer
2299	Oscillating Slider Bushing
2300	Oscillating Pawl
2387	Pinion Gear
2388	Ball Bearing
2391	Drive Gear
2446	Bushing
2707	Drag Washers Retainer
2852	Handle Screw Lock
2856	Bail Spring Guide (A)
2876	Bearing Retainer
2877	Idle Gear (B) Shaft
2878	Worm Bearing
2879	Worm Shaft Spacer
2881	Worm Shaft
2883	Oscillating Pawl Cover

RD #	DESCRIPTION
2884	Oscillating Slider
2901	Spool Assembly
3046	Drag Knob
3047	Key Washer
3048	Drag Washer
3049	Rotor
3050	Quick-Fire II Trigger
3051	Rotor Side Cover
3052	Bail Assembly
3053	Line Roller Screw
3054	Trigger Cam
3055	Bail Arm
3056	Bail Spring Cover
3057	Idle Gear (A)
3058	Anti-Reverse Lever
3059	Idle Gear (B)
3060	Side Cover
3061	Side Cover Screw
3062	Handle Screw Cap
3063	Body
3064	Handle Assembly

Prices and specifications subject to change without notice

1/1991