
# SHIMANO

## SUSTAIN

## SA-C3000HG




Please note that the number of adjusting washers may not always be the same as shown in the exploded views.
(51SF46E035X) Please note that your actions take full responsibility when you take it apart.

| Part No. | Description | Part No. | Description | Part No. | Description |
|---|---|---|---|---|---|
| RD 0582 | O Ring | RD18724 | Spring Guide A Collar | RD19989 | Screw |
| RD 0647 | Screw | RD18732 | Rotor Ring | RD19990 | Screw |
| RD 5820 | Washer | RD18735 | Roller Clutch Assembly | RD19992 | Bushing |
| RD 9833 | Ratchet Spring | RD18741 | Washer | RD19993 | Worm Shaft Retainer |
| RD 9912 | Bearing Retainer | RD18744 | Idle Gear | RD19994 | Washer |
| RD13241 | Ball Bearing | RD18761 | Idle Gear (Small) | RD19995 | Screw |
| RD13269 | Ball Bearing | RD18771 | Idle Gear (Large) | RD19996 | Washer |
| RD13274 | Ball Bearing | RD19745 | Washer | RD19997 | Washer |
| RD13381 | Ball Bearing | RD19746 | Washer | RD19998 | Ball Bearing |
| RD13620 | Screw | RD19748 | Spool Washer | RD20012 | Pinion Gear |
| RD13829 | Ball Bearing | RD19767 | Drag Knob Assembly | RD20013 | Drive Gear |
| RD14780 | Screw | RD19771 | Main Shaft Assembly | RD20069 | Click Spring |
| RD14867 | Spool Support A | RD19775 | Screw | RD20150 | Collar |
| RD15231 | Key Washer B | RD19777 | Screw | RD20987 | Screw |
| RD15862 | Eared Washer | RD19780 | O Ring | RD20988 | Screw |
| RD16740 | Drag Washer A | RD19781 | O Ring | RD20990 | Screw |
| RD16742 | Drag Washer B | RD19793 | Bearing Water Proof | RD20998 | Bail Hold Support Guard |
| RD16796 | Spacer | RD19802 | Bail Trip Strike | RD20999 | Rotor Nut |
| RD16801 | Washer | RD19803 | Handle Screw Cap | RD21002 | Bail Trip Lever |
| RD16931 | Retainer | RD19804 | Oscillating Guide A | RD21003 | Rotor Brim |
| RD17183 | Drag Click Spring | RD19805 | Main Shaft Collar | RD21006 | Washer |
| RD17184 | Drag Click | RD19807 | Oscillating Pawl | RD21012 | Counter Weight Cover |
| RD17267 | Key Washer | RD19808 | Worm Shaft | RD21784 | Rotor Assembly |
| RD17415 | Click Pin | RD19815 | Idle Gear Shaft | RD21785 | Bail Arm |
| RD17493 | Handle Knob | RD19816 | Rear Protector | RD21786 | Bail Assembly |
| RD17494 | Handle Knob Seal | RD19818 | Oscillating Pawl Cover | RD21787 | Screw |
| RD17667 | Set Screw | RD19822 | Bearing Retainer | RD21788 | Body |
| RD17680 | Washer | RD19831 | O Ring | RD21797 | Handle Shank Assembly |
| RD17683 | Bail Spring | RD19837 | Bushing | RD21800 | Handle Assembly |
| RD17684 | Bail Spring Guide B | RD19839 | Spacer | RD21801 | Spool Assembly |
| RD17695 | Handle Shaft Seal | RD19857 | Bail Spring Guide A | RD21802 | Side Cover Assembly |
| RD17698 | Bushing | RD19866 | O Ring | | |
| RD17700 | Screw | RD19876 | Bail Spring Guide A Bushing | | |
| RD17719 | Screw | RD19883 | Friction Ring | | |
| RD18199 | Spacer | RD19884 | Oscillating Slider Bushing | | |
| RD18206 | Spool Bearing Bushing | RD19886 | Flange Water Proof | | |
| RD18207 | Drag Click Ratchet | RD19895 | Handle Shaft Cover | | |
| RD18208 | Bearing Spacer | RD19899 | Roller Clutch Inner | | |
| RD18210 | Screw | RD19926 | Nut Lock Plate | | |
| RD18211 | Screw | RD19959 | Line Roller | | |
| RD18215 | Line Roller Support | RD19976 | Bushing | RD18054 | Anti Line Slip Sticker |

(210125)_001