



TO ORDER: USE RD PREFIX
WITH PART NUMBER

PARTS LIST

RD #	DESCRIPTION	RD #	DESCRIPTION	RD #	DESCRIPTION
0041	Drive Gear Washer	1442	Handle Screw Cap	2307	Worm Shaft
0064	Click Gear	1504	Bail Spring Cover Screw	2309	Slider Retainer Screw
0071	Rotor Nut	1506	Bail Trip Lever Screw	2310	Oscillating Slider Retainer
0345	Anti-Reverse Lever Screw	1509	Bail Spring	2311	Oscillating Slider
0544	Drag Washer "C ₂ " (white)	1888	Anti-Reverse Lock Out Spring	2313	Drag Click
0549	Eared Washer "B"	1890	Bushing Washer	2314	Pressure Screw
0551	"O" Ring	1891	Bearing Retainer Screw	2315	Lever Click Gear
0553	Hold Click Spring	1974	Drag Coil Spring	2380	Drag Shaft
0555A	Fightin' Pressure Screw Washer	2271	Quick Fire II Trigger	2390	Idle Gear
0560	Lever Hold Spring	2272	Rotor Side Cover	2391	Drive Gear
0562	Drag Programmer Screw	2275	Bail Spring Guide (B)	2417	Pinion Gear
0773	Handle Knob	2278	Bail Trip Lever	2852	Handle Screw Lock
0774	Handle Knob Screw	2279	Anti-Reverse Ratchet	2856	Bail Spring Guide (A)
0784	Line Roller Washer	2280	Anti-Reverse Lock Out	2857	Trigger Cam
0787	Nut Lock Screw	2281	Bearing Retainer	2858	Bail Arm
0930	Ball Bearing	2283	Anti-Reverse Pawl Screw	2905	Spool Assembly
0949	Trigger Screw	2284	Anti-Reverse Pawl	3061	Side Cover Screw
1008	Handle Lock Washer	2285	Anti-Reverse Pawl Spring	3085	Rotor
1021	Handle Assembly	2286	Anti-Reverse Cam	3087	Bail Spring Cover
1038	SiC Ceramic Roller	2287	Anti-Reverse Cam Spring	3088	Bail Arm Screw
1302	Line Roller Screw	2288	Worm Bearing	3089	Bail Spring Cover
1355	Drag Washer "C ₁ " (white)	2292	Anti-Reverse Lever	3122	Bail Assembly
1356	Eared Washer "B _F	2298	Spacer	3123	Side Cover
1360	Fightin' Pressure Screw	2299	Oscillating Slider Bushing	3124	Body
1397	Fightin' Drag II Lever	2300	Oscillating Pawl	3125	Drag Click Screw
1398	Drag Programmer	2305	Main Shaft		