

PART #	DESCRIPTION	"A" INTERCHANGEABILITY	"B" INTERCHANGEABILITY
RD 0026	Ball Bearing	BNT0807, BR 0037, KXB0028, MLX0025, TGT0223, TLD0123, TT 0117	
RD 0041	Drive Gear Washer	BR 0049, RD 1524, MLX0040, X/Z0150.	
RD 0071	Rotor Nut	BR 0010, KXB0073, MLX0096.	
RD 0540	Multi Purpose Screw	BNT0689, BR 0066, MCR0021, TGT0068, TLD0056, TT 0187	BR 0470, BR 0539, RD 1506, RD 3088.
RD 0579	Eared Washer "B"	BR 0839.	
RD 0584	Hold Click Spring	BR 0844.	
RD 0586	Fightin' Pressure Screw Washer		
RD 0589	Lever Hold Spring		
RD 0787	Nut Lock Screw	BNT0696, BR 0778.	RD 1111.
RD 0930	Ball Bearing	BR 0047.	
RD 1366	Drag Click		
RD 1370	Lever Click Gear		
RD 1371	Fightin' Pressure Screw		
RD 1511	Lever Spring		
RD 1520	Anti-Reverse Cam Spring		
RD 1596	Bushing Washer		
RD 1712	Anti-Reverse Pawl Screw		
RD 1868	Anti-Reverse Lock Out Spring		
RD 1890	Bushing Washer	TGT0224.	
RD 1932	Anti-Reverse Pawl Spring		
RD 2016	Drag Washer "H2" (white)	BR 0840.	
RD 2017	Drag Coil Spring		
RD 2257	Drag Washer "H1"		
RD 2288	Worm Bearing (rear)		
RD 2298	Spacer	BR 0513.	
RD 2299	Oscillating Slider Bushing	BR 0514.	
RD 2300	Oscillating Pawl	BR 0515.	
RD 2309	Slider Retainer Screw	BR 0801.	
RD 2330	Anti-Reverse Ratchet		
RD 2331	Anti-Reverse Lock Out		
RD 2332	Bearing Retainer		
RD 2334	Anti-Reverse Pawl		
RD 2335	Anti-Reverse Cam		
RD 2336	Worm Bearing (front)		
RD 2337	Worm Shaft Spacer		
RD 2339	Worm Shaft		
RD 2343	Oscillating Slider Retainer		
RD 2344	Oscillating Slider		
RD 2346	Drag Washer "C2" (white)	BR 0836.	
RD 2347	Click Gear		
RD 2348	Drag Washer "C1"		
RD 2349	Eared Washer "BF"		
RD 2350	Drag Shaft		
RD 2351	Drag Spring Washer		
RD 2394	Bail Trip Lever		
RD 2406	Drive Gear		
RD 2428	Pinion Gear		
RD 2429	Idle Gear		
RD 2908	Spool Assembly		RD 2912.
RD 3125	Drag Click Screw		
RD 3130	Main Shaft		
RD 3305	SiC Ceramic Roller		
RD 3402	Cover Screw		RD 3655.
RD 3403	Anti-Reverse Lever Assembly		RD 3826.
RD 3406	Handle Screw Cap Assembly		RD 3668.
RD 3415	Rotor		
RD 3416	Quick-Fire II Trigger Assembly		RD 3679.
RD 3417	Bail Assembly		
RD 3418	Bail Spring Guide (A)		
RD 3419	Bail Spring		
RD 3420	Bail Spring Guide (B)		
RD 3421	Bail Spring Cover		
RD 3422	Counterbalance Cover		
RD 3425	Handle Assembly		
RD 3432	Side Cover Screws		RD 3827.
RD 3433	Pressure Screw Assembly		
RD 3434	Fightin' Drag II Lever		RD 2466, RD 2698, RD 3161, RD 1392, RD 1388, RD 1401, RD 2019, RD 1411, RD 1829, RD 2103
RD 3435	Drag Programmer		RD 2467, RD 2698, RD 0861, RD 1241, RD 0824, RD 0867, RD 0895, RD 0957, RD 0889, RD 1028, RD 1275, RD 1051, RD 1373, RD 1389, RD 1412
RD 3436	Drag Programmer Screw		RD 2353.
RD 3437	Body Assembly		