


SHIMANO

TALICA

TAC40IIA



(51RJ381A50X)

#	Part No.	TGT No.	Description	#	Part No.	TGT No.	Description	#	Part No.	TGT No.	Description
1	13ZQG		Screw	38	10PYJ	1941	Harness Lug	75	10KJ6		Drag Plate Spring
2	13ZQH		Push Button Shield	39	104JP	1227	Ball Bearing	76	1496D		Spool Shaft
3	10PWJ	1475	Slide Plate Spring	40	1496G		Washer	77	13ZRC		Cross Pin
4	13ZRS		Slide Plate Assembly	41	10PFS	2099	Anti-Reverse Pawl Pin	78	14ARE		Spool Assembly
5	10PBN	1477	Handle Nut Plate	42	10MWC	883	Anti-Reverse Pawl Assembly	79	1496J		Spool Shaft Collar
6	109XB	1552	Push Low Button Shaft	43	10KVH	1942	Anti-Reverse Pawl Keeper	80	14962		Washer
7	105NK	62	E Lock	44	1055F	1965	Screw	81	1496A		Drag Spring Spacer
8	106XP	1479	Handle Bolt	45	1496E		Pinion Gear A	82	1496Y		Drag Spring
9	14AZ1		Screw	46	1496B		Pinion Gear B	83	14961		Washer
10	14AZ2		Handle Knob I.D. Plate	47	10DAQ	1947	Anti-Reverse Ratchet	84	105RZ	900	E Lock
11	14AZ3		Screw	48	10KXA	1567	Ball Bearing	85	1496M		Click Gear Support
12	14960		Washer	49	13ZQW		Drive Gear Washer	86	103E9	729	Screw
13	10EU1	1935	Handle Knob Bushing	50	1497D		Drive Gear A	87	1496H		Click Gear
14	14AZ4		Handle Knob	51	10D61	990	Friction Washer	88	1495W		Click Gear Retainer
15	14AR9		Handle Shank Assembly	52	1497G		Drive Gear B	89	14BG3		Click Spring
16	14ARA		Handle Assembly	53	10D6P	1964	Drive Shaft	90	10J16	3904	Washer
17	10KZS	1554	Drive Shaft Shield	54	10KXH	993	Gear Select Cross Bar	91	14964		Click Pawl
18	141QR		Washer	55	10KXL	994	Cross Bar Stop	92	104H2	65	Spacer
19	109AS	1963	Drive Gear Bushing	56	109VM	995	Drive Shaft Spring B	93	10LZL		Screw
20	108PH	1937	Ball Bearing	57	10KXQ	996	Drive Shaft Spring	94	14966		Click Spring Retainer
21	14ARB		Pre-Program Dial Assembly	58	10D5B	997	Friction Washer	95	14967		Click Spring Holder
22	10K07	1484	Click Spring	59	10FCD	1572	Drive Shaft Screw	96	14965		Click Spring
23	10JX6	1485	Click Pin	60	10EYP	1950	Waterproof Ring	97	14969		Click Switch Cam
24	141Q0		Lever Shaft Body	61	10PRU	1577	Screw	98	14970		Set Plate
25	14ARC		Drag Control Lever Assembly	62	1496K		Cooling Shield	99	14973		Click Spring Shaft
26	13ZQM		Lever Click	63	1495X		O Ring	100	14ARF		Frame Assembly
27	10C3X	1489	Lever Click Shoe	64	1496F		Pinion Guard	101	10M6T	1313	Screw
28	13ZQN		Lever Click Cover	65	1496P		Drag Washer	102	14968		Click Button
29	10S65		Screw	66	1496L		Screw	103	1458J		Washer
30	1497C		Lever Protector	67	1496R		Drag Plate				
31	13ZQQ		Screw	68	10KXE	1234	Ball Bearing	501	10J9W	1471	Rod Clamp Bolt (Accessory)
32	108DP	1215	Lever Thrust Ring	69	1496N		Pressure Release Spring	502	10JCG	1442	Rod Clamp Nut B (Accessory)
33	10G6G	1216	Washer	70	1496W		Pressure Plate	503	10J9P	1443	Rod Clamp (Accessory)
34	10F6C	1707	Lever Click Gear	71	10BMF	1956	Ball Bearing	504	10JC3	1444	Rod Clamp Nut A (Accessory)
35	148UZ		Screw	72	14963		Bearing Retainer	505	10MJ8	1547	Wrench (Accessory)
36	14ARD		A Side Plate Assembly	73	13B0R		Washer	506	141Q2		Light Line Cam (Accessory)
37	10M6X	767	Screw	74	1496U		Bearing Spacer	507	10AAB	1962	Harness Lug Plug (Accessory)

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(250214)_001