
SHIMANO

TIAGRA

TI-30A



(51RJ201030U)

#	Part No.	Description	#	Part No.	Description	#	Part No.	Description	
0002A	10QUC	Handle Bolt Plate	0503	10CC3	Lever Shaft Body	0669	10PHV	Screw	
0040A	1052C	Pre-Load Spring	0504	10EWQ	Pre-Program Key Pin	0670	108B5	Drag Control Lever	
0042A	104L7	Bearing Thrust Washer	0505	1089E	Pre-Program Key	0671	104BG	Lever Click Shoe	
0069	105NK	E Lock	0506	1088X	Pre-Program Screw	0672	10C3T	Lever Click	
0091	109XD	Push Button Shield	0509	10QK6	Drive Gear A	0673	10PHT	Screw	
0092	10LZ9	Screw	0510	109WT	Drive Gear B	0674	10C9V	Lever Quadrant	
0093	10PWH	Slide Plate Spring	0511	10D5T	Drive Shaft	0675	10CCJ	Strike Stop	
0094	109XC	Slide Plate	0512	104LD	Cross Pin A	0676	10BNN	Pressure Spring	
0107	109VM	Drive Shaft Spring B	0513	10N9J	Pinion Gear B	0677	10F3R	Right Side Plate B	
0206	10D61	Friction Washer C	0514	10HYG	Pinion Shaft	0678	10BNG	Free Spool Detent	
0209	10KXH	Gear Select Cross Bar	0515	10MCT	Cross Pin B	0680	10PYE	Harness Lug	
0210	10KXL	Cross Bar Stop	0518	10CCV	Pressure Plate Spring	0681	108CY	Plunger Holder	
0211	10KXQ	Drive Shaft Spring	0521	10G11	Drag Washer	0682	103HQ	Screw	
0212	10D5B	Friction Washer A	0522	10EVT	Pressure Plate	0683	10GUU	Click Spring	
0213	10FCD	Drive Shaft Screw	0524	10EW9	Waterproof Ring	0684	10EZP	Plunger Cross Pin A	
0276	10F1S	Cross Pin Support Spring	0526	10PSW	Stand Washer	0685	108D8	Alert Plunger	
0424	10LZ5	Screw	0527	10NY8	Stand	0686	1052Q	Alert Ratchet	
0474	10KZQ	Drive Shaft Shield	0528	10PV9	Screw	0688	10G48	Drag Plate	
0475	107QW	Drive Shaft Thrust Washer	0529	10DAH	Anti-Reverse Ratchet	0689	104QV	Cooling Shield	
0476	105UA	Bearing Spacer	0530	10KNT	Bearing Spacer	0691	107Z7	Left Side Plate	
0477	108H5	Pre-Program Dial	0531	103E9	Screw	0693	102UL	Handle Assembly	
0478	10K06	Friction Shoe Spring	0532	10KVD	Set Plate	0694	10EMC	Spool	
0479	1035W	Dial Click Shoe	0533	10CBU	Dog Spring	0695	1059G	One-Piece Frame	
0480	10J1W	Dial Click	0534	10PKF	Dog	0701	10BC4	Screw	
0482	10BHM	Lever Hub Cover	0563	10LVE	Screw	0768	10BKB	Right Side Plate A	
0483	109RR	Washer	0567	10JDE	Bearing Thrust Washer	0769	105ZE	Handle Knob Bushing	
0484	105NG	E Lock	0575	10BMH	Ball Bearing	0811	108FY	Strike Alert Lever	
0485	109RQ	Lever Thrust Ring	0581	10EYZ	O Ring	0873	10PHP	Screw	
0487	109RP	Lever Thrust Ring	0593	10C3Y	Lever Click Cover				
0490	1059Y	Spacer	0594	10MGG	Screw	0648	10JC7	Rod Clamp Nut A	(Accessory)
0492	10EZS	Plunger Cross Pin B	0601	10PRP	Screw	0697	105N9	Rod Clamp Nut B	(Accessory)
0493	10EZM	Plunger Cross Pin Support	0632	10MT4	Screw	0698	10J9U	Rod Clamp	(Accessory)
0497	103H4	Screw	0654	10ML5	Screw	0802	10JBT	Rod Clamp Bolt	(Accessory)
0501	103J1	Screw	0666	109X9	Push Low Button Shaft				
0502	10EZF	Washer	0667	106XN	Handle Bolt	0470	10MJ4	Wrench	(Accessory)

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(230303)_002