


# SHIMANO®

## TRINIDAD®

TN-30



Part No.	Description	Part No.	Description	Part No.	Description
TGT0033	Drive Shaft Retainer	TGT0285	Clutch Lever Screw	TGT0321	"BR" Friction Washer
TGT0058	Spacer "B"	TGT0286	Roller Clutch Inner Tube	TGT0322	"BR" Washer (C)
TGT0062	Click Pawl Retainer	TGT0287	Key Washer	TGT0323	"BR" Washer (A)
TGT0065	Spacer (A)	TGT0288	Drag Washer (D)	TGT0324	"BR" Gear (C)
TGT0111	Click Gear Retainer	TGT0289	Eared Washer (E)	TGT0325	"BR" Washer (B)
TGT0112	Ball Bearing	TGT0290	Key Washer (C)	TGT0326	Click Pawl Spring
TGT0128	Handle Nut Plate Screw	TGT0291	Drag Washer (B)	TGT0327	"BR" Set Plate
TGT0182	Cast Control Spacer (A)	TGT0292	Drive Gear	TGT0328	"BR" Set Plate Screw
TGT0185	"O" Ring	TGT0294	Anti-Reverse Ratchet	TGT0329	Spacer (B)
TGT0257	Brake Collar	TGT0295	Click Pin	TGT0330	Click Pawl
TGT0261	Handle Nut Plate	TGT0296	Click Spring	TGT0331	Click Pawl Spacer
TGT0262	Handle Nut	TGT0297	Drive Shaft	TGT0332	Click Spring Retainer
TGT0263	Handle Assembly	TGT0298	Drive Shaft Washer (B)	TGT0333	Click Spring
TGT0264	Drive Shaft Shield	TGT0299	Yoke Spring	TGT0334	Click Spring Holder
TGT0265	Star Drag	TGT0300	Yoke	TGT0335	"BR" Click Spring
TGT0266	Star Drag Washer	TGT0301	Pinion Gear	TGT0336	"BR" Click Pin
TGT0267	Drag Spring Washer (9L)	TGT0302	Yoke Plate	TGT0337	Left Side Plate Screw
TGT0268	Drag Spring Washer (9H)	TGT0303	Anti-Reverse Pawl	TGT0338	"BR" Washer (D)
TGT0269	Bearing Thrust Washer	TGT0304	Set Plate Screw (B)	TGT0339	"BR" Dial
TGT0270	Bearing Seal	TGT0305	Multi-Purpose Screw	TGT0340	Left Side Plate
TGT0271	Ball Bearing	TGT0306	Anti-Reverse Pawl Keeper	TGT0341	Click Button
TGT0272	Right Side Plate Screw (D)	TGT0307	Set Plate	TGT0342	Right Side Plate
TGT0273	Right Side Plate Screw (C)	TGT0308	Set Plate Screw (A)	TGT0343	One-Piece Frame
TGT0274	Right Side Plate Screw (A)	TGT0309	Ball Bearing	TGT0344	Spool Assembly
TGT0276	Cast Control Cap	TGT0310	Drive Shaft Washer (A)	TGT0348	Spacer (C)
TGT0277	Cast Control Spacer (B)	TGT0312	Brake Shaft Holder Screw	TGT0418	Drag Washer (A)
TGT0278	Clutch Lever	TGT0313	Brake Shaft Holder		
TGT0279	Smoother	TGT0315	Click Gear	TGT0351	Rod Clamp Bolt (accessory)
TGT0280	Line Clip	TGT0316	Spool Shaft Spacer	TGT0352	Rod Clamp Nut (B) (accessory)
TGT0281	Roller Clutch Bearing	TGT0317	"BR" Gear (A)	TGT0353	Rod Clamp (accessory)
TGT0282	Eccentric Cam Bushing	TGT0318	Bearing Retainer	TGT0354	Rod Clamp Nut (A) (accessory)
TGT0283	Clutch Spring	TGT0319	"BR" Cam Pin		
TGT0284	Clutch Cam	TGT0320	"BR" Cam	TGT0355	Wrench (accessory)