
www.reelschematic.com



TT No.	PARTS NAMES	TT No.	PARTS NAMES	TT No.	PARTS NAMES
0002A	Handle Bolt Plate	0171	Cooling Shield	0209	Gear Select Cross Bar
0013	“C” Lock	0172	Pre-Load Spring A	0210	Cross Bar Stop
0040A	Pre-Load Spring B	0174	Seal Lock	0211	Drive Shaft Spring
0042A	Bearing Thrust Washer	0176	Pressure Release Spring	0212	Friction Washer (A)
0069	“C” Lock	0178	Main Shaft	0213	Drive Shaft Screw
0090	Push Button Shield Screw	0179	“C” Lock	0216	Click Button Washer
0091	Push Button Shield	0181	Ball Bearing	0217	Click Button
0092	Handle Bolt Plate Screw	0183	Click Gear	0228	Pressure Spring (C)
0093	Slide Plate Spring	0184	Click Gear Screw	0229	Cross Pin
0094	Slide Plate	0185	Click Pawl	0236	Lever Quadrant
0107	Drive Shaft Spring “B”	0186	Click Pawl Washer	0237	Side Plate
0117	Ball Bearing	0187	Click Spring Screw	0238	Spool
0147	Push “Low” Button Shaft	0188	Click Spring	0239	Cross Bar
0148	Handle Bolt	0189	Cross Bar Bolt (A)	0240	One Piece Frame
0150	Drive Shaft Shield	0190	Line Guard	0245	Drag Plate
0151	Pre-Program Dial	0192	Harness Lug	0246	Drag Washer
0152	Dial Spring	0193	Cross Bar Bolt (B)	0338	Dog
0153	Body “O” Seal	0194	Lever Click Spring	0340	Guard Against Dog
0154	Lever Shaft Body	0195	Click Spring Screw	0341	Dog Spring Guide
0155	Drag Control Lever (# 30)	0196	Lever Thrust Washer	0342	Dog Spring
0156	Friction Shoe Spring	0199	Free Spool Detent	0406	Side Plate Screw (B)
0157	Friction Shoe	0200	Ball Bearing	0471	Handle Assembly
0158	Quadrant Anchor Bolt	0201	Pinion Gear (A)		
0159	Bolt Shield	0202	Pinion Gear (B)		
0161	Quadrant / Line Guard Screw	0203	Pinion Guard	0146	Wrench
0162	Strike Stop	0205	Drive Gear (A)	0224	Rod Clamp Bolt
0163	Pressure Spring (B)	0206	Friction Washer (C)	0225	Rod Clamp Nut (B)
0164	Side Plate Screw (A)	0207	Drive Gear (B)	0226	Rod Clamp
0167	Guard Screw	0208	Drive Shaft	0227	Rod Clamp Nut (A)

(120129)