
www.reelschematic.com

SHIMANO®

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

EXPLODED PARTS VIEW



TO ORDER:
This reel belongs to the "Triton" series. Please order parts using the abbreviation "TRN" and the part number.

TRITON® 300

PARTS LIST

PART#	DESCRIPTION
9.	Cast Control Spacer
41.	Click Spring Screw
42.	Click Spring
43.	C-Lock "A"
54.	Handle Bolt
55.	Handle Bolt Lock Screw
56.	Handle
57.	Drag Star
58.	Clutch Lever Screw
59.	Clutch Lever
60.	Cast Control Cap
62.	Right Side Plate Screw
63.	Set Plate Screw
64.	Right Side Plate
65.	Eccentric Cam
66.	Eccentric Cam Spring
67.	Right Spool Shaft Bearing
68.	Right Bearing Lock
69.	Drag Tube
70.	Drag Bearing
71.	Soft Spring Washer
72.	Hard Spring Washer
73.	Drag Disk
74.	Drag Washer
75.	Key Washer
76.	Drive Gear
77.	Pinion Gear
78.	Pinion Yoke Spring
79.	Pinion Yoke
80.	Base Drag Washer
81.	Set Plate
82.	Anti Reverse Dog
83.	A/R Dog Spring
84.	Eccentric Jack
85.	Spool
86.	Click Gear
87.	Spool Shaft Gear
88.	Spool Shaft Gear Lock
89.	Line Guide Stabilizer Bar
91	C-Lock "B"
92.	L/W Gear Washer
93.	Level Wind Bearing
94.	Level Wind Guard
95.	Line Guide
96.	Level Wind Pawl
97.	Pawl Shim (Optional)
98.	Pawl Cap
99.	Level Wind Gear
100.	Frame
101.	L/W Drive Gear Screw
102.	L/W Drive Gear
103.	L/W Drive Gear Spacer
104.	Click Pawl
105.	Click Pawl Washer
106.	Left Spool Shaft Bushing
107.	Friction Shim
108.	Left Side Plate
109.	Click Button Washer
110.	Click Button
111.	Left Side Ring
112.	Left Side Plate Screw
SATRTN300 -	Complete Spool Assy.

Prices and specifications subject to change without notice

JUNE 1986