
www.reelschematic.com

# SHIMANO

## 1992 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718



TLD 2 Speed 30 92

| TT No. | PARTS NAMES | TT No. | PARTS NAMES | TT No. | PARTS NAMES |
|---|---|---|---|---|---|
| 0002A | Handle Bolt Plate | 0169 | Dog | 0209 | Gear Select Cross Bar |
| 0013 | "C" Lock | 0170 | Dog Spring | 0210 | Cross Bar Stop |
| 0040A | Pre-Load Spring B | 0171 | Cooling Shield | 0211 | Drive Shaft Spring |
| 0042A | Bearing Thrust Washer | 0172 | Pre-Load Spring A | 0212 | Friction Washer (A) |
| 0069 | "C" Lock | 0174 | Seal Lock | 0213 | Drive Shaft Screw |
| 0090 | Push Button Shield Screw | 0176 | Pressure Release Spring | 0216 | Click Button Washer |
| 0091 | Push Button Shield | 0177 | Side Plate Screw (B) | 0217 | Click Button |
| 0092 | Handle Bolt Plate Screw | 0179 | "C" Lock | 0218 | Main Shaft |
| 0093 | Slide Plate Spring | 0181 | Ball Bearing | 0220 | Line Guard |
| 0094 | Slide Plate | 0183 | Click Gear | 0228 | Pressure Spring (C) |
| 0107 | Drive Shaft Spring "B" | 0184 | Click Gear Screw | 0229 | Cross Pin |
| 0117 | Ball Bearing | 0185 | Click Pawl | 0230 | Friction Washer (D) |
| 0147 | Push "Low" Button Shaft | 0186 | Click Pawl Washer | 0235 | Handle Assembly |
| 0148 | Handle Bolt | 0187 | Click Spring Screw | 0236 | Lever Quadrant |
| 0150 | Drive Shaft Shield | 0188 | Click Spring | 0237 | Side Plate |
| 0151 | Pre-Program Dial | 0189 | Cross Bar Bolt (A) | 0241 | Drag Control Lever (# 50) |
| 0152 | Dial Spring | 0192 | Harness Lug | 0242 | Spool |
| 0153 | Body "O" Seal | 0193 | Cross Bar Bolt (B) | 0243 | Cross Bar |
| 0154 | Lever Shaft Body | 0194 | Lever Click Spring | 0244 | One Piece Frame |
| 0156 | Friction Shoe Spring | 0195 | Click Spring Screw | 0245 | Drag Plate |
| 0157 | Friction Shoe | 0196 | Lever Thrust Washer | 0246 | Drag Washer |
| 0158 | Quadrant Anchor Bolt | 0199 | Free Spool Detent | | |
| 0159 | Bolt Shield | 0200 | Ball Bearing | | |
| 0161 | Quadrant/Line Guard Screw | 0201 | Pinion Gear (A) | | |
| 0162 | Strike Stop | 0202 | Pinion Gear (B) | 0146 | Wrench |
| 0163 | Pressure Spring (B) | 0203 | Pinion Guard | 0224 | Rod Clamp Bolt |
| 0164 | Side Plate Screw (A) | 0205 | Drive Gear (A) | 0225 | Rod Clamp Nut (B) |
| 0166 | Guard against Dog | 0206 | Friction Washer (C) | 0226 | Rod Clamp |
| 0167 | Guard Screw | 0207 | Drive Gear (B) | 0227 | Rod Clamp Nut (A) |
| 0168 | Dog Spring Retainer | 0208 | Drive Shaft | | |

Prices and specifications subject to change without notice (020903)