


# SILSTAR EC-5130



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	001-0715	FRONT COVER	14	014-0715	BODY
2	002-0115	ROTOR NUT	15	015-0715	DRAG SCREW
3	003-0415	ROTOR A'SSY	16	016-0615	DRAG DIAL
4	004-0315	SPRING	17	017-0715	PUSH BUTTON
5	005-0415	PICK UP	22	022-0415	DRIVE GEAR
6	006-0115	"E" RING	23	023-0415	DRIVE GEAR A/D W/S
7	007-0115	WASHER	26	026-0515	ANTI-R-CLAW
8	008-0415	SPOOL	29	029-0715	BODY COVER
10	010-0715	MAIN SHAFT	35	035-0415	HANDLE A'SSY
11	011-0415	PINION	36	036-0115	TOOTH WASHER
12	012-0315	SPRING	37	037-0415	SCREW
13	013-0715	LEAF SPRING	40	040-0415	WASHER

PARTS LIST FOR 5130 REEL