



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	001-3010	SPOOL A'SSY	46	046-1810	WASHER
2	002-2710	MAIN SHAFT A'SSY	47	047-1810	CLICK METAL
3	003-3010	ROTOR NUT	49	049-1810	DISK B WASHER
5	005-3010	ROTOR	50	050-1810	DISK D WASHER
6	006-3010	BAIL HOLDER COVER	51	051-1810	DISK C WASHER
7	007-0410	BAIL HOLDER C/O S/C	52	052-1810	DISK A WASHER
8	008-3010	BAIL KICK LEVER S/P	53	053-1810	COIL S/P
9	009-3010	BAIL LEVER	54	054-1810	PRESSURE WASHER
13	013-3010	BAIL SPRING	55	055-1810	PRESSURE
14	014-3010	ARM LEVER C/O	56	056-2610	DRAG KNOB A'SSY
15	015-0410	ARM LEVER C/O S/C	57	057-0710	DRAG KNOB S/C
16	016-3010	LINE SLIDER S/C	58	058-3010	HANDLE A'SSY
17	017-3010	ARM LEVER	59	059-1810	SCREW
18	018-2610	LINE ROLLER COLLAR	60	060-3010	O/S SLIDER
19	019-1810	LINE ROLLER	65	065-2710	A-R-CAM
20	020-3010	ARM LEVER S/C	69	069-2710	SCREW
21	021-3010	BAIL A'SSY	75	075-2710	SCREW
22	022-3010	BAIL HOLDER S/C	82	082-3010	SCREW
23	023-2710	BEARING PLATE	83	083-3010	ROTOR RETAINER
24	024-2610	BEARING	84	084-2710	A-R-LEVER W/S
25	025-3010	RATCHET	85	085-3010	KICK LINK
26	026-2710	PINION	86	086-3010	SCREW
27	027-1810	RETAINER	87	087-3010	NUT
29	029-3010	BODY A'SSY	88	088-3010	LEAF S/P
31	031-3010	ANTI-R-LEVER	89	089-3010	NUT
35	035-2710	ANTI-R-CLAW ADJ	90	090-3010	NUT
36	036-3010	DRIVE GEAR	91	091-2710	LINK A'SSY
37	037-3010	O/S GEAR	92	092-3010	SCREW
38	038-0710	DRIVE GEAR ADJ W/S	93	093-3010	BEARING
39	039-2710	A-R-CLAW	94	094-3010	BEARING
40	040-1810	DRAG LEAF S/P	95	095-2610	BALL
41	041-3010	ANTI-R-CLAW S/C	96	096-2710	SPRING
43	043-3010	BODY COVER A'SSY	97	097-3010	HANDLE SCREW
44	044-3010	BODY COVER S/C	98	098-3010	WASHER
45	045-2610	HANDLE S/C CAP			

PARTS LIST FOR 2835 REEL