

spinning reel parts list

IMPORTANT - SPECIFY REEL MODEL, NUMBER WHEN ORDERING PARTS.
 Example - Extra spool for Elite-specify 970 (reel no.) 6 (spool part no.)

| No. | Description |
|-----|------------------------------|
| 1 | Drag knob assembly |
| 2 | Drag retainer |
| 3 | Spool Washer "U" |
| 4 | Spool Washer "D" |
| 5 | Spool Washer "A" |
| 6 | Spool assembly |
| 7 | Main shaft |
| 8 | Spool washer |
| 9 | Spool click gear |
| 10 | Rotor nut |
| 11 | Rotor retainer washer |
| 12 | Bail screw |
| 13 | Arm lever |
| 14 | Roller washer |
| 15 | Line roller (ball bearing) |
| 16 | Bail assembly |
| 17 | Bail spring cover |
| 18 | Bail spring cover screw |
| 19 | E-clip |
| 20 | Spring holder |
| 21 | Holder spring |
| 22 | Spring shaft |
| 23 | Balance |
| 24 | Balance cover |
| 25 | Balance cover screw |
| 26 | Rotor nut lock screw |
| 27 | E-clip |
| 28 | Kick lever cover screw |
| 29 | Kick lever cover |
| 30 | Kick lever |
| 31 | Kick lever spring |
| 33 | Ratchet |
| 34 | Ratchet holder |
| 35 | Bearing plate |
| 36 | Ball bearing |
| 37 | Collar |
| 38 | Pinion Gear |
| 39 | Bearing plate screw |
| 46 | Stopper screw |
| 47 | Stopper assembly |
| 48 | Handle screw cap |
| 49 | Handle screw cap washer |
| 50 | Body |
| 51 | Ball bearing (bush) |
| 52 | Drive gear |
| 53 | Drive gear adjustable washer |
| 54 | Ball bearing (bush) |
| 55 | Handle assembly |
| 56 | Body cover |
| 57 | Body cover screw |
| 58 | Oscillating gear |
| 59 | Oscillating gear screw |
| 60 | Oscillating slider |
| 61 | Oscillating slider screw |
| 62 | Stopper lever spring |
| 63 | Stopper lever |
| 64 | Click claw spring |
| 65 | Click claw |
| 66 | Click claw screw |

