

CONDOR™

Spinning Reel Parts List

Model 510, 520, 530, 540 and 550 - 555

IMPORTANT — Specify Reel Model Number When Ordering Parts.

EXAMPLE — Extra Spool for **Condor 530** — Order part no. **530** (reel model no.) -2 (part model no.).

| Part # | Description | Part # | Description | Part # | Description |
|--------|------------------------|--------|----------------------|--------|----------------------------|
| 1 | Drag Knob Assembly | 16 | Bearing Retainer | 30 | Silent A/R Spring |
| 2 | Spool Assembly | 17 | Ball Hinge Screw | 31 | Main Gear |
| 3 | Spool Washer | 18 | Ball Roller Screw | 32 | Main Gear Shim |
| 4 | Spool Click | 19 | Ball Hinge | 33 | Sideplate Bushing |
| 5 | Main Shaft | 19A | Bail Spring | 34 | Sideplate |
| 6 | Nut Locking Screw | 20 | Bail Roller Flange | 35 | Sideplate Screws (3) |
| 7 | Rotor Nut | 21 | Bail Roller | 36 | Handle Assembly |
| 8 | Counterweight Screw | 22 | Bail Wire Assembly | 37 | Oscillation Pin |
| 9 | Counterweight | 23 | Trip Lever Screw | 38 | Oscillation Arm |
| 10 | Ball Wire Pivot | 24 | Trip Lever Spring | 39 | Anti-Reverse Slide Switch |
| 11 | Rotor | 25 | Trip Lever | 40 | Anti-Reverse Switch Spring |
| 12 | Rotor Bushing Race | 26 | Rotor Cover Screw | 41 | Anti-Reverse Pawl |
| 13 | Rotor Bushing | 27 | Rotor Cover | 42 | Anti-Reverse Pawl Screw |
| 14 | Pinion Gear | 28 | Main housing | 43 | Bail Trip Lever |
| 15 | Bearing Retainer Screw | 29 | Main Housing Bushing | 44 | Handle Screw |

