

# Elite® spinning reel parts list

**IMPORTANT - SPECIFY REEL MODEL NUMBER WHEN ORDERING PARTS.**  
 Example - Extra spool for Elite 910-specify 910 (reel no.)-6 (spool part no.)

- 1 Drag knob assembly
- 6 Spool assembly
- 7 Spool washer
- 8 Spool click gear
- 9 Rotor nut
- 10 Kick lever cover screw
- 11 Kick lever cover
- 12 Kick lever
- 13 Kick lever spring
- 14 Rotor nut lock screw
- 15 "E" clip
- 16 "E" clip
- 17 Ball screw
- 18 Arm lever
- 19 Arm lever pin
- 20 Drag spring washer
- 21 Line roller
- 23 Bail assembly
- 24 Spring shaft
- 25 Arm lever spring
- 26 Spring holder
- 27 Arm lever spring cover
- 28 Arm lever spring cover screw
- 29 Ball bearing
- 31 Pinion gear
- 32 Bearing screw
- 33 Handle screw cap
- 34 Handle cap washer
- 35 Body

- 38 Stopper bushing
- 39 Stopper spring
- 41 Stopper "H"
- 42 Stopper screw
- 43 Body bushing

- 44 Drive gear
- 46 Drive gear adjustable washer
- 47 Ball bearing
- 48 Oscillation gear
- 49 Oscillation slider

- 50 Main shaft screw
- 51 Body cover
- 52 Body cover screw
- 53 Handle assembly
- 54 Main shaft
- 55 Rotor

