



# Elite<sup>®</sup> Spinning Reel Parts List

**IMPORTANT - SPECIFY REEL MODEL NUMBER WHEN ORDERING PARTS.**  
 Example - Extra spool for Elite 940A - specify 940A (reel no.)-6 (spool part no.)

Key# Description

- 1 Drag Knob Assy.
- 2 Drag Retainer
- 3 Spool Washer "B"
- 4 Spool Washer "A"
- 5 Spool Washer "D"
- 6 Spool Assy.
- 7 Spool Washer
- 8 Click Gear
- 9 Rotor Nut
- 10 Kick Lever Cover Screw
- 11 Kick Lever Cover
- 12 Kick Lever
- 13 Kick Lever Spring
- 14 Rotor Nut Lock Screw
- 15 "E"-Clip
- 16 "E"-Clip
- 17 Bail Screw
- 18 Arm Lever
- 19 Drag Spring Washer
- 20 Bail Collar
- 21 Super Line Roller
- 23 Bail Assy.
- 24 Spring Shaft
- 25 Arm Lever Spring
- 26 Spring Holder
- 27 Arm Lever Cover
- 28 Arm Lever Cover Screw
- 29 Ball Bearing
- 30 Ratchet Gear
- 31 Pinion Gear
- 32 Bearing Screw
- 33 Handle Screw Cap

- 34 Handle Screw Washer
- 35 Body
- 36 Stopper Lever
- 37 Stopper Lever Spring
- 38 Stopper Bushing
- 39 Stopper Spring
- 40 Rotor
- 41 Stopper "B"

- 42 Stopper Screw
- 43 Bush
- 44 Drive Gear
- 45 Silent Cam
- 46 Drive Gear Adj. Washer
- 47 Ball Bearing
- 48 Oscillation Gear
- 49 Oscillation Slider

- 50 Main Shaft Screw
- 51 Body Cover
- 52 Body Cover Screw
- 53 Handle Assy.
- 54 Main Shaft
- 56 Balance
- 57 Balance Cover
- 58 Balance Cover Screw

