



Detail No.	Part Name	Part No.	Price	Detail No.	Part Name	Part No.	Price
1	Control Button	C-17-B	1.50	21	Right Cover Plate	CE-27-B	1.25
2	Frame Assembly	CE16-B	4.50	22	Crank Nut	RG-11	.30
3	Left Cover Plate	CE33-B	.75	23	Crank Assembly	C-26-B	1.00
4	Pinion Gear	CE-22	.50	24	Pick-up Arm Assembly	CE-38	1.50
5	Spool Friction Washer	CA-35	.10	25	Pick-up Arm Retaining Ring	R-51	.10
6	Spool Assembly	CD-15	2.50	26	Pick-up Arm Retaining washer	CA-47	.10
8	Pickup Assembly	CE-24-B	4.00	27	Pick-up Arm Spring	C-37	.20
9	Pickup Wear Rings (Front)	B-61	.50	28	Line Disc	CB-58	.25
9A	Pickup Wear Rings (Rear)	CB-36	.75	29	Drag Washer	B-31	.20
10	Outer Cone Assembly	CK-25-B	4.00	30	Drag Spring Rivet	B-13	.10
11	Retainer Spring	C-21	.10	31	Non-Reverse Lever Screw	R-18	.10
12	Spring Retainer Washer	C-20	.10	32	Non-Reverse Pawl Spring	C-40	.10
13	Main Shaft Spring	C-19	.15	33	Non-Reverse Tension Washer	C-29	.20
14	Main Shaft	CE-18	.50	34	Crank Stud	R-40	.15
15	Drive Gear Assembly	CE-32	1.50	35	Crank Handle	R-39B	.30
16	Non-Reverse Pawl	C-30	.10	36	Pinion Thrust Washer	C-47	.10
17	Non-Reverse Throwout	C-31	.20	37	Click Spring	C-39	.15
18	Non-Reverse Lever	C-28	.25	38	Click Spring Rivet	CA-43	.10
19	Drag Adjusting Spring	CB-23	.15	39	Anti-Rattle Spring	C-42	.10
20	Cover Plate Screws	R-18	.10	40	Anti-rattle spring rivet	CB-43	.10