



Detail No.	Part Name	Part No.	Price	Detail No.	Part Name	Part No.	Price
1	Control Button	C-17	.80	15	Drive Gear Assembly	C-32	1.50
2	Frame Assembly	C-16	4.00	16	Non-Reverse Pawl	C-30	.10
3	Left Cover Plate	C-33	.75	17	Non-Reverse Throwout	C-31	.20
4	Pinion Gear	C-22	.40	18	Non-Reverse Lever	C-28	.25
5	Spool Friction Washer	C-35	.10	19	Drag Adjusting Spring	C-23	.15
6	Spool Assembly	C-15	2.00	20	Cover Plate Screws	R-18	.10
8	Pick-up Assembly	C-24	3.25	21	Right Cover Plate	C-27	1.25
9	Pick-up Wear Rings (Front)	C-36	.50	22	Crank Nut	RG-11	.35
9A	Pick-up Wear Rings (Rear)	CA-36	.75	23	Crank Assembly	C-26	.75
10	Outer Cone Assembly	CH-25	4.00	24	Pick-up Arm Assembly	C38A	.75
11	Retainer Spring	C-21	.10		Outer Cone Assembly, Non-Fluted	C-25	3.25
12	Spring Retainer Washer	C-20	.10				
13	Main Shaft Spring	C-19	.15				
14	Main Shaft	C-18	.50				

\*Prior to the introduction of the Contour Control Spin Cast Reel in June 1959, all Spin Cast reels had non-fluted Outer Cone Assemblies. When ordering this part, please indicate if reel is Contour control.