



Revised 700 Series

Detail No.	Part Name	3-201-725A Part No.	3-201-730A Part No.	3-201-750A Part No.	3-201-760A Part No.	Detail No.	Part Name	3-201-725A Part No.	3-201-730A Part No.	3-201-750A Part No.	3-201-760A Part No.
1	Drag Nut	SPC37	SPD40	SPC38	SPC38	28	Bail Bracket Spring	SPD83	SPD83	SPD84	SPD84
2	Spool Assy. (complete with internal parts)	SPC40	SPD41	SPC41	SPC42	29	Bail Bracket Screw	SPD85	SPO85	SPO86	SPD86
3	Retaining Ring	SPC43	SPD42	SPA89	SPA89	30	Pinion Washer-Thick		SPD87	SPD88	SPD89
4	Keyed Drag Washer	SPC44	SPD43	SPA91	SPA91	31	Anti Throw-in Screw		SPD91	SPD91	SPD91
5	Leather Drag Washer	SPC45	SPD44	SPC46	SPC46	32	Anti Throw-in Spring		SPD92	SPD93	SPD93
6	Eared Drag Washer	SPC47	SPD45	SPA95	SPA95	33	Pinion Washer-Thin			SPC92	SPC92
7	Tension Washer	SPC48	SPD46	SPC49	SPC49	34	Pinion Gear		SPD94	SPO95	SPD96
8	Spool Shell	SPC50	SPD47	SPC51	SPC52	35	Pinion Gear	SPD97			
9	Line Guard	SPC57	SPC57	SPC57	SPC58	36	Pinion Gear Ring	SPD98			
10	Click Spring	SPC59	SPD48			37	Frame	SPD99	SPE1	SPE2	SPE3
11	Click Spring Screw	SPB67	SPB67			38	Level Wind Bracket	SPD23	SPE4	SPD24	SPD24
12	Click Pawl Spring	SPB61	SPB61	SPB61	SPB61	39	Bracket Screw (2 req'd for 750A & 760A)	SPD22	SPE5	SPC15	SPC15
13	Click Pawl	SPE56	SPE56	SPE56	SPE56	40	Drive Gear	SPE6	SPE7	SPC98	SPC99
14	Click Pawl Screw	SPB68	SPB68	SPB68	SPB68	41	Drive Gear Washer	SPA27	SPA28	SPD2	SPD2
15	Spool Washer	SPC73	SPD49	SPB73	SPB73	42	Cover Plate	SPE8	SPE9	SPD6	SPD6
16	Main Shaft	SPD50	SPD51	SPD52	SPD53	43	Pawl Retaining Ring	SPB97	SPB97	SPB97	SPB97
17	Bail Wire Assembly	SPD54	SPD55	SPD56	SPD57	44	Non-Reverse Pawl	SPD8	SPE10	SPD12	SPE11
18	Line Roller	SPD58	SPD59	SPD60	SPD61	45	Non-Reverse Spring	SPB99	SPB99	SPB99	SPE13
19	Bail Bracket	SPD62	SPD63	SPD64	SPD65	46	Lever Retaining Ring	SPB96	SPB96	SPB96	SPF55
21	Line Roller Nut	SPD67	SPD67	SPC26	SPC26	47	Lever Tension Washer	SPC1	SPC1	SPC1	SPC1
22	Trip Bracket Screw	SPB68	SPB68	SPB68	SPB68	48	Non-Reverse Lever	SPD9	SPE14	SPD2	SPD10
23	Trip Bracket Spring	SPD68	SPD69	SPD68	SPE19	49	Crank Assembly	SPD12	SPE15	SPD13	SPD14
24	Trip Bracket	SPD70	SPD71	SPD72	SPD73	50	Crank Arm		SPE16	SPD16	SPD17
25	Pick-up Housing Nut	SPD74	SPD75	SPB75	SPB75	51	Crank Handle		SPE17	SPC12	SPD19
26	Pick-up Housing Washer	SPD76	SPD77	SPD78	SPD78	52	Crank Handle Screw		SPE18	SPE18	SPE18
27	Pick-up Housing	SPD79	SPD80	SPD81	SPD82	53	Cover Plate Screws	SPE11	SPC3	SPC3	SPC3
						54	Oil Cap	SPF52	SPF52	SPF52	SPF52