




# LM - LAZER MAG SOLO® 142 2011-2013 Parts List



MODEL # LM  
LAZER MAG  
SOLO® 142

Item Number	Part Number	Description
1	N/A	Solo 142 Engine
2	151364C-1	Composite Handle with Lever
3	151645	Throttle Lever with Screw & Washer
4	151401	Stop Switch Assembly
5	410090B	Stop Switch Screw (Requires 2)
6	151505	Throttle Linkage Cable
7	151510-A	Throttle Linkage Assembly (Includes #6)
		Transmission
8	140S-U	Upper Transmission (Includes #10, 11, 12, 13 & 14)
9	211310	40:1 Compound Gear
10	122210	Flange Bushing Compound (Upper)
11	140320	40:1 Pinion Gear (No Longer Available)
12	122910	Washer (No Longer Available)
13	122205	Clutch Cup Bearing
14	122410	Clutch Cup Drum
15	470840R	Upper Transmission Bolt - 6mm x 1 x 40mm (Requires 4)
16	140S-L	Lower Transmission (Includes #17, 18, 20, 21 & qty 2 - 19)
17	122920	Snap Ring Output Shaft
18	122915	Output Shaft Washer
19	122215	Flange Bushing Output Shaft (Requires 2)
20	122305	Output Shaft with Drive Gear
21	122210	Flange Bushing Compound (Lower)
22	410011S	Lower Trans Screws HI-Low Cut Philips (Requires 6)