




LM - LAZER MAG SOLO® 142 2014 - Current Model Parts List



MODEL # LM
LAZER MAG
SOLO® 142

For Transmission Information See Parts List for:
140S Transmission (includes 140S-U and 140S-L)

Item Number	Part Number	Description
1	N/A	Solo 142 Engine
2	151364C-1	Composite Handle with Lever, Screw and Washer
3	151645	Throttle Lever
4	151401	Stop Switch Assembly
5	410090B	Stop Switch Screw (Requires 2)
6	151505	Throttle Linkage Cable
7	151510-A	Throttle Linkage Assembly (Includes #6)
8	410015	Composite Handle Washer
9	410012	Composite Handle Rivet
10	410014	Throttle Linkage Screw-Lever
11	410065	Throttle Linkage Screw-Engine
12	410016	T-Sleeve
13	410013	Throttle Linkage Beveled Washer
14	470840R	Upper Transmission Bolt - 6mm x 1 x 40mm (Requires 4)
15	410011S	Lower Trans Screws HI-Low Cut Phillips (Requires 6)