



Tibor Light®



Change your reel from left to right hand retrieve in seconds. Using a small screwdriver, simply press the Clutch Pins and rotate 180°.