


BAIT CASTING REEL

Samira K Series

KL100

Please order by parts number, not key number
Bitte Best-Nr angeben! Nicht "key" -nr!
Veuillez indiquer le numero de la piece (Non "key" no.)




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	2F5-097-02	HANDLE NUT CAP	44	2Z2-021-01	BUSHING
2	2E3-016-01	NUT	45	2M2-017-01	CLUTCH PLATE
3	2YH-084-02	HANDLE TOTAL ASSEMBLY	46	2G3-022-01	IDLE GEAR
4	2E2-030-02	F20M-050 SCREW	47	2Q3-086-01	RETRACTOR SPRING
5	2E4-018-01	RETAINER	48	2F8-016-01	GEAR SETTING PLATE
6	2F8-050-01	CLICK LEAF SPRING HOLDER	49	2E2-031-01	A26M-075 SCREW
7	2L3-029-01	CLICK LEAF SPRING	50	2W1-054-01	052-080 WASHER
8	2D4-008-03	STAR DRAG LEVER	51	2W1-070-01	052-080 WASHER
9	2Q1-052-01	STAR DRAG SPRING	52	2E5-013-01	E3.0 RETAINER
10	2E3-029-01	STAR DRAG NUT	53	2Y5-061-03	SPOOL ASSEMBLY
11	2W1-020-01	081-130 WASHER	54	2C2-057-01	BRAKE COLLAR
12	2L1-004-01	SPRING WASHER	55	2Z1-023-01	814-4 BALL BEARING
13	2W1-035-05	080-105 WASHER	56	2F3-037-01	CLICK GEAR
14	2Z1-024-05	812-2.5 BALL BEARING	57	2YM-041-01	WORM SHAFT ASSEMBLY
15	2A4-022-01	ONE-WAY CLUTCH INNER TUBE	58	2C1-059-01	SPACER
16	2E3-024-01	CAST CONTROL NUT	59	2C2-042-01	WORM SHAFT BUSH
17	2W5-026-01	SPACER	60	2C4-015-01	LEVEL WIND GUARD
18	2W5-029-01	CAST CONTROL SPACER	61	2YR-038-01	LINE GUIDE ASSEMBLY
19	2E4-019-01	BEARING RETAINER	62	2M5-005-01	LINE GUIDE PIN
20	2C2-003-01	LINE ROLLER BUSH	63	2W1-100-01	020-068 WASHER
21	2E9-005-01	O RING	64	2E3-014-01	LINE GUIDE NUT
22	2E0-011-01	RIGHT SIDE COVER SCREW	65	2E2-034-01	A20M-090 SCREW
23	2W1-132-01	036-060 WASHER	66	2Y8-096-10	BODY ASSEMBLY
24	2YF-034-23	RIGHT SIDE COVER ASSEMBLY	67	2W1-046-01	051-068 WASHER
25	2E5-006-01	E2.5 RETAINER	68	2F6-050-01	BEARING HOLDING PLATE
26	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING	69	2E2-037-01	A26M-060 SCREW
27	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY	70	2P4-006-02	LEVEL WIND GUIDE
28	2W2-032-01	KEY WASHER	71	2C4-013-02	CASTING BAR GUIDE A
29	2W1-126-02	082-210 WASHER	72	2Y5-085-03	CASTING BAR ASSEMBLY
30	2W3-017-01	EARED WASHER	73	2C4-014-02	CASTING BAR GUIDE B
31	2W1-111-02	100-230 WASHER	74	2P2-021-01	CASTING BAR PIN
32	2W2-025-01	KEY WASHER	75	2P4-008-02	CASTING BAR SUPPORT
33	2G1-027-01	DRIVE GEAR	76	2E2-003-01	B26M-036 SCREW
34	2YG-023-01	OSCILLATING GEAR ASSEMBLY	77	2E4-011-01	BEARING RETAINER
35	2A3-027-01	RATCHET	78	2W5-015-01	CAST CONTROL SPACER
36	2M3-048-01	DRIVE SHAFT	79	2F6-055-01	CLICK PLATE
37	2Z1-018-05	510-3 BALL BEARING	80	2E2-022-01	B20M-030 SCREW
38	2G2-010-01	PINION GEAR	81	2F2-020-01	CLICK SPRING
39	2Q1-031-01	YOKE SPRING	82	2F4-018-01	CLICK PAWL
40	2A2-039-01	PINION YOKE	83	2F5-123-10	LEFT SIDE COVER
41	2E2-047-01	A20M-065 SCREW	84	2F7-004-01	CLICK SWITCH
42	2F8-030-01	CLUTCH CAM RETAINER	85	2X3-004-01	WRENCH
43	2YA-018-01	CLUTCH CAM ASSEMBLY	86	2YT-144-03	SPOOL TOTAL ASSEMBLY

BAIT CASTING REEL

Samira K Series

KL101

Please order by parts number, not key number
Bitte Best. Nr. angeben (nicht "key" nr.)
Veuillez indiquer le numéro de la pièce (Non "key" no.)



Key NO.	Parts No.	Parts name
1	2F5-097-02	HANDLE NUT CAP
2	2E3-016-02	NUT
3	2YH-084-02	HANDLE TOTAL ASSEMBLY
4	2E2-030-02	F20M-050 SCREW
5	2E4-018-01	RETAINER
6	2F8-050-01	CLICK LEAF SPRING HOLDER
7	2L3-029-01	CLICK LEAF SPRING
8	2D4-008-03	STAR DRAG LEVER
9	2Q1-052-01	STAR DRAG SPRING
10	2E3-029-02	STAR DRAG NUT
11	2W1-020-01	081-130 WASHER
12	2L1-004-01	SPRING WASHER
13	2W1-035-05	080-105 WASHER
14	2Z1-024-05	812-2.5 BALL BEARING
15	2A4-022-01	ONE-WAY CLUTCH INNER TUBE
16	2E3-024-01	CAST CONTROL NUT
17	2W5-026-01	SPACER
18	2W5-029-01	CAST CONTROL SPACER
19	2E4-019-01	BEARING RETAINER
20	2C2-003-01	LINE ROLLER BUSH
21	2E9-005-01	O RING
22	2E0-011-01	RIGHT SIDE COVER SCREW
23	2W1-132-01	036-060 WASHER
24	2YF-140-21	LEFT SIDE COVER ASSEMBLY
25	2E5-006-01	E2.5 RETAINER
26	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING
27	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY
28	2W2-032-01	KEY WASHER
29	2W1-126-02	082-210 WASHER
30	2W3-017-01	EARED WASHER
31	2W1-111-02	100-230 WASHER
32	2W2-025-01	KEY WASHER
33	2G1-032-01	DRIVE GEAR
34	2Y6-023-01	OSCILLATING GEAR ASSEMBLY
35	2A3-027-01	RATCHET
36	2M3-048-02	DRIVE SHAFT
37	2Z1-018-05	510-3 BALL BEARING
38	2G2-046-01	PINION GEAR
39	2Q1-031-01	YOKE SPRING
40	2A2-050-01	PINION YOKE
41	2E2-047-01	A20M-065 SCREW
42	2F8-030-01	CLUTCH CAM RETAINER
43	2YA-031-01	CLUTCH CAM ASSEMBLY
44	2Z2-021-01	BUSHING


Key NO.	Parts No.	Parts name
45	2M2-019-01	CLUTCH PLATE
46	2G3-022-01	IDLE GEAR
47	2Q3-089-01	RETRACTOR SPRING
48	2F8-106-01	GEAR SETTING PLATE
49	2E2-031-01	A26M-075 SCREW
50	2W1-054-01	052-080 WASHER
51	2W1-070-01	052-080 WASHER
52	2E5-013-01	E3.0 RETAINER
53	2YS-061-03	SPOOL ASSEMBLY
54	2C2-057-01	BRAKE COLLAR
55	2Z1-023-01	814-4 BALL BEARING
56	2F3-037-01	CLICK GEAR
57	2YM-041-01	WORM SHAFT ASSEMBLY
58	2C1-059-01	SPACER
59	2C2-042-01	WORM SHAFT BUSH
60	2C4-015-01	LEVEL WIND GUARD
61	2YR-038-01	LINE GUIDE ASSEMBLY
62	2M5-005-01	LINE GUIDE PIN
63	2W1-100-01	020-068 WASHER
64	2E3-014-01	LINE GUIDE NUT
65	2E2-034-01	A20M-090 SCREW
66	2YB-215-10	BODY ASSEMBLY
67	2W1-046-01	051-068 WASHER
68	2F6-050-01	BEARING HOLDING PLATE
69	2E2-037-01	A26M-060 SCREW
70	2P4-006-02	LEVEL WIND GUIDE
71	2C4-014-02	CASTING BAR GUIDE B
72	2YS-085-03	CASTING BAR ASSEMBLY
73	2C4-013-02	CASTING BAR GUIDE A
74	2P2-021-01	CASTING BAR PIN
75	2E5-020-01	E1.5 RETAINER
76	2P4-008-02	CASTING BAR SUPPORT
77	2E2-003-01	B26M-036 SCREW
78	2E4-011-01	BEARING RETAINER
79	2W5-015-01	CAST CONTROL SPACER
80	2F6-113-01	CLICK PLATE
81	2E2-022-01	B20M-030 SCREW
82	2F2-020-01	CLICK SPRING
83	2F4-018-01	CLICK PAWL
84	2F5-362-10	RIGHT SIDE COVER
85	2F7-004-01	CLICK SWITCH
86	2YT-144-03	SPOOL TOTAL ASSEMBLY
87	2X3-004-01	WRENCH



BAIT CASTING REEL

Samira

Bitte, Best.-Nr. angeben (Nicht "key" "nr.")
 Veuillez indiquer le numero de la pièce (Non "key" "no.")

KL150LC-ft
KL150LC-M
**Key
NO.****Parts No.****Parts name**

1	2F5-097-02	HANDLE NUT CAP
2	2E3-016-01	NUT
3	2YH-084-02	HANDLE TOTAL ASSEMBLY
4	2E2-030-02	F20M-050 SCREW
5	2E4-018-01	RETAINER
6	2F8-050-01	CLICK LEAF SPRING HOLDER
7	2L3-029-01	CLICK LEAF SPRING
8	2D4-008-03	STAR DRAG LEVER
9	2Q1-052-01	STAR DRAG SPRING
10	2E3-029-01	STAR DRAG NUT
11	2L1-004-01	SPRING WASHER
12	2W1-035-05	080-105 WASHER
13	2Z1-024-06	812-2.5 BALL BEARING
14	2A4-022-01	ONE-WAY CLUTCH INNER TUBE
15	2E3-024-01	CAST CONTROL NUT
16	2W5-026-01	SPACER
17	2W5-029-01	CAST CONTROL SPACER
18	2E4-019-01	BEARING RETAINER
19	2C2-003-01	LINE ROLLER BUSH
20	2E9-005-01	O RING
21	2E0-067-01	LEFT SIDE COVER SCREW
22	2W1-132-01	036-060 WASHER
23	2YF-195-01	RIGHT SIDE COVER ASSEMBLY
24	2E5-006-01	E2.5 RETAINER
25	2E9-061-01	OIL RESISTANCE O RING
26	2I6-012-01	SOFT PLATE
27	2YF-085-04	COUNTER ASSEMBLY
28	2E2-095-01	B26M-050 SCREW
29	2E2-092-01	B20M-050 SCREW
30	2F5-543-01	DUST COVER
31	2E2-026-01	A20M-075 SCREW
32	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY
33	2E4-008-01	DRAG WASHER RETAINER
34	2W2-032-01	KEY WASHER
35	2W1-126-02	082-210 WASHER
36	2W3-017-01	EARED WASHER
37	2W2-025-01	KEY WASHER
38	2W1-111-02	100-230 WASHER
39	2G1-027-01	DRIVE GEAR
40	2YG-023-02	OSCILLATING GEAR ASSEMBLY
41	2A3-027-01	RATCHET
42	2M3-048-01	DRIVE SHAFT
43	2Z1-018-06	510-3 BALL BEARING
44	2G2-010-01	PINION GEAR
45	2Q1-031-01	YOKE SPRING
46	2A2-039-01	PINION YOKE
47	2E1-050-01	A20-060 SCREW
48	2F8-030-01	CLUTCH CAM RETAINER
49	2YA-042-01	CLUTCH CAM ASSEMBLY
50	2Z2-021-01	BUSHING

**Key
NO.****Parts No.****Parts name**

51	2M2-002-01	CLUTCH PLATE
52	2G3-109-01	COUNTER GEAR A
53	2Q3-086-01	RETRACTOR SPRING
54	2F8-153-01	GEAR SETTING PLATE
55	2E2-005-03	B26M-080 SCREW
56	2W1-054-01	052-080 WASHER
57	2W1-070-01	052-080 WASHER
58	2E5-013-01	E3.0 RETAINER
59	2YS-282-03	SPOOL ASSEMBLY
60	2C2-057-01	BRAKE COLLAR
61	2Z1-023-05	814-4 BALL BEARING
62	2W1-070-01	052-080 WASHER
63	2F3-041-01	CLICK GEAR
64	2G3-023-02	IDLE GEAR
65	2M4-043-01	WORM SHAFT
66	2C2-133-01	WORM SHAFT BUSHING
67	2C4-007-01	LEVEL WIND GUARD
68	2YR-038-01	LINE GUIDE ASSEMBLY
69	2M5-005-01	LINE GUIDE PIN
70	2W1-100-01	020-068 WASHER
71	2E3-014-01	LINE GUIDE NUT
72	2E1-066-01	A20-100 SCREW
73	2YB-089-61	BODY ASSEMBLY
74	2G3-088-01	IDLE GEAR
75	2W1-166-02	031-102 WASHER
76	2E2-007-01	B30M-100 SCREW
77	2G3-111-01	IDLE GEAR
78	2E2-003-01	B26M-036 SCREW
79	2C2-042-01	WORM SHAFT BUSH
80	2F6-050-01	BEARING HOLDING PLATE
81	2E2-037-01	A26M-060 SCREW
82	2C1-055-01	SPACER
83	2P4-006-01	LEVEL WIND GUIDE
84	2E5-020-01	E1.5 RETAINER
85	2P2-021-01	CASTING BAR PIN
86	2P4-008-01	CASTING BAR SUPPORT
87	2E2-003-01	B26M-036 SCREW
88	2C4-013-02	CASTING BAR GUIDE A
89	2YS-085-03	CASTING BAR ASSEMBLY
90	2C4-014-02	CASTING BAR GUIDE B
91	2E4-011-01	BEARING RETAINER
92	2W5-015-01	CAST CONTROL SPACER
93	2F4-018-01	CLICK PAWL
94	2E1-075-01	B22-045 SCREW
95	2F2-020-01	CLICK SPRING
96	2F6-032-01	CLICK PLATE
97	2F5-541-01	LEFT SIDE COVER
98	2F7-004-01	CLICK SWITCH
KL150LC-M SPECIAL PARTS		
26	2YF-085-05	COUNTER ASSEMBLY


<http://www.ticaglobal.com>

BAIT CASTING REEL


Samira K Series

KL150

Please order by parts number, not key number
 Bitte Best.-Nr. angeben (nicht "key" nr.)
 Veuillez indiquer le numero de la piece (non "key" no.)



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	2F5-097-02	HANDLE NUT CAP	44	2Z2-021-01	BUSHING
2	2E3-016-01	NUT	45	2M2-002-01	CLUTCH PLATE
3	2YH-084-02	HANDLE TOTAL ASSEMBLY	46	2G3-022-01	IDLE GEAR
4	2E2-030-02	F20M-050 SCREW	47	2Q3-086-01	RETRACTOR SPRING
5	2E4-018-01	RETAINER	48	2F8-032-01	GEAR SETTING PLATE
6	2F8-050-01	CLICK LEAF SPRING HOLDER	49	2E2-005-03	B26M-080 SCREW
7	2L3-029-01	CLICK LEAF SPRING	50	2W1-054-01	052-080 WASHER
8	2D4-008-03	STAR DRAG LEVER	51	2W1-070-01	052-080 WASHER
9	2Q1-052-01	STAR DRAG SPRING	52	2E5-013-01	E3.0 RETAINER
10	2E3-029-01	STAR DRAG NUT	53	2Y5-080-04	SPOOL ASSEMBLY
11	2W1-020-01	081-130 WASHER	54	2C2-057-01	BRAKE COLLAR
12	2L1-004-01	SPRING WASHER	55	2Z1-023-01	814-4 BALL BEARING
13	2W1-035-05	080-105 WASHER	56	2F3-037-01	CLICK GEAR
14	2Z1-024-05	812-2.5 BALL BEARING	57	2YM-032-01	WORM SHAFT ASSEMBLY
15	2A4-022-01	ONE-WAY CLUTCH INNER TUBE	58	2C1-059-01	SPACER
16	2E3-024-01	CAST CONTROL NUT	59	2C2-042-01	WORM SHAFT BUSH
17	2W5-026-01	SPACER	60	2C4-007-01	LEVEL WIND GUARD
18	2W5-029-01	CAST CONTROL SPACER	61	2YR-038-01	LINE GUIDE ASSEMBLY
19	2E4-019-01	BEARING RETAINER	62	2M5-005-01	LINE GUIDE PIN
20	2C2-003-01	LINE ROLLER BUSH	63	2W1-100-01	020-068 WASHER
21	2E9-005-01	O RING	64	2E3-014-01	LINE GUIDE NUT
22	2E0-011-01	RIGHT SIDE COVER SCREW	65	2E2-034-01	A20M-090 SCREW
23	2W1-132-01	036-060 WASHER	66	2YB-089-11	BODY ASSEMBLY
24	2YF-029-23	RIGHT SIDE COVER ASSEMBLY	67	2W1-046-01	051-068 WASHER
25	2E5-006-01	E2.5 RETAINER	68	2F6-050-01	BEARING HOLDING PLATE
26	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING	69	2E2-037-01	A26M-060 SCREW
27	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY	70	2P4-006-01	LEVEL WIND GUIDE
28	2W2-032-01	KEY WASHER	71	2C4-013-02	CASTING BAR GUIDE A
29	2W1-126-02	082-210 WASHER	72	2Y5-085-03	CASTING BAR ASSEMBLY
30	2W3-017-01	EARED WASHER	73	2C4-014-02	CASTING BAR GUIDE B
31	2W1-111-02	100-230 WASHER	74	2P2-021-01	CASTING BAR PIN
32	2W2-025-01	KEY WASHER	75	2P4-008-01	CASTING BAR SUPPORT
33	2G1-027-01	DRIVE GEAR	76	2E2-003-01	B26M-036 SCREW
34	2Y6-023-01	OSCILLATING GEAR ASSEMBLY	77	2E4-011-01	BEARING RETAINER
35	2A3-027-01	RATCHET	78	2W5-015-01	CAST CONTROL SPACER
36	2M3-048-01	DRIVE SHAFT	79	2F6-032-01	CLICK PLATE
37	2Z1-018-05	510-3 BALL BEARING	80	2E2-022-01	B20M-030 SCREW
38	2G2-010-01	PINION GEAR	81	2F2-020-01	CLICK SPRING
39	2Q1-031-01	YOKE SPRING	82	2F4-018-01	CLICK PAWL
40	2A2-039-01	PINION YOKE	83	2F5-089-11	LEFT SIDE COVER
41	2E2-047-01	A20M-065 SCREW	84	2F7-004-01	CLICK SWITCH
42	2F8-030-01	CLUTCH CAM RETAINER	85	2X3-004-01	WRENCH
43	2YA-017-01	CLUTCH CAM ASSEMBLY	86	2YT-139-04	SPOOL TOTAL ASSEMBLY



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2F5-097-02	HANDLE NUT CAP	50	2M2-020-01	CLUTCH PLATE
2	2E3-016-02	NUT	51	2Z2-021-01	BUSHING
3	2YH-084-02	HANDLE TOTAL ASSEMBLY	52	2G3-109-01	COUNTER GEAR A
4	2E2-030-02	F20M-050 SCREW	53	2Q3-089-01	RETRACTOR SPRING
5	2E4-018-01	RETAINER	54	2F8-154-01	GEAR SETTING PLATE
6	2F8-050-01	CLICK LEAF SPRING HOLDER	55	2E2-005-03	B26M-080 SCREW
7	2L3-029-01	CLICK LEAF SPRING	56	2W1-054-01	052-080 WASHER
8	2D4-008-03	STAR DRAG LEVER	57	2W1-070-01	052-080 WASHER
9	2Q1-052-01	STAR DRAG SPRING	58	2E5-013-01	E3.0 RETAINER
10	2E3-029-02	STAR DRAG NUT	59	2YS-282-03	SPOOL ASSEMBLY
11	2L1-004-01	SPRING WASHER	60	2C2-057-01	BRAKE COLLAR
12	2W1-035-05	080-105 WASHER	61	2Z1-023-05	814-4 BALL BEARING
13	2Z1-024-06	812-2.5 BALL BEARING	62	2W1-070-01	052-080 WASHER
14	2A4-022-01	ONE-WAY CLUTCH INNER TUBE	63	2F3-041-01	CLICK GEAR
15	2E3-024-01	CAST CONTROL NUT	64	2G3-023-02	IDLE GEAR
16	2W5-026-01	SPACER	65	2M4-043-01	WORM SHAFT
17	2W5-029-01	CAST CONTROL SPACER	66	2C2-133-01	WORM SHAFT BUSHING
18	2E4-019-01	BEARING RETAINER	67	2C4-007-01	LEVEL WIND GUARD
19	2C2-003-01	LINE ROLLER BUSH	68	2YR-038-01	LINE GUIDE ASSEMBLY
20	2E9-005-01	O RING	69	2M5-005-01	LINE GUIDE PIN
21	2E0-067-01	LEFT SIDE COVER SCREW	70	2W1-100-01	020-068 WASHER
22	2W1-132-01	036-060 WASHER	71	2E3-014-01	LINE GUIDE NUT
23	2YF-196-01	LEFT SIDE COVER ASSEMBLY	72	2E1-066-01	A20-100 SCREW
24	2E5-006-01	E2.5 RETAINER	73	2YB-218-61	BODY ASSEMBLY
25	2E9-061-01	OIL RESISTANCE O RING	74	2G3-088-01	IDLE GEAR
26	2I6-012-01	SOFT PLATE	75	2W1-166-02	031-102 WASHER
27	2YF-198-01	COUNTER ASSEMBLY	76	2E2-007-01	B30M-100 SCREW
28	2E2-095-01	B26M-050 SCREW	77	2C2-042-01	WORM SHAFT BUSH
29	2E2-092-01	B20M-050 SCREW	78	2F6-050-01	BEARING HOLDING PLATE
30	2F5-546-01	DUST COVER	79	2E2-037-01	A26M-060 SCREW
31	2E2-026-01	A20M-075 SCREW	80	2C1-055-01	SPACER
32	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY	81	2P4-006-01	LEVEL WIND GUIDE
33	2E4-008-01	DRAG WASHER RETAINER	82	2E5-020-01	E1.5 RETAINER
34	2W2-032-01	KEY WASHER	83	2P2-021-01	CASTING BAR PIN
35	2W1-126-02	082-210 WASHER	84	2P4-008-01	CASTING BAR SUPPORT
36	2W3-017-01	EARED WASHER	85	2E2-003-01	B26M-036 SCREW
37	2W2-025-01	KEY WASHER	86	2C4-014-02	CASTING BAR GUIDE B
38	2W1-111-02	100-230 WASHER	87	2YS-085-03	CASTING BAR ASSEMBLY
39	2G1-032-01	DRIVE GEAR	88	2C4-013-02	CASTING BAR GUIDE A
40	2YG-023-02	OSCILLATING GEAR ASSEMBLY	89	2E4-011-01	BEARING RETAINER
41	2A3-027-01	RATCHET	90	2W5-015-01	CAST CONTROL SPACER
42	2M3-048-02	DRIVE SHAFT	91	2F4-018-01	CLICK PAWL
43	2Z1-018-06	510-3 BALL BEARING	92	2F2-020-01	CLICK SPRING
44	2G2-046-01	PINION GEAR	93	2E1-075-01	B22-045 SCREW
45	2Q1-031-01	YOKE SPRING	94	2F6-032-01	CLICK PLATE
46	2A2-050-01	PINION YOKE	95	2F5-545-01	RIGHT SIDE COVER
47	2E1-050-01	A20-060 SCREW	96	2F7-004-01	CLICK SWITCH
48	2F8-030-01	CLUTCH CAM RETAINER			
49	2YA-043-01	CLUTCH CAM ASSEMBLY			
			KL151LC-M SPECIAL PARTS		
			26	2YF-198-02	COUNTER ASSEMBLY




BAIT CASTING REEL

Samira K Series

KL151

Please order by parts number, not key number
 Bitte Best. Nr. angeben (Nicht "key" - nr.)
 Veuillez indiquer le numero de la piece (Non "key" no.)



Key No.	Parts No.	Parts Name
1	2F5-097-02	HANDLE NUT CAP
2	2E3-016-02	NUT
3	2YH-084-02	HANDLE TOTAL ASSEMBLY
4	2E2-030-02	F20M-050 SCREW
5	2E4-018-01	RETAINER
6	2F8-050-01	CLICK LEAF SPRING HOLDER
7	2L3-029-01	CLICK LEAF SPRING
8	2D4-008-03	STAR DRAG LEVER
9	2Q1-052-01	STAR DRAG SPRING
10	2E3-029-02	STAR DRAG NUT
11	2W1-020-01	081-130 WASHER
12	2L1-004-01	SPRING WASHER
13	2W1-035-05	080-105 WASHER
14	2Z1-024-05	812-2.5 BALL BEARING
15	2A4-022-01	ONE-WAY CLUTCH INNER TUBE
16	2E3-024-01	CAST CONTROL NUT
17	2W5-026-01	SPACER
18	2W5-029-01	CAST CONTROL SPACER
19	2E4-019-01	BEARING RETAINER
20	2C2-003-01	LINE ROLLER BUSH
21	2E9-005-01	O RING
22	2E0-011-01	RIGHT SIDE COVER SCREW
23	2W1-132-01	036-060 WASHER
24	2YF-145-21	
25	2E5-006-01	E2.5 RETAINER
26	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING
27	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY
28	2W2-032-01	KEY WASHER
29	2W1-126-02	082-210 WASHER
30	2W3-017-01	EARED WASHER
31	2W1-111-02	100-230 WASHER
32	2W2-025-01	KEY WASHER
33	2G1-032-01	DRIVE GEAR
34	2YG-023-01	OSCILLATING GEAR ASSEMBLY
35	2A3-027-01	RATCHET
36	2M3-048-02	DRIVE SHAFT
37	2Z1-018-05	510-3 BALL BEARING
38	2G2-046-01	PINION GEAR
39	2Q1-031-01	YOKE SPRING
40	2A2-050-01	PINION YOKE
41	2E2-047-01	A20M-065 SCREW
42	2F8-030-01	CLUTCH CAM RETAINER
43	2YA-032-01	CLUTCH CAM ASSEMBLY
44	2Z2-021-01	BUSHING

Key No.	Parts No.	Parts Name
45	2M2-020-01	CLUTCH PLATE
46	2G3-022-01	IDLE GEAR
47	2Q3-089-01	RETRACTOR SPRING
48	2F8-107-01	GEAR SETTING PLATE
49	2E2-005-03	B26M-080 SCREW
50	2W1-054-01	052-080 WASHER
51	2W1-070-01	052-080 WASHER
52	2E5-013-01	E3.0 RETAINER
53	2Y5-080-04	SPOOL ASSEMBLY
54	2C2-057-01	BRAKE COLLAR
55	2Z1-023-01	814-4 BALL BEARING
56	2F3-037-01	CLICK GEAR
57	2YM-032-01	WORM SHAFT ASSEMBLY
58	2C1-059-01	SPACER
59	2C2-042-01	WORM SHAFT BUSH
60	2C4-007-01	LEVEL WIND GUARD
61	2YR-038-01	LINE GUIDE ASSEMBLY
62	2M5-005-01	LINE GUIDE PIN
63	2W1-100-01	020-068 WASHER
64	2E3-014-01	LINE GUIDE NUT
65	2E2-034-01	A20M-090 SCREW
66	2YB-218-10	BODY ASSEMBLY
67	2W1-046-01	051-068 WASHER
68	2F6-050-01	BEARING HOLDING PLATE
69	2E2-037-01	A26M-060 SCREW
70	2P4-006-01	LEVEL WIND GUIDE
71	2C4-014-02	CASTING BAR GUIDE B
72	2Y5-085-03	CASTING BAR ASSEMBLY
73	2C4-013-02	CASTING BAR GUIDE A
74	2P2-021-01	CASTING BAR PIN
75	2E5-020-01	E1.5 RETAINER
76	2P4-008-01	CASTING BAR SUPPORT
77	2E2-003-01	B26M-036 SCREW
78	2E4-011-01	BEARING RETAINER
79	2W5-015-01	CAST CONTROL SPACER
80	2F6-032-01	CLICK PLATE
81	2E2-022-01	B20M-030 SCREW
82	2F2-020-01	CLICK SPRING
83	2F4-018-01	CLICK PAWL
84	2F5-365-10	RIGHT SIDE COVER
85	2F7-004-01	CLICK SWITCH
86	2YT-139-04	SPOOL TOTAL ASSEMBLY
87	2X3-004-01	WRENCH




BAIT CASTING REEL

Samira K Series

KL200

Please order by parts number, not key number
 Bitte Best.-Nr. angeben! Nicht "key"-nr.
 Veuillez indiquer le numero de la piece (non "key" no.)




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	2F5-097-02	HANDLE NUT CAP	44	2Z2-021-01	BUSHING
2	2E3-016-01	NUT	45	2M2-003-01	CLUTCH PLATE
3	2YH-084-02	HANDLE TOTAL ASSEMBLY	46	2Q3-086-01	RETRACTOR SPRING
4	2E2-030-02	F20M-050 SCREW	47	2F8-039-01	GEAR SETTING PLATE
5	2E4-018-01	RETAINER	48	2E2-005-03	B26M-080 SCREW
6	2F8-050-01	CLICK LEAF SPRING HOLDER	49	2W1-054-01	052-080 WASHER
7	2L3-029-01	CLICK LEAF SPRING	50	2W1-070-01	052-080 WASHER
8	2D4-008-03	STAR DRAG LEVER	51	2E5-013-01	E3.0 RETAINER
9	2Q1-052-01	STAR DRAG SPRING	52	2YS-083-11	SPOOL ASSEMBLY
10	2E3-029-01	STAR DRAG NUT	53	2C2-057-01	BRAKE COLLAR
11	2W1-020-01	081-130 WASHER	54	2Z1-023-01	814-4 BALL BEARING
12	2L1-004-01	SPRING WASHER	55	2F3-041-01	CLICK GEAR
13	2W1-035-05	080-105 WASHER	56	2W1-046-01	051-068 WASHER
14	2Z1-024-05	812-2.5 BALL BEARING	57	2C2-042-01	WORM SHAFT BUSH
15	2A4-022-01	ONE-WAY CLUTCH INNER TUBE	58	2C4-010-01	LEVEL WIND GUARD
16	2E3-024-01	CAST CONTROL NUT	59	2YR-038-01	LINE GUIDE ASSEMBLY
17	2W5-026-01	SPACER	60	2M5-005-01	LINE GUIDE PIN
18	2W5-029-01	CAST CONTROL SPACER	61	2W1-100-01	020-068 WASHER
19	2E4-019-01	BEARING RETAINER	62	2E3-014-01	LINE GUIDE NUT
20	2C2-003-01	LINE ROLLER BUSH	63	2E2-034-01	A20M-090 SCREW
21	2E9-005-01	O RING	64	2YB-095-16	BODY ASSEMBLY
22	2E0-011-01	RIGHT SIDE COVER SCREW	65	2YM-042-01	WORM SHAFT ASSEMBLY
23	2W1-132-01	036-060 WASHER	66	2E2-003-01	B26M-036 SCREW
24	2YF-033-28	RIGHT SIDE COVER ASSEMBLY	67	2P4-006-03	LEVEL WIND GUIDE
25	2E5-006-01	E2.5 RETAINER	68	2G3-015-01	IDLE GEAR
26	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING	69	2W1-166-02	031-102 WASHER
27	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY	70	2E2-007-01	B30M-100 SCREW
28	2W2-032-01	KEY WASHER	71	2C4-013-02	CASTING BAR GUIDE A
29	2W1-126-02	082-210 WASHER	72	2YS-085-03	CASTING BAR ASSEMBLY
30	2W3-017-01	EARED WASHER	73	2C4-014-02	CASTING BAR GUIDE B
31	2W1-111-02	100-230 WASHER	74	2P2-021-01	CASTING BAR PIN
32	2W2-025-01	KEY WASHER	75	2P4-008-03	CASTING BAR SUPPORT
33	2G1-027-01	DRIVE GEAR	76	2E4-011-01	BEARING RETAINER
34	2Y6-023-01	OSCILLATING GEAR ASSEMBLY	77	2W5-015-01	CAST CONTROL SPACER
35	2A3-027-01	RATCHET	78	2F6-032-01	CLICK PLATE
36	2M3-053-01	DRIVE SHAFT	79	2F2-020-01	CLICK SPRING
37	2Z1-018-05	510-3 BALL BEARING	80	2E2-022-01	B20M-030 SCREW
38	2G2-010-01	PINION GEAR	81	2F4-018-01	CLICK PAWL
39	2Q1-031-01	YOKE SPRING	82	2F5-108-19	LEFT SIDE COVER
40	2A2-039-01	PINION YOKE	83	2F7-004-01	CLICK SWITCH
41	2E2-047-01	A20M-065 SCREW	84	2X3-004-01	WRENCH
42	2F8-030-01	CLUTCH CAM RETAINER	85	2YT-143-11	SPOOL TOTAL ASSEMBLY
43	2YA-035-01	CLUTCH CAM ASSEMBLY			

BAIT CASTING REEL

Samira K Series

KL201

Key
No.

Parts No.

Parts Name

1	2F5-097-02	HANDLE NUT CAP
2	2E3-016-02	NUT
3	2YH-084-02	HANDLE TOTAL ASSEMBLY
4	2E2-030-02	F20M-050 SCREW
5	2E4-018-01	RETAINER
6	2F8-050-01	CLICK LEAF SPRING HOLDER
7	2L3-029-01	CLICK LEAF SPRING
8	2D4-008-03	STAR DRAG LEVER
9	2Q1-052-01	STAR DRAG SPRING
10	2E3-029-02	STAR DRAG NUT
11	2W1-020-01	081-130 WASHER
12	2L1-004-01	SPRING WASHER
13	2W1-035-05	080-105 WASHER
14	2Z1-024-05	812-2.5 BALL BEARING
15	2A4-022-01	ONE-WAY CLUTCH INNER TUBE
16	2E3-024-01	CAST CONTROL NUT
17	2W5-026-01	SPACER
18	2W5-029-01	CAST CONTROL SPACER
19	2E4-019-01	BEARING RETAINER
20	2C2-003-01	LINE ROLLER BUSH
21	2E9-005-01	O RING
22	2E0-011-01	RIGHT SIDE COVER SCREW
23	2W1-132-01	036-060 WASHER
24	2YF-046-23	
25	2E5-006-01	F2.5 RETAINER
26	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING
27	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY
28	2W2-032-01	KEY WASHER
29	2W1-126-02	082-210 WASHER
30	2W3-017-01	EARED WASHER
31	2W1-111-02	100-230 WASHER
32	2W2-025-01	KEY WASHER
33	2G1-032-01	DRIVE GEAR
34	2Y6-023-01	OSCILLATING GEAR ASSEMBLY
35	2A3-027-01	RATCHET
36	2M3-053-02	DRIVE SHAFT
37	2Z1-018-05	510-3 BALL BEARING
38	2G2-046-01	PINION GEAR
39	2Q1-031-01	YOKE SPRING
40	2A2-050-01	PINION YOKE
41	2E2-047-01	A20M-065 SCREW
42	2F8-030-01	CLUTCH CAM RETAINER
43	2YA-019-01	CLUTCH CAM ASSEMBLY

Key
No.

Parts No.

Parts Name

44	2Z2-021-01	BUSHING
45	2M2-004-01	CLUTCH PLATE
46	2Q3-089-01	RETRACTOR SPRING
47	2F8-029-01	GEAR SETTING PLATE
48	2E2-005-03	B26M-080 SCREW
49	2W1-054-01	052-080 WASHER
50	2W1-070-01	052-080 WASHER
51	2E5-013-01	E3.0 RETAINER
52	2YS-083-11	SPOOL ASSEMBLY
53	2C2-057-01	BRAKE COLLAR
54	2Z1-023-01	814-4 BALL BEARING
55	2F3-041-01	CLICK GEAR
56	2W1-046-01	051-068 WASHER
57	2C2-042-01	WORM SHAFT BUSH
58	2C4-010-01	LEVEL WIND GUARD
59	2YR-038-01	LINE GUIDE ASSEMBLY
60	2M5-005-01	LINE GUIDE PIN
61	2W1-100-01	020-068 WASHER
62	2E3-014-01	LINE GUIDE NUT
63	2E2-034-01	A20M-090 SCREW
64	2YB-094-14	SPOOL ASSEMBLY
65	2YM-042-01	WORM ASSEMBLY
66	2E2-003-01	B26M-036 SCREW
67	2P4-006-03	LEVEL WIND GUIDE
68	2G3-015-01	IDLE GEAR
69	2W1-147-02	041-100 WASHER
70	2E0-035-01	IDLE GEAR
71	2C4-013-02	CASTING BAR GUIDE A
72	2YS-085-03	CASTING BAR ASSEMBLY
73	2C4-014-02	CASTING BAR GUIDE B
74	2P2-021-01	CASTING BAR PIN
75	2P4-008-03	CASTING BAR SUPPORT
76	2E4-011-01	BEARING RETAINER
77	2W5-015-01	CAST CONTROL SPACER
78	2F6-032-01	CLICK PLATE
79	2F2-020-01	CLICK SPRING
80	2E2-022-01	B20M-030 SCREW
81	2F4-018-01	CLICK PAWL
82	2F5-085-14	RIGHT SIDE COVER
83	2F7-004-01	CLICK SWITCH
84	2X3-004-01	WRENCH
85	2YT-143-11	SPOOL TOTAL ASSEMBLY