




Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-094-03	DRAG KNOB ASSEMBLY	29	2E1-050-01	A20-060 SCREW
2	2E4-034-01	DRAG WASHER RETAINER	30	2F5-403-01	ROLLER CLUTCH RETAINER
3	2W2-071-01	KEY WASHER	31	2Q2-021-01	SPRING
4	2W1-226-01	080-260 WASHER	32	2YZ-022-01	ONE-WAY CLUTCH BEARING
5	2YT-409-03	SPOOL TOTAL ASSEMBLY	33	2A4-072-01	ONE-WAY CLUTCH INNER TUBE
6	2W2-016-01	KEY WASHER	34	2Z1-003-07	714-5 BALL BEARING
7	2Z1-029-07	408-3 BALL BEARING	35	2G2-148-01	PINION GEAR
8	2W1-060-03	041-065 WASHER	36	2E1-037-01	B30-080 SCREW
9	2W1-236-01	055-188 WASHER	37	2B1-157-01	BODY
10	2L3-014-01	CLICK LEAF SPRING	38	2Z1-009-07	711-3 BALL BEARING
11	2M3-133-01	MAIN SHAFT	39	2G1-139-01	DRIVE GEAR
12	2F8-013-01	CLICK LEAF SPRING HOLDER	40	2W1-035-00	080-105 WASHER
13	2W2-015-01	KEY WASHER	41	2Z1-023-07	814-4 BALL BEARING
14	2E3-007-01	ROTOR NUT	42	2M2-018-01	OSCILLATING CAM
15	2E1-036-01	B26-040 SCREW	43	2G3-084-01	OSCILLATING GEAR
16	2R1-134-03	ROTOR	44	2M1-067-01	OSCILLATING SLIDER
17	2R4-178-02	BAIL TRIP COVER	45	2E2-030-02	F20M-050 SCREW
18	2E1-020-02	B22-055 SCREW	46	2B2-112-03	BODY COVER
19	2E2-094-01	B30M-090 SCREW	47	2E1-055-01	A26-100 SCREW
20	2R2-061-03	BAIL ARM	48	2YH-363-01	HANDLE TOTAL ASSEMBLY
21	2E1-025-01	b30-080 SCREW	49	2C3-042-01	HANDLE SCREW SLEEVE
22	2C1-034-01	LINE ROLLER COLLAR	50	2H6-001-13	HANDLE SCREW CAP
23	2Z1-012-07	407-2.5 BALL BEARING	51	2A2-094-03	ANTI-REVERSE CAM
24	2R6-020-02	LINE ROLLER	52	2L5-010-01	ANTI-REVERSE CAM SPRING
25	2YL-144-03	BAIL ASSMBLY	53	2F5-402-02	REAR COVER
26	2Q1-051-02	BAIL SPRING	54	2E1-020-02	B22-055 SCREW
27	2R5-161-01	BAIL TRIP LEVER	LD2500	SPECIAL PARTS	
28	2R4-179-02	BAIL SPRING COVER	5	2YT-442-03	SPOOL TOTAL ASSEMBLY