www.reelschematic.com

2X526101E


Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SPINNING REEL

TL2000R / TL3000R / TL4000R / TL5000R
TL6000R / TL8000R / TL9000R / TL10000R

GEAR RATIO(5.2/4.1/3.3)



Key NO.	Parts No.	Parts name
1	2YD-069-01	DRAG KNOB ASSEMBLY
2	2E9-015-01	PROOF WATER RING
3	2E4-003-01	DRAG WASHER RETAINER
4	2W2-048-02	KEY WASHER
5	2W1-175-01	100-300 WASHER
6	2W3-027-01	EARED WASHER
7	2YT-284-04	SPOOL TOTAL ASSEMBLY
8	2W2-050-01	KEY WASHER
9	2L3-018-01	CLICK LEAF SPRING
10	2F8-027-02	CLICK LEAF SPRING HOLDER
11	2W2-034-01	KEY WASHER
12	2E1-060-01	A26-060 SCREW
13	2F6-028-01	ROTOR NUT HOLDING PLATE
14	2E3-026-01	ROTOR NUT
15	2R1-112-01	ROTOR
16	2E2-007-01	B30M-100 SCREW
17	2E3-055-01	SHAFT NUT(A)
18	2R2-046-01	BAIL ARM
19	2C1-049-01	LINE ROLLER COLLAR
20	2Z1-001-05	508-2.5 BALL BEARING
21	2R6-018-01	LINE ROLLER
22	2C1-068-01	COLLAR
23	2YL-122-01	BAIL ASSEMBLY
24	2R5-127-01	BAIL PAWL
25	2P1-055-01	BAIL TRIP PIN
26	2E3-056-01	SHAFT NUT(B)
27	2E2-005-03	B26M-080 SCREW
28	2R5-126-01	BAIL TRIP SHAFT
29	2Q1-077-01	BAIL SPRING
30	2C2-102-01	BAIL SPRING GUIDE
31	2R5-128-01	BAIL TRIP LEVER A
32	2R4-132-01	BAIL TRIP COVER
33	2R4-131-01	BAIL SPRING COVER
34	2E1-037-01	B30-080 SCREW
35	2Q3-104-01	BAIL TRIP LEVER SPRING
36	2R5-129-01	BAIL TRIP LEVER B
37	2F5-270-01	ROTOR COVER
38	2E1-016-02	B26-080 SCREW
39	2E2-037-01	A26M-060 SCREW
40	2F8-094-01	BEARING HOLDER
41	2M3-101-01	MAIN SHAFT
42	2Z1-008-05	1020-5 BALL BEARING
43	2C1-096-01	COLLAR
44	2A4-034-01	ONE-WAY CLUTCH INNER TUBE
45	2Q1-071-01	CAGE SPRING
46	2F8-084-01	CAGE
47	2Z3-003-01	ROLLER
48	2A3-009-01	ANTI-REVERSE RATCHET
49	2F2-033-01	ANTI-REVERSE PAWL
50	2YZ-020-01	ONE-WAY CLUTCH BEARING ASSEMBLY
51	2E2-052-02	F26M-080 SCREW
52	2F5-259-01	BEARING RETAINER
53	2G2-099-01	PINION GEAR
54	2YB-176-01	BODY ASSEMBLY
55	2A2-075-01	ANTI-REVERSE CAM
56	2Q3-009-01	ANTI-REVERSE SPRING
57	2A1-026-01	ANTI-REVERSE LEVER
58	2E2-013-02	B20M-060 SCREW
59	2C2-101-01	WORM SHAFT BUSH
60	2Z1-014-05	306-2.5 BALL BEARING
61	2C1-046-01	COLLAR
62	2G3-035-01	OSCILLATING GEAR
63	2M1-051-01	OSCILLATING SILDER
64	2E5-045-01	OSCILLATING SLIDER RETAINER
65	2M4-032-01	WORM SHAFT
66	2W1-058-02	030-050 WASHER
67	2E2-014-02	F26M-060 SCREW
68	2M5-004-01	LINE GUIDE PIN
69	2C2-034-01	LINE GUIDE PIN BUSH
70	2W1-107-02	030-050 WASHER
71	2W1-059-01	020-049 WASHER
72	2F5-296-01	OSCILLATING SILDER COVER
73	2E2-014-02	F26M-060 SCREW
74	2W5-031-01	WORM SHAFT COVER GASKET
75	2F5-161-01	WORM SHAFT COVER
76	2E2-003-01	B26M-036 SCREW
77	2E2-050-01	A20M-035 SCREW
78	2Z1-035-05	917-5 BALL BEARING
79	2B2-073-01	BODY COVER(R)
80	2E1-016-02	B26-080 SCREW
81	2G1-081-02	DRIVE GEAR
82	2W1-014-00	091-130 WASHER
83	2B2-074-01	BODY COVER(L)
84	2E1-006-02	A30-130 SCREW
85	2YH-199-01	HANDLE ASSEMBLY
86	2C3-047-01	HANDLE SCREW SLEEVE
87	2H6-002-10	HANDLE SCREW CAP
88	2E9-031-01	REAR COVER PROOF WATER RING
89	2F5-291-01	REAR COVER A
90	2F5-292-01	REAR COVER B
91	2E2-029-03	B26M-060 SCREW
TL2000R	SPECIAL PARTS	
7	2YT-281-04	SPOOL TOTAL ASSEMBLY
TL3000R	SPECIAL PARTS	
7	2YT-282-04	SPOOL TOTAL ASSEMBLY
TL4000R	SPECIAL PARTS	
7	2YT-283-04	SPOOL TOTAL ASSEMBLY
TL6000R	SPECIAL PARTS	
7	2YT-285-04	SPOOL TOTAL ASSEMBLY
TL8000R	SPECIAL PARTS	
7	2YT-286-04	SPOOL TOTAL ASSEMBLY
TL9000R	SPECIAL PARTS	
7	2YT-287-04	SPOOL TOTAL ASSEMBLY
TL10000R	SPECIAL PARTS	
7	2YT-288-04	SPOOL TOTAL ASSEMBLY
GEAR RATIO 5.2	SPECIAL PARTS	
32	2R4-132-02	BAIL TRIP COVER
53	2G2-098-01	PINION GEAR
62	2G3-025-01	OSCILLATING GEAR
81	2G1-080-02	DRIVE GEAR
GEAR RATIO 3.3	SPECIAL PARTS	
32	2R4-132-03	BAIL TRIP COVER
53	2G2-100-01	PINION GEAR
62	2G3-048-01	OSCILLATING GEAR
81	2G1-082-02	DRIVE GEAR

http：//www.ticaglobal.com