www.reelschematic.com


2X516002

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SPINNING REEL

SA3500 / SA3500BH / SA3500H / SA3500HBH
SA4000 / SA4000BH / SA4000H / SA4000HBH



Key NO.	Parts No.	Parts name
2-7	2YT-151-01	SPOOL TOTAL ASSEMBLY
1	2YD-030-03	DRAG KNOB ASSEMBLY
2	2E2-005-03	B26M-080 SCREW
3	2S5-029-01	LIP COVER
4	2W2-005-01	KEY WASHER
5	2W3-003-01	EARED WASHER
6	2W1-052-02	050-187 WASHER
7	2YS-072-01	SPOOL ASSEMBLY
8	2W2-014-01	KEY WASHER
9	2Z1-009-01	711-3 BALL BEARING
10	2C1-057-01	INSERT METAL
11	2L3-014-01	CLICK LEAF SPRING
12	2W1-053-02	080-185 WASHER
13	2F8-013-02	CLICK LEAF SPRING HOLDER
14	2W2-024-01	KEY WASHER
15	2E1-036-01	B26-040 SCREW
16	2E3-002-01	ROTOR NUT
17	2YR-059-01	ROTOR ASSEMBLY
18	2E2-018-01	B30M-080 SCREW
19	2R5-106-01	BAIL TRIP PLATE
20	2R5-104-01	BAIL TRIP LEVER A
21	2R4-109-01	BAIL TRIP COVER SPACER
22	2F5-207-01	BAIL TRIP COVER
23	2E1-016-03	B26-080 SCREW
24	2Q3-056-01	BAIL TRIP LEVER SPRING
25	2R5-107-01	BAIL TRIP LEVER
26	2W5-037-01	SPACER
27	2E1-048-02	B22-080 SCREW
28	2E3-040-02	SHAFT NUT
29	2E2-018-02	B30M-080 SCREW
30	2R2-036-01	BAIL ARM
31	2C2-082-01	BAIL ARM BUSH
32	2C1-034-01	LINE ROLLER COLLAR
33	2Z1-012-02	407-2.5 BALL BEARING
34	2R6-020-01	LINE ROLLER
35	2C2-032-01	LINE ROLLER BUSH
36	2YL-095-01	BAIL ASSEMBLY
37	2F6-033-01	HOLDING PLATE
38	2R5-101-01	BAIL TRIP SHAFT
39	2Q1-075-01	BAIL SPRING
40	2C2-081-01	BAIL SPRING GUIDE
41	2R4-106-01	BAIL SPRING COVER SPACER
42	2F5-206-01	BAIL SPRING COVER
43	2M3-058-01	MAIN SHAFT
44	2E1-029-01	B22-090 SCREW
45	2F8-079-01	ANTI-REVERSE SPRING ANCHOR
46	2F5-189-01	ROLLER CLUTCH RETAINER
47	2Q2-016-01	SPRING
48	2F2-027-01	ANTI-REVERSE PAWL
49	2W5-036-01	WASHER

Key NO.	Parts No.	Parts name
50	2Z3-003-01	ROLLER
51	2A3-025-01	ANTI-REVERSE RATCHET
52	2F8-082-01	CAGE
53	2YZ-017-01	ONE-WAY CLUTCH BEARING ASSEMBLY
54	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
55	2E1-068-01	F30-100 SCREW
56	2F5-203-01	BEARING RETAINER
57	2Z1-005-02	816-5 BALL BEARING
58	2G2-005-01	PINION GEAR
59	2C2-070-01	PINION GEAR BUSH
60	2A2-028-01	ANTI-REVERSE CAM
61	2Q3-009-01	ANTI-REVERSE SPRING
62	2YB-132-01	BODY ASSEMBLY
63	2C2-049-01	WORM SHAFT BUSH C
64	2C1-048-02	WORM SHAFT COLLAR
65	2G3-018-01	OSCILLATING GEAR
66	2M4-018-01	WORM SHAFT
67	2W1-058-02	030-050 WASHER
68	2W1-058-03	030-050 WASHER
69	2Z1-014-01	306-2.5 BALL BEARING
70	2E2-009-01	F23M-060 SCREW
71	2M1-032-01	OSCILLATING SLIDER
72	2W1-058-04	030-050 WASHER
73	2M5-007-01	LINE GUIDE PIN
74	2C2-034-01	LINE GUIDE PIN BUSH
75	2W1-059-01	020-049 WASHER
76	2F5-181-01	OSCILLATING SLIDER COVER
77	2Z1-010-02	812-3.5 BALL BEARING
78	2G1-010-01	DRIVE GEAR
79	2W1-035-00	080-105 WASHER
80	2Z1-004-01	814-3.5 BALL BEARING
81	2B2-035-01	BODY COVER
82	2E1-006-03	A30-130 SCREW
83	2YH-090-01	HANDLE TOTAL ASSEMBLY
84	2C3-023-01	HANDLE SCREW SLEEVE
85	2E2-023-01	a30M-120 SCREW
86	2H6-010-01	HANDLE SCREW CAP
87	2A1-022-01	ANTI-REVERSE LEVER
88	2E2-013-03	B20M-060 SCREW
89	2P1-025-01	OSCILLATING SLIDER PIN
90	2F5-182-01	WORM SHAFT COVER
91	2YN-004-01	NAMEPLATE ASSEMBLY
92	2E1-020-01	B22-055 SCREW
SA3500BH	SPECIAL PARTS	SA3500BH SPECIAL PARTS
83	2YH-092-01	HANDLE TOTAL ASSEMBLY
SA3500H	SPECIAL PARTS	SA3500H SPECIAL PARTS
2-7	2YT-151-03	SPOOL TOTAL ASSEMBLY
7	2YS-072-03	SPOOL ASSEMBLY
58	2G2-074-01	PINION GEAR
65	2G3-031-01	OSCILLATING GEAR

Key NO.	Parts No.	Parts name
78	2G1-057-01	DRIVE GEAR
SA3500HBH	SPECIAL PARTS	SA3500HBH SPECIAL PARTS
2-7	2YT-151-03	SPOOL TOTAL ASSEMBLY
7	2YS-072-03	SPOOL ASSEMBLY
58	2G2-074-01	PINION GEAR
65	2G3-031-01	OSCILLATING GEAR
78	2G1-057-01	DRIVE GEAR
83	2YH-092-01	HANDLE TOTAL ASSEMBLY
SA4000	SPECIAL PARTS	SA4000 SPECIAL PARTS
2-7	2YT-153-01	SPOOL TOTAL ASSEMBLY
7	2YS-074-01	SPOOL ASSEMBLY
17	2YR-060-01	ROTOR ASSEMBLY
21	2R4-110-01	BAIL TRIP COVER SPACER
25	2R5-108-01	BAIL TRIP LEVER
36	2YL-096-01	BAIL ASSEMBLY
62	2YB-132-02	BODY ASSEMBLY
SA4000BH	SPECIAL PARTS	SA4000BH SPECIAL PARTS
2-7	2YT-153-01	SPOOL TOTAL ASSEMBLY
7	2YS-074-01	SPOOL ASSEMBLY
17	2YR-060-01	ROTOR ASSEMBLY
21	2R4-110-01	BAIL TRIP COVER SPACER
25	2R5-108-01	BAIL TRIP LEVER
36	2YL-096-01	BAIL ASSEMBLY
62	2YB-132-02	BODY ASSEMBLY
83	2YH-092-01	HANDLE TOTAL ASSEMBLY
SA4000H	SPECIAL PARTS	SA4000H SPECIAL PARTS
2-7	2YT-153-03	SPOOL TOTAL ASSEMBLY
7	2YS-074-03	SPOOL ASSEMBLY
17	2YR-060-01	ROTOR ASSEMBLY
21	2R4-110-01	BAIL TRIP COVER SPACER
25	2R5-108-01	BAIL TRIP LEVER
36	2YL-096-01	BAIL ASSEMBLY
58	2G2-074-01	PINION GEAR
62	2YB-132-02	BODY ASSEMBLY
65	2G3-031-01	OSCILLATING GEAR
78	2G1-057-01	DRIVE GEAR
SA4000HBH	SPECIAL PARTS	SA4000HBH SPECIAL PARTS
2-7	2YT-153-03	SPOOL TOTAL ASSEMBLY
7	2YS-074-03	SPOOL ASSEMBLY
17	2YR-060-01	ROTOR ASSEMBLY
21	2R4-110-01	BAIL TRIP COVER SPACER
25	2R5-108-01	BAIL TRIP LEVER
36	2YL-096-01	BAIL ASSEMBLY
58	2G2-074-01	PINION GEAR
62	2YB-132-02	BODY ASSEMBLY
65	2G3-031-01	OSCILLATING GEAR
78	2G1-057-01	DRIVE GEAR
83	2YH-092-01	HANDLE TOTAL ASSEMBLY