
Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

TICA WARRANTY QUALITY

SPINNING REEL *DYNASPIN* SH1000 / SH1500




Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-096-05	DRAG KNOB ASSEBLY	34	2F5-398-01	ROLLER CLUTCH RETAINER
2	2E4-034-01	DRAG WASHER RETAINER	35	2Q2-016-01	SPRING
3	2W2-078-01	KEY WASHER	36	2YZ-023-01	ONE-WAY CLUTCH BEARING ASSEMBLY
4	2W1-226-01	080-260 WASHER	37	2E2-052-02	F26M-080 SCREW
5	2YT-444-05	SPOOL TOTAL ASSEMBLY	38	2F5-212-01	BEARING RETAINER
6	2W2-079-01	KEY WASHER	39	2C1-090-01	COLLAR
7	2Z1-001-05	508-2.5 BALL BEARING	40	2Z1-019-05	612-4 BALL BEARING
8	2C1-118-01	SPACER	41	2G2-156-01	PINION GESR
9	2W1-250-01	081-145 WASHER	42	2A2-097-01	ANTI-REVERSE CAM
10	2L3-025-01	CLICK LEAF SPRING	43	2Q3-102-01	ANTI-REVERSE SPRING
11	2F8-063-02	CLICK LEAF SPRING HOLDER	44	2YB-234-04	BODY ASSEMBLY
12	2M3-142-01	MAIN SHAFT	45	2B2-113-04	BODY COVER (R)
13	2W2-056-01	KEY WASHER	46	2Z1-009-05	711-3 BALL BEARING
14	2E3-062-01	ROTOR NUT	47	2M2-023-01	OSCILLATING CAM
15	2R1-138-04	ROTOR	48	2G3-091-01	OSCILLATING GEAR
16	2R5-166-01	BAIL PAWL	49	2M1-068-01	OSCILLATING SILDER
17	2R4-187-01	BAIL TRIP COVER	50	2E5-060-01	OSCILLATING SLIDER RETAINER
18	2E1-020-02	B22-055 SCREW	51	2E2-030-02	F20M-050 SCREW
19	2E2-018-03	B30M-080 SCREW	52	2E1-060-01	A26-060 SCREW
20	2E1-025-01	b30-080 SCREW	53	2G1-142-01	DRIVE GEAR
21	2R2-069-04	BAIL ARM	54	2W1-019-00	071-103 WASHER
22	2C1-056-01	LINE ROLLER COLLAR	55	2B2-114-04	BODY COVER (L)
23	2Z1-012-05	407-2.5 BALL BEARING	56	2E1-055-01	A26-100 SCREW
24	2R6-012-02	LINE ROLLER	57	2YH-364-01	HANDLE TOTAL ASSEMBLY
25	2C2-032-01	LINE ROLLER BUSH	58	2C3-042-01	HANDLE SCREW SLEEVE
26	2YL-157-05	BAIL ASSEMBLY	59	2H6-017-02	HANDLE SCREW CAP
27	2R5-165-01	BAIL TRIP SHAFT	60	2E2-013-02	B20M-060 SCREW
28	2W1-199-01	015-027 WASHER	61	2A1-034-05	ANTI-REVERSE LEVER
29	2Q1-117-01	BAIL SPRING	62	2F5-412-04	REAR COVER
30	2C2-121-01	BAIL SPRING GUIDE	63	2E2-092-01	B20M-050 SCREW
31	2R4-186-01	BAIL SPRING COVER	SH1500	SPECIAL PARTS	
32	2A4-054-01	ONE-WAY CLUTCH INNER TUBE	5	2YT-412-05	SPOOL TOTAL ASSEMBLY
33	2E2-044-01	A20M-050 SCREW			

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SPINNING REEL *DYNASPIN* SH2000 / SH2500




Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-089-05	DRAG KNOB ASSEBLY	34	2E2-044-01	A20M-050 SCREW
2	2E4-034-01	DRAG WASHER RETAINER	35	2F5-398-01	ROLLER CLUTCH RETAINER
3	2W2-071-01	KEY WASHER	36	2YZ-023-01	ONE-WAY CLUTCH BEARING ASSEMBLY
4	2W1-226-01	080-260 WASHER	37	2Q2-016-01	SPRING
5	2YT-413-05	SPOOL TOTAL ASSEMBLY-	38	2E2-052-02	F26M-080 SCREW
6	2W2-016-01	KEY WASHER	39	2F5-212-01	BEARING RETAINER
7	2Z1-029-05	408-3 BALL BEARING	40	2Z1-003-05	714-5 BALL BEARING
8	2C1-119-01	SPACER	41	2G2-158-01	PINION GESR
9	2W1-053-01	080-185 WASHER	42	2A2-088-01	ANTI-REVERSE CAM
10	2L3-014-01	CLICK LEAF SPRING	43	2Q3-102-01	ANTI-REVERSE SPRING
11	2F8-013-01	CLICK LEAF SPRING HOLDER	44	2YB-211-06	BODY ASSEMBLY
12	2M3-123-01	MAIN SHAFT	45	2B2-097-07	BODY COVER (R)
13	2W2-015-01	KEY WASHER	46	2Z1-009-05	711-3 BALL BEARING
14	2E3-007-01	ROTOR NUT	47	2M2-018-01	OSCILLATING CAM
15	2E1-036-01	B26-040 SCREW	48	2G3-084-01	OSCILLATING GEAR
16	2R1-136-04	KEY WASHER	49	2M1-061-01	OSCILLATING SILDER
17	2R5-163-01	BAIL PAWL	50	2E5-054-01	OSCILLATING SLIDER RETAINER
18	2R4-182-01	BAIL TRIP COVER	51	2E2-009-02	F23M-060 SCREW
19	2E1-015-02	B26-060 SCREW	52	2E1-045-01	A26-080 SCREW
20	2E2-018-03	B30M-080 SCREW	53	2G1-144-01	DRIVE GEAR
21	2E1-010-01	b30-100 SCREW	54	2W1-019-00	071-103 WASHER
22	2R2-063-04	BAIL ARM	55	2Z1-010-05	812-3.5 BALL BEARING
23	2C1-034-01	LINE ROLLER COLLAR	56	2B2-096-07	BODY COVER (L)
24	2Z1-012-05	407-2.5 BALL BEARING	57	2E1-005-02	A26-120 SCREW
25	2R6-020-02	LINE ROLLER	58	2YH-358-01	HANDLE TOTAL ASSEMBLY
26	2C2-032-01	LINE ROLLER BUSH	59	2C3-042-01	HANDLE SCREW SLEEVE
27	2YL-155-05	BAIL ASSEMBLY	60	2H6-017-02	HANDLE SCREW CAP
28	2R5-135-01	BAIL TRIP SHAFT	61	2A1-034-05	ANTI-REVERSE LEVER
29	2W1-199-01	015-027 WASHER	62	2E2-013-02	B20M-060 SCREW
30	2Q1-096-01	BAIL SPRING	63	2F5-355-04	REAR COVER
31	2C2-119-01	BAIL SPRING GUIDE	64	2E2-055-01	B23M-050 SCREW
32	2R4-183-01	BAIL SPRING COVER	SH2500	SPECIAL PARTS	
33	2A4-021-01	ONE-WAY CLUTCH INNER TUBE	5	2YT-414-05	SPOOL TOTAL ASSEMBLY

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

TICA WARRANTY QUALITY

SPINNING REEL *DYNASPIN* SH3000 / SH3500




Key NO.	Parts No.	Parts name
1	2YD-089-05	DRAG KNOB ASSEBLY
2	2E4-034-01	DRAG WASHER RETAINER
3	2W2-071-01	KEY WASHER
4	2W1-226-01	080-260 WASHER
5	2W3-035-01	EARED WASHER
6	2YT-415-05	SPOOL TOTAL ASSEMBLY
7	2W2-016-01	KEY WASHER
8	2Z1-029-05	408-3 BALL BEARING
9	2C1-119-01	SPACER
10	2W1-053-01	080-185 WASHER
11	2L3-015-01	CLICK LEAF SPRING
12	2M3-120-01	MAIN SHAFT
13	2F8-019-02	CLICK LEAF SPRING HOLDER
14	2W2-015-01	KEY WASHER
15	2E3-007-01	ROTOR NUT
16	2E1-036-01	B26-040 SCREW
17	2R1-137-04	ROTOR
18	2R5-164-01	BAIL PAWL
19	2R4-185-01	BAIL TRIP COVER
20	2E1-015-02	B26-060 SCREW
21	2E2-007-01	B30M-100 SCREW
22	2E1-010-01	b30-100 SCREW
23	2R2-062-04	BAIL ARM
24	2C1-034-01	LINE ROLLER COLLAR
25	2Z1-012-05	407-2.5 BALL BEARING
26	2R6-020-02	LINE ROLLER
27	2C2-032-01	LINE ROLLER BUSH
28	2YL-146-05	BAIL ASSEMBLY
29	2R5-135-01	BAIL TRIP SHAFT
30	2W1-199-01	015-027 WASHER
31	2Q1-096-01	BAIL SPRING
32	2C2-119-01	BAIL SPRING GUIDE
33	2R4-184-01	BAIL SPRING COVER
34	2A4-021-01	ONE-WAY CLUTCH INNER TUBE
35	2E2-047-02	A20M-065 SCREW
36	2F8-079-01	ANTI-REVERSE SPRING ANCHOR
37	2F5-192-01	ROLLER CLUTCH RETAINER
38	2Q2-016-01	SPRING
39	2YZ-014-01	ONE-WAY CLUTCH BEARING ASSEMBLY
40	2E2-052-01	F26M-080 SCREW
41	2F5-193-01	BEARING RETAINER
42	2Z1-003-05	714-5 BALL BEARING
43	2G2-155-01	PINION GEAR
44	2A2-031-01	ANTI-REVERSE CAM
45	2Q3-009-01	ANTI-REVERSE SPRING
46	2YB-206-06	BODY ASSEMBLY
47	2B2-110-07	BODY CAVER(R)
48	2Z1-010-05	812-3.5 BALL BEARING
49	2M2-016-01	OSCILLATING CAM
50	2G3-081-01	OSCILLATING GEAR
51	2M1-057-01	OSCILLATING SILDER
52	2E5-051-01	OSCILLATING SILDER RETAINER
53	2E2-009-02	F23M-060 SCREW
54	2E1-020-02	B22-055 SCREW
55	2G3-068-01	DRIVE PINION
56	2G1-141-01	DRIVE GEAR
57	2W1-019-00	071-103 WASHER
58	2Z1-039-05	713-4 BALL BEARING
59	2B2-111-07	BODY CAVER(L)
60	2E1-005-02	A26-120 SCREW
61	2YH-359-01	HANDLE TOTAL ASSEMBLY
62	2C3-042-01	HANDLE SCREW SLEEVE
63	2W1-004-01	029-080 WASHER
64	2H6-017-02	HANDLE SCREW CAP
65	2E2-013-02	B20M-060 SCREW
66	2A1-033-05	ANTI-REVERSE LEVER
67	2F5-389-04	REAR COVER
68	2E2-051-01	B23M-060 SCREW
SH3500	SPECIAL PARTS	
6	2YT-437-05	SPOOL TOTAL ASSEMBLY

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

TCA WARRANTY QUALITY

SPINNING REEL *DYNASPIN* SH5000 / SH6000

GEAR RATIO (4.4/3.3)



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-097-05	DRAG KNOB ASSEMBLY	37	2F8-124-01	BEARING HOLDER
2	2E4-034-01	DRAG WASHER RETAINER	38	2Z1-035-05	917-5 BALL BEARING
3	2W1-090-02	082-260 WASHER	39	2C1-126-01	COLLAR
4	2W2-061-01	KEY WASHER	40	2A4-019-05	ONE-WAY CLUTCH INNER TUBE
5	2W3-031-01	EARED WASHER	41	2Q1-071-01	CAGE SPRING
6	2YT-417-05	SPOOL TOTAL ASSEMBLY	42	2YZ-020-01	ONE-WAY CLUTCH BEARING ASSEMBLY
7	2W2-081-01	KEY WASHER	43	2E2-052-02	F26M-080 SCREW
8	2Z1-009-05	711-3 BALL BEARING	44	2F5-259-01	BEARING RETAINER
9	2C1-121-01	SPACER	45	2G2-162-01	PINION GEAR
10	2W1-237-01	070-225 WASHER	46	2Q3-009-01	ANTI-REVERSE SPRING
11	2L3-015-01	CLICK LEAF SPRING	47	2A2-075-01	ANTI-REVERSE CAM
12	2F8-019-01	CLICK LEAF SPRING HOLDER	48	2A1-034-05	ANTI-REVERSE LEVER
13	2W2-019-01	KEY WASHER	49	2E2-013-02	B20M-060 SCREW
14	2E3-003-01	ROTOR NUT	50	2YB-244-04	BODY ASSEMBLY
15	2E1-036-01	B26-040 SCREW	51	2B2-123-04	BODY COVER (R)
16	2M3-149-01	MAIN SHAFT	52	2E2-014-01	F26M-060 SCREW
17	2R1-143-04	ROTOR	53	2E5-062-01	OSCILLATING SILDER RETAINER
18	2Q3-108-01	BAIL SPRING	54	2M1-073-01	OSCILLATING SILDER
19	2R5-178-01	BAIL PAWL	55	2M2-015-01	OSCILLATING CAM
20	2R5-172-01	BAIL TRIP LEVER	56	2G3-093-01	OSCILLATING GEAR
21	2R4-197-01	BAIL TRIP COVER	57	2E1-045-01	A26-080 SCREW
22	2E1-016-02	B26-080 SCREW	58	2G1-152-01	DRIVE GEAR
23	2E2-007-01	B30M-100 SCREW	59	2W1-014-01	091-130 WASHER
24	2E1-072-01	B40-120 SCREW	60	2B2-122-04	BODY COVER (L)
25	2R2-067-04	BAIL ARM	61	2E1-005-02	A26-120 SCREW
26	2C1-049-01	LINE ROLLER COLLAR	62	2E1-006-02	A30-130 SCREW
27	2Z1-001-05	508-2.5 BALL BEARING	63	2YH-388-01	HANDLE TOTAL ASSEMBLY
28	2R6-018-02	LINE ROLLER	64	2C3-047-01	HANDLE SCREW SLEEVE
29	2C1-068-01	COLLAR	65	2H6-021-01	HANDLE SCREW CAP
30	2YL-154-05	BAIL ASSEMBLY	66	2F5-430-04	REAR COVER
31	2R5-186-01	BAIL TRIP SHAFT	67	2E2-055-01	B23M-050 SCREW
32	2W1-199-01	015-027 WASHER	SH6000	SPECIAL PARTS	
33	2C2-127-01	BAIL SPRING GUIDE	6	2YT-418-05	SPOOL TOTAL ASSEMBLY
34	2Q1-127-01	BAIL SPRING	GEAR RATIO 3.3	SPECIAL PARTS	
35	2R4-196-01	BAIL SPRING COVER	45	2G2-171-01	PINION GEAR
36	2E2-037-01	A26M-060 SCREW	58	2G1-154-01	DRIVE GEAR