
TG3000

GEAR RATIO〈6.3/5.2〉




Key NO.	Parts No.	Parts name
1	2YD-112-01	DRAG KNOB ASSEMBLY
2	2E4-040-01	DRAG WASHER RETAINER
3	2W2-088-02	KEY WASHER
4	2W1-263-02	070-285 WASHER
5	2W3-041-01	EARED WASHER
6	2W1-264-02	140-285 WASHER
7	2Z1-013-05	610-3 BALL BEARING
8	2C1-134-01	COLLAR
9	2S1-419-01	SPOOL
10	2F4-023-01	CLICK PAWL
11	2E5-013-01	E3.0 RETAINER
12	2Q2-007-01	CLICK PAWL SPRING
13	2S4-019-01	LINE STOPPER
14	2Q3-121-01	SPRING
15	2YT-515-01	SPOOL TOTAL ASSEMBLY
16	2W1-280-01	090-260 WASHER
17	2F3-074-02	CLICK GEAR
18	2E9-053-01	PROOF WATER RING
19	2E2-092-01	B20M-050 SCREW
20	2F6-120-01	ROTOR NUT HOLDING PLATE
21	2Z1-030-05	610-2.5 BALL BEARING
22	2E3-093-01	ROTOR NUT
23	2W1-198-01	111-158 WASHER
24	2C2-061-01	WORM SHAFT COLLAR
25	2M3-169-01	MAIN SHAFT
26	2E2-006-03	B26M-050 SCREW
27	2R4-226-01	BAIL TRIP COVER
28	2R1-160-01	ROTOR
29	2E0-031-02	X30M-070 SCREW
30	2R2-077-01	BAIL ARM
31	2Z1-012-05	407-2.5 BALL BEARING
32	2C1-077-01	LINE ROLLER COLLAR
33	2R6-022-02	LINE ROLLER
34	2W1-283-01	060-080 WASHER
35	2E2-015-04	B35M-060 SCREW
36	2YL-177-01	BAIL ASSEMBLY
37	2R5-188-01	BAIL TRIP SHAFT
38	2W1-044-01	016-035 WASHER
39	2Q1-132-02	BAIL SPRING
40	2R5-198-01	BAIL PAWL
41	2R4-225-01	BAIL TRIP COVER
42	2A2-060-01	CAM
43	2E2-013-02	B20M-060 SCREW
44	2Q3-009-01	ANTI-REVERSE SPRING
45	2F8-079-01	ANTI-REVERSE SPRING ANCHOR
46	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
47	2F5-189-01	ROLLER CLUTCH RETAINER
48	2Q2-016-01	SPRING
49	2YZ-017-01	ONE-WAY CLUTCH BEARING ASSEMBLY
50	2E2-011-01	F30M-080 SCREW
51	2F5-203-01	BEARING RETAINER
52	2Z1-005-05	816-5 BALL BEARING
53	2G2-069-01	PINION GEAR
54	2Z1-013-05	610-3 BALL BEARING
55	2E2-099-01	B20M-050 SCREW
56	2B4-019-01	BODY COVER FLANGE
57	2C2-036-01	WORM SHAFT BUSH
58	2Z1-014-05	306-2.5 BALL BEARING
59	2C1-071-01	WORM SHAFT COLLAR
60	2G3-044-01	OSCILLATING GEAR
61	2E2-009-01	F23M-060 SCREW
62	2M1-032-01	OSCILLATING SLIDER
63	2W1-058-02	030-050 WASHER
64	2M5-007-01	LINE GUIDE PIN
65	2C2-034-01	LINE GUIDE PIN BUSH
66	2W1-058-04	030-050 WASHER
67	2F5-181-01	OSCILLATING SLIDER COVER
68	2YB-138-51	BODY ASSEMBLY
69	2Z1-010-02	812-3.5 BALL BEARING
70	2G1-169-01	DRIVE GEAR
71	2W1-035-00	080-105 WASHER
72	2Z1-023-05	814-4 BALL BEARING
73	2B2-037-03	BODY COVER
74	2W1-058-06	030-050 WASHER
75	2W1-127-02	027-048 WASHER
76	2E2-060-03	A30M-100 SCREW
77	2E2-031-01	A26M-075 SCREW
78	2YH-469-01	HANDLE TOTAL ASSEMBLY
79	2H6-015-01	HANDLE SCREW CAP
80	2A2-059-02	ANTI-REVERSE CAM
81	2M4-018-01	WORM SHAFT
82	2W1-058-03	030-050 WASHER
83	2P1-025-01	OSCILLATING SLIDER PIN
84	2W5-031-01	WORM SHAFT COVER GASKET
85	2F5-161-01	WORM SHAFT COVER
86	2E2-050-01	A20M-035 SCREW
87	2W1-124-02	045-065 WASHER
88	2E2-003-01	B26M-036 SCREW
89	2F6-054-01	WATER SHIELD
90	2F5-162-02	REAR COVER
91	2E2-095-01	B26M-050 SCREW
TG3000<5.2>	SPECIAL PARTS	
9	2S1-419-02	SPOOL
13	2YT-515-02	SPOOL TOTAL ASSEMBLY
51	2G2-056-01	PINION GEAR
58	2G3-037-01	WORM SHAFT GEAR
68	2G1-168-01	DRIVE GEAR

Please order by parts number,not key number *Bitte,Best:-Nr.angeben(Nicht " key " -nr.)*

Veuillez indiquer le numero de la pièce(Non " key " no.)

TG4000

GEAR RATIO〈6.3/5.2〉



Key NO.	Parts No.	Parts name
1	2YD-112-01	DRAG KNOB ASSEMBLY
2	2E4-040-01	DRAG WASHER RETAINER
3	2W2-088-02	KEY WASHER
4	2W1-263-02	070-285 WASHER
5	2W3-041-01	EARED WASHER
6	2W1-264-02	140-285 WASHER
7	2Z1-013-05	610-3 BALL BEARING
8	2C1-134-01	COLLAR
9	2S1-430-01	SPOOL
10	2F4-023-01	CLICK PAWL
11	2E5-013-01	E3.0 RETAINER
12	2Q2-007-01	CLICK PAWL SPRING
13	2S4-019-01	LINE STOPPER
14	2Q3-121-01	SPRING
15	2YT-522-01	SPOOL TOTAL ASSEMBLY
16	2W1-280-01	090-260 WASHER
17	2F3-074-02	CLICK GEAR
18	2E9-053-01	PROOF WATER RING
19	2E2-092-01	B20M-050 SCREW
20	2F6-120-01	ROTOR NUT HOLDING PLATE
21	2Z1-030-05	610-2.5 BALL BEARING
22	2E3-093-01	ROTOR NUT
23	2W1-198-01	111-158 WASHER
24	2C2-061-01	WORM SHAFT COLLAR
25	2M3-169-01	MAIN SHAFT
26	2E2-006-03	B26M-050 SCREW
27	2R4-226-01	BAIL TRIP COVER
28	2R1-160-01	ROTOR
29	2E0-031-02	X30M-070 SCREW
30	2R2-077-01	BAIL ARM
31	2Z1-012-05	407-2.5 BALL BEARING
32	2C1-077-01	LINE ROLLER COLLAR
33	2R6-022-02	LINE ROLLER
34	2W1-283-01	060-080 WASHER
35	2E2-015-04	B35M-060 SCREW
36	2YL-177-01	BAIL ASSEMBLY
37	2R5-188-01	BAIL TRIP SHAFT
38	2W1-044-01	016-035 WASHER
39	2Q1-132-02	BAIL SPRING
40	2R5-198-01	BAIL PAWL
41	2R4-225-01	BAIL TRIP COVER
42	2A2-060-01	CAM
43	2E2-013-02	B20M-060 SCREW
44	2Q3-009-01	ANTI-REVERSE SPRING
45	2F8-079-01	ANTI-REVERSE SPRING ANCHOR
46	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
47	2F5-189-01	ROLLER CLUTCH RETAINER
48	2Q2-016-01	SPRING
49	2YZ-017-01	ONE-WAY CLUTCH BEARING ASSEMBLY
50	2E2-011-01	F30M-080 SCREW
51	2F5-203-01	BEARING RETAINER
52	2Z1-005-05	816-5 BALL BEARING
53	2G2-069-01	PINION GEAR
54	2Z1-013-05	610-3 BALL BEARING
55	2E2-099-01	B20M-050 SCREW
56	2B4-019-01	BODY COVER FLANGE
57	2C2-036-01	WORM SHAFT BUSH
58	2Z1-014-05	306-2.5 BALL BEARING
59	2C1-071-01	WORM SHAFT COLLAR
60	2G3-044-01	OSCILLATING GEAR
61	2E2-009-01	F23M-060 SCREW
62	2M1-032-01	OSCILLATING SLIDER
63	2W1-058-02	030-050 WASHER
64	2M5-007-01	LINE GUIDE PIN
65	2C2-034-01	LINE GUIDE PIN BUSH
66	2W1-058-04	030-050 WASHER
67	2F5-181-01	OSCILLATING SLIDER COVER
68	2YB-138-51	BODY ASSEMBLY
69	2Z1-010-02	812-3.5 BALL BEARING
70	2G1-169-01	DRIVE GEAR
71	2W1-035-00	080-105 WASHER
72	2Z1-023-05	814-4 BALL BEARING
73	2B2-037-03	BODY COVER
74	2W1-058-06	030-050 WASHER
75	2W1-127-02	027-048 WASHER
76	2E2-060-03	A30M-100 SCREW
77	2E2-031-01	A26M-075 SCREW
78	2YH-469-01	HANDLE TOTAL ASSEMBLY
79	2H6-015-01	HANDLE SCREW CAP
80	2A2-059-02	ANTI-REVERSE CAM
81	2M4-018-01	WORM SHAFT
82	2W1-058-03	030-050 WASHER
83	2P1-025-01	OSCILLATING SLIDER PIN
84	2W5-031-01	WORM SHAFT COVER GASKET
85	2F5-161-01	WORM SHAFT COVER
86	2E2-050-01	A20M-035 SCREW
87	2W1-124-02	045-065 WASHER
88	2E2-003-01	B26M-036 SCREW
89	2F6-054-01	WATER SHIELD
90	2F5-162-02	REAR COVER
91	2E2-095-01	B26M-050 SCREW
TG4000<5.2>	SPECIAL PARTS	
9	2S1-430-02	SPOOL
13	2YT-522-02	SPOOL TOTAL ASSEMBLY
51	2G2-056-01	PINION GEAR
58	2G3-037-01	WORM SHAFT GEAR
68	2G1-168-01	DRIVE GEAR


Please order by parts number,not key number *Bitte,Best:-Nr.angeben(Nicht " key " -nr.)*

Veuillez indiquer le numero de la pièce(Non " key " no.)

ReelSchematic

TG6000

GEAR RATIO (5.4/4.3)




Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-101-01	DRAG KNOB ASSEMBLY	33	2Z1-001-05	508-2.5 BALL BEARING	65	2C2-034-01	LINE GUIDE PIN BUSH
2	2E9-049-01	PROOF WATER RING	34	2R6-028-02	LINE ROLLER	66	2W1-058-04	030-050 WASHER
3	2E4-040-01	DRAG WASHER RETAINER	35	2W4-008-01	SPACER	67	2F5-051-01	OSCILLATING SLIDER COVER
4	2W2-088-01	KEY WASHER	36	2W1-267-01	061-105 WASHER	68	2E2-006-03	B26M-050 SCREW
5	2W1-263-02	070-285 WASHER	37	2YL-171-01	BAIL ASSEMBLY	69	2W1-058-03	030-050 WASHER
6	2W3-041-01	EARED WASHER	38	2R5-184-01	BAIL TRIP SHAFT	70	2H6-011-02	HANDLE SCREW CAP
7	2W1-264-02	140-285 WASHER	39	2W1-044-01	016-035 WASHER	71	2YB-250-01	BODY ASSEMBLY
8	2Z1-009-05	711-3 BALL BEARING	40	2Q1-122-01	BAIL SPRING	72	2Z1-007-05	917-4 BALL BEARING
9	2C1-124-01	SPACER	41	2R4-223-01	BAIL SPRING COVER	73	2G1-166-01	DRIVE GEAR
10	2S1-415-01	SPOOL	42	2E9-046-01	PROOF WATER RING	74	2W1-014-03	091-130 WASHER
11	2S4-019-01	LINE STOPPER	43	2E2-040-01	b26M-060 SCREW	75	2E9-051-01	PROOF WATER RING
12	2Q3-121-01	SPRING	44	2F5-441-01	ROLLER CLUTCH RETAINER	76	2B2-027-03	BODY COVER
13	2F4-023-01	CLICK PAWL	45	2Z1-007-05	917-4 BALL BEARING	77	2E2-064-03	H30M-100 SCREW
14	2E5-013-01	E3.0 RETAINER	46	2C1-123-01	SPACER	78	2E2-031-01	A26M-075 SCREW
15	2Q2-007-01	CLICK PAWL SPRING	47	2A4-019-05	ONE-WAY CLUTCH INNER TUBE	79	2B4-009-01	BODY FLANGE
16	2YT-511-01	SPOOL TOTAL ASSEMBLY	48	2YZ-015-01	ONE-WAY CLUTCH BEARING ASSEMBLY	80	2YH-463-01	HANDLE TOTAL ASSEMBLY
17	2W1-266-04	050-210 WASHER	49	2Q1-071-01	CAGE SPRING	81	2F5-068-01	WORM SHAFT COVER
18	2F3-074-01	CLICK GEAR	50	2E2-052-02	F26M-080 SCREW	82	2E2-050-01	A20M-035 SCREW
19	2E2-092-01	B20M-050 SCREW	51	2F5-178-01	BEARING RETAINER	83	2W4-006-01	SPACER
20	2E9-050-01	PROOF WATER RING	52	2Z1-008-05	1020-5 BALL BEARING	84	2E2-006-03	B26M-050 SCREW
21	2F6-120-01	ROTOR NUT HOLDING PLATE	53	2G2-170-01	PINION GEAR	85	2P1-021-01	OSCILLATING SLIDER PIN
22	2E3-003-01	ROTOR NUT	54	2Z1-009-05	711-3 BALL BEARING	86	2F6-014-01	WATER SHIELD
23	2W1-265-01	092-160 WASHER	55	2C2-130-01	WORM SHAFT BUSH	87	2F5-067-03	REAR COVER
24	2M3-154-01	MAIN SHAFT	56	2Z1-014-05	306-2.5 BALL BEARING	88	2E2-095-01	B26M-050 SCREW
25	2E0-010-02	X26M-060 SCREW	57	2C1-046-01	COLLAR	TG6000<4.3>	SPECIAL PARTS	
26	2R4-224-01	BAIL TRIP COVER	58	2G3-095-01	OSCILLATING GEAR	10	2S1-415-02	SPOOL
27	2R5-180-01	BAIL TRIP LEVER	59	2M4-006-02	WORM SHAFT	16	2YT-511-02	SPOOL TOTAL ASSEMBLY
28	2Q1-131-01	TAPPET SPRING	60	2W1-058-04	030-050 WASHER	53	2G2-172-01	PINION GEAR
29	2R5-192-01	GRIND LEVER	61	2E2-052-02	F26M-080 SCREW	58	2G3-097-01	OSCILLATING GEAR
30	2E0-008-01	BAIL HOLDER SCREW	62	2M1-022-01	OSCILLATING SLIDER	73	2G1-167-01	DRIVE GEAR
31	2R1-159-01	ROTOR	63	2E2-009-02	F23M-060 SCREW			
32	2E0-004-03	LINE ROLLER SCREW	64	2M5-001-01	LINE GUIDE PIN			

Please order by parts number,not key number *Bitte,Best:-Nr.angeben(Nicht " key " -nr.)*

TG8000

GEAR RATIO (5.4/4.3)



Key NO.	Parts No.	Parts name
1	2YD-101-01	DRAG KNOB ASSEMBLY
2	2E9-049-01	PROOF WATER RING
3	2E4-040-01	DRAG WASHER RETAINER
4	2W2-088-01	KEY WASHER
5	2W1-263-01	070-285 WASHER
6	2W3-041-01	EARED WASHER
7	2W1-264-01	140-285 WASHER
8	2Z1-009-05	711-3 BALL BEARING
9	2C1-124-01	SPACER
10	2YS-288-01	SPOOL ASSEMBLY
11	2F4-023-01	CLICK PAWL
12	2Q2-007-01	CLICK PAWL SPRING
13	2E5-013-01	E3.0 RETAINER
14	2YT-453-01	SPOOL TOTAL ASSEMBLY
15	2W1-266-01	050-210 WASHER
16	2F3-074-01	CLICK GEAR
17	2E2-092-01	B20M-050 SCREW
18	2E9-050-01	PROOF WATER RING
19	2F6-120-01	ROTOR NUT HOLDING PLATE
20	2E3-003-01	ROTOR NUT
21	2W1-265-01	092-160 WASHER
22	2M3-154-01	MAIN SHAFT
23	2E0-010-02	X26M-060 SCREW
24	2YR-074-01	BAIL TRIP COVER ASSEMBLY
25	2R5-180-01	BAIL TRIP LEVER
26	2Q1-131-01	TAPPET SPRING
27	2R5-183-01	GRIND LEVER
28	2E0-008-01	BAIL HOLDER SCREW
29	2R1-148-01	ROTOR
30	2E0-004-03	LINE ROLLER SCREW
31	2Z1-001-05	508-2.5 BALL BEARING
32	2R6-028-02	LINE ROLLER
33	2W4-008-01	SPACER
34	2W1-267-01	061-105 WASHER
35	2YL-160-01	BAIL ASSEMBLY
36	2R5-184-01	BAIL TRIP SHAFT
37	2W1-044-01	016-035 WASHER
38	2Q1-122-01	BAIL SPRING
39	2YR-073-01	BAIL SPRING COVER ASSEMBLY
40	2E9-046-01	PROOF WATER RING
41	2E2-040-01	b26M-060 SCREW
42	2F5-441-01	ROLLER CLUTCH RETAINER
43	2Z1-007-05	917-4 BALL BEARING
44	2C1-123-01	INTERVAL COVER
45	2A4-019-05	ONE-WAY CLUTCH INNER TUBE
46	2YZ-015-01	ONE-WAY CLUTCH BEARING ASSEMBLY
47	2Q1-071-01	CAGE SPRING
48	2E2-052-02	F26M-080 SCREW
49	2F5-178-01	BEARING RETAINER
50	2Z1-008-05	1020-5 BALL BEARING
51	2G2-170-01	PINION GEAR
52	2Z1-009-05	711-3 BALL BEARING
53	2C2-130-01	WORM SHAFT BUSH
54	2Z1-014-05	306-2.5 BALL BEARING
55	2C1-046-01	COLLAR
56	2G3-095-01	OSCILLATING GEAR
57	2M4-006-01	WORM SHAFT
58	2W1-058-04	030-050 WASHER
59	2E2-052-02	F26M-080 SCREW
60	2E2-009-02	F23M-060 SCREW
61	2M1-022-01	OSCILLATING SLIDER
62	2M5-001-01	LINE GUIDE PIN
63	2C2-034-01	LINE GUIDE PIN BUSH
64	2W1-058-04	030-050 WASHER
65	2F5-051-01	OSCILLATING SLIDER COVER
66	2E2-006-03	B26M-050 SCREW
67	2W1-058-03	030-050 WASHER
68	2H6-011-02	HANDLE SCREW CAP
69	2YB-250-01	BODY ASSEMBLY
70	2Z1-007-05	917-4 BALL BEARING
71	2G1-166-01	DRIVE GEAR
72	2W1-014-03	091-130 WASHER
73	2E9-051-01	PROOF WATER RING
74	2B2-027-03	BODY COVER
75	2E2-064-03	H30M-100 SCREW
76	2E2-031-01	A26M-075 SCREW
77	2B4-009-01	BODY FLANGE
78	2YH-380-01	HANDLE TOTAL ASSEMBLY
79	2F5-068-01	WORM SHAFT COVER
80	2E2-050-01	A20M-035 SCREW
81	2W4-006-01	SPACER
82	2E2-006-03	B26M-050 SCREW
83	2P1-021-01	OSCILLATING SLIDER PIN
84	2F6-014-01	WATER SHIELD
85	2F5-067-03	REAR COVER
86	2E2-095-01	B26M-050 SCREW
GEAR RATIO 4.3	SPECIAL PARTS	
51	2G2-172-01	PINION GEAR
56	2G3-097-01	OSCILLATING GEAR
71	2G1-167-01	DRIVE GEAR

ReelSchematic