
2X576101AE

Please order by parts number,not key number
Bitte.Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

TCA WARRANTY QUALITY

SPINNING REEL SEASPIRIT SA148R




Key NO.	Parts No.	Parts name
63-68	2YT-576-02	SPOOL TOTAL ASSEMBLY
1	2E2-006-03	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-434-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-04	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2Z1-023-05	814-4 BALL BEARING
12	2E3-048-01	CAST CONTROL NUT
13	2W5-015-01	CAST CONTROL SPACER
14	2E9-005-01	O RING
15	2S3-022-04	CASTING BUTTON
16	2E1-009-01	A30-100 SCREW
17	2F5-231-12	RIGHT SIDE COVER
18	2Q3-099-01	ANTI-REVERSE RATCHET SET
19	2A2-069-01	CLUTCH CAM
20	2E1-014-01	B40-100 SCREW
21	2F8-072-01	ANTI-REVERSE RATCHET SET
22	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
23	2F6-068-01	HOLDING PLATE
24	2E1-036-01	B26-040 SCREW
25	2Z2-017-01	BUSHING
26	2A4-026-05	ONE-WAY CLUTCH INNER TUBE
27	2W2-046-01	KEY WASHER
28	2W1-170-03	082-300 WASHER
29	2W3-025-01	EARED WASHER
30	2W2-045-01	KEY WASHER
31	2G1-059-01	DRIVE GEAR
32	2W1-173-01	081-140 WASHER
33	2M3-079-01	DRIVE SHAFT
34	2Q3-081-01	ONE-WAY CLUTCH SPRING
35	2YF-082-01	ANTI-REVERSE RATCHET A
36	2W1-286-01	081-310 WASHER
37	2YA-026-01	ANTI-REVERSE RATCHET B
38	2W1-169-01	061-120 WASHER
39	2E5-028-01	E4.0 RETAINER
40	2E1-020-02	B22-055 SCREW
41	2F6-074-03	BODY SPACER
42	2E1-066-01	A20-100 SCREW
43	2G2-076-01	PINION GEAR
44	2Q1-080-01	YOKE SPRING
45	2A2-068-01	PINION YOKE
46	2F6-067-01	YOKE PLATE
47	2P4-011-03	LEVEL WIND GUIDE
48	2Q2-009-01	CLICK PAWL SPRING
49	2P1-036-01	ANTI-REVERSE PAWL PIN
50	2A4-055-01	ANTI-REVERSE PAWL
51	2YB-280-03	BODY ASSEMBLY
52	2E5-013-01	E3.0 RETAINER
53	2W1-046-01	051-068 WASHER
54	2G3-050-01	COUNTER GEAR
55	2C2-074-01	WORM SHAFT BUSHING
56	2E3-014-01	LINE GUIDE NUT
57	2W1-100-01	020-068 WASHER
58	2M5-005-01	LINE GUIDE PIN
59	2YR-061-01	LINE GUIDE ASSEMBLY
60	2C4-029-01	LEVEL WIND GUARD
61	2W1-087-01	060-080 WASHER
62	2YM-119-01	WORM SHAFT ASSEMBLY
63	2YS-297-02	SPOOL ASSEMBLY
64	2Z1-035-05	917-5 BALL BEARING
65	2W1-097-01	059-100 WASHER
66	2F3-052-01	CLICK GEAR
67	2G3-049-01	SPOOL GEAR
68	2E5-006-01	E2.5 RETAINER
69	2W5-015-01	CAST CONTROL SPACER
70	2E1-020-02	B22-055 SCREW
71	2F6-119-01	CLUTCH PAWL RETAINER
72	2F2-020-01	CLICK SPRING
73	2F4-019-01	CLICK PAWL
74	2E2-007-01	B30M-100 SCREW
75	2G3-053-01	IDLE GEAR
76	2E3-049-01	IDLE GEAR SHAFT
77	2F6-069-01	RETAINER
78	2F5-216-23	LEFT SIDE COVER
79	2W5-040-01	CLICK SWITCH WASHER
80	2F7-006-01	CLICK SWITCH
81	2E3-050-06	SIDEPLATE HOLDING NUT
SA148R SPECIAL PARTS		
4	2YH-510-01	HANDLE TOTAL ASSEMBLY

Please order by parts number,not key number
Bitte,Best.-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

TCL WARRANTY QUALITY

SPINNING REEL SEASPIRIT SA148R/C-ft/SA148R/C-M




Key NO.	Parts No.	Parts name
67-72	2YT-576-02	SPOOL TOTAL ASSEMBLY
1	2E2-006-03	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-434-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-04	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2Z1-023-05	814-4 BALL BEARING
12	2E3-048-01	CAST CONTROL NUT
13	2W5-015-01	CAST CONTROL SPACER
14	2E9-005-01	O RING
15	2S3-022-04	CASTING BUTTON
16	2E1-009-01	A30-100 SCREW
17	2YF-084-08	RIGHT SIDE COVER ASSEMBLY
18	2Q3-099-01	ANTI-REVERSE RATCHET SET
19	2A2-069-01	CLUTCH CAM
20	2E1-014-01	B40-100 SCREW
21	2F8-072-01	ANTI-REVERSE RATCHET SET
22	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
23	2F6-068-01	HOLDING PLATE
24	2E1-036-01	B26-040 SCREW
25	2Z2-017-01	BUSHING
26	2A4-026-05	ONE-WAY CLUTCH INNER TUBE
27	2W2-046-01	KEY WASHER
28	2W1-170-03	082-300 WASHER
29	2W3-025-01	EARED WASHER
30	2W2-045-01	KEY WASHER
31	2G1-059-01	DRIVE GEAR
32	2W1-173-01	081-140 WASHER
33	2M3-079-01	DRIVE SHAFT
34	2Q3-081-01	ONE-WAY CLUTCH SPRING
35	2YF-082-01	ANTI-REVERSE RATCHET A
35	2W1-286-01	081-310 WASHER
37	2YA-026-01	ANTI-REVERSE RATCHET B
38	2W1-169-01	061-120 WASHER
39	2E5-028-01	E4.0 RETAINER
40	2YF-085-01	COUNTER ASSEMBLY
41	2E1-016-02	B26-080 SCREW
42	2E1-020-02	B22-055 SCREW
43	2F6-073-04	BODY SPACER

Key NO.	Parts No.	Parts name
44	2E1-066-01	A20-100 SCREW
45	2G2-076-01	PINION GEAR
46	2Q1-080-01	YOKE SPRING
47	2A2-068-01	PINION YOKE
48	2F6-067-01	YOKE PLATE
49	2P4-011-03	LEVEL WIND GUIDE
50	2Q2-009-01	CLICK PAWL SPRING
51	2P1-036-01	ANTI-REVERSE PAWL PIN
52	2A4-055-01	ANTI-REVERSE PAWL
53	2C1-084-01	COUNTER GEAR COLLAR
54	2G3-054-01	COUNTER GEAR A
55	2YB-280-03	BODY ASSEMBLY
56	2E5-013-01	E3.0 RETAINER
57	2W1-046-01	051-068 WASHER
58	2G3-050-01	COUNTER GEAR
59	2C2-074-01	WORM SHAFT BUSHING
60	2E3-014-01	LINE GUIDE NUT
61	2W1-100-01	020-068 WASHER
62	2M5-005-01	LINE GUIDE PIN
63	2YR-061-01	LINE GUIDE ASSEMBLY
64	2C4-029-01	LEVEL WIND GUARD
65	2W1-087-01	060-080 WASHER
66	2YM-119-01	WORM SHAFT ASSEMBLY
67	2YS-297-02	SPOOL ASSEMBLY
68	2Z1-035-05	917-5 BALL BEARING
69	2W1-097-01	059-100 WASHER
70	2F3-052-01	CLICK GEAR
71	2G3-049-01	SPOOL GEAR
72	2E5-006-01	E2.5 RETAINER
73	2W5-015-01	CAST CONTROL SPACER
74	2E1-020-02	B22-055 SCREW
75	2F6-119-01	CLUTCH PAWL RETAINER
76	2F2-020-01	CLICK SPRING
77	2F4-019-01	CLICK PAWL
78	2E2-007-01	B30M-100 SCREW
79	2G3-053-01	IDLE GEAR
80	2E3-049-01	IDLE GEAR SHAFT
81	2F6-069-01	RETAINER
82	2F5-216-24	LEFT SIDE COVER
83	2W5-040-01	CLICK SWITCH WASHER
84	2F7-006-01	CLICK SWITCH
85	2E3-050-06	SIDEPLATE HOLDING NUT
SA148R/C-M SPECIAL PARTS		
4	2YH-510-01	HANDLE TOTAL ASSEMBLY

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SALTWATER REEL SEASPIRIT SA248R / SA348R




Key NO.	Parts No.	Parts name
62-67	2YT-201-02	SPOOL TOTAL ASSEMBLY
1	2E2-006-01	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-434-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-04	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2Z1-023-05	814-4 BALL BEARING
12	2E3-048-01	CAST CONTROL NUT
13	2W5-029-01	CAST CONTROL SPACER
14	2E9-005-01	O RING
15	2S3-022-04	CASTING BUTTON
16	2E1-009-01	A30-100 SCREW
17	2F5-231-09	RIGHT SIDE COVER
18	2Q3-099-01	ANTI-REVERSE RATCHET SET
19	2A2-069-01	CLUTCH CAM
20	2E1-014-01	B40-100 SCREW
21	2Z2-017-01	BUSHING
22	2F8-072-01	ANTI-REVERSE RATCHET SET
23	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
24	2F6-068-01	HOLDING PLATE
25	2E1-036-01	B26-040 SCREW
26	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
27	2W2-045-01	KEY WASHER
28	2W1-170-03	082-300 WASHER
29	2W3-025-01	EARED WASHER
30	2W2-046-01	KEY WASHER
31	2G1-059-01	DRIVE GEAR
32	2W1-173-01	081-140 WASHER
33	2M3-079-01	DRIVE SHAFT
34	2Q3-081-01	ONE-WAY CLUTCH SPRING
35	2YF-082-01	ANTI-REVERSE RATCHET A
36	2YA-026-01	ANTI-REVERSE RATCHET B
37	2W1-169-01	061-120 WASHER
38	2E5-028-01	E4.0 RETAINER
39	2E1-020-02	B22-055 SCREW
40	2F6-074-03	BODY SPACER
41	2G2-076-01	PINION GEAR
42	2Q1-080-01	YOKE SPRING
43	2A2-068-01	PINION YOKE
44	2F6-067-01	YOKE PLATE
45	2P4-011-01	LEVEL WIND GUIDE
46	2Q2-009-01	CLICK PAWL SPRING
47	2A4-055-01	ANTI-REVERSE PAWL
48	2P1-036-01	ANTI-REVERSE PAWL PIN
49	2YB-140-03	BODY ASSEMBLY
50	2E5-013-01	E3.0 RETAINER
51	2W1-046-01	051-068 WASHER
52	2G3-050-01	COUNTER GEAR
53	2C2-074-01	WORM SHAFT BUSHING
54	2E3-014-01	LINE GUIDE NUT
55	2W1-100-01	020-068 WASHER
56	2M5-005-01	LINE GUIDE PIN
57	2YR-061-01	LINE GUTDE ASSEMBLY
58	2C4-006-01	LEVEL WIND GUARD
59	2W1-087-01	060-080 WASHER
60	2YM-047-01	WORM SHAFT ASSEMBLY
61	2E1-066-01	A20-100 SCREW
62	2YS-142-02	SPOOL ASSEMBLY
63	2Z1-035-05	917-5 BALL BEARING
64	2W1-097-01	059-100 WASHER
65	2F3-052-01	CLICK GEAR
66	2G3-049-01	SPOOL GEAR
67	2E5-006-01	E2.5 RETAINER
68	2W5-015-01	CAST CONTROL SPACER
69	2E2-007-01	B30M-100 SCREW
70	2G3-053-01	IDLE GEAR
71	2E3-049-01	IDLE GEAR SHAFT
72	2F6-069-01	RETAINER
73	2E1-048-01	B22-080 SCREW
74	2F2-020-01	CLICK SPRING
75	2F4-019-01	CLICK PAWL
76	2F5-216-18	LEFT SIDE COVER
77	2W5-040-01	CLICK SWITCH WASHER
78	2F7-006-01	CLICK SWITCH
79	2E3-050-05	SIDEPLATE HOLDING NUT
SA348R	SPECIAL PARTS	
62-67	2YT-246-03	SPOOL TOTAL ASSEMBLY
45	2P4-011-02	LEVEL WIND GUIDE
49	2YB-141-04	BODY ASSEMBLY
58	2C4-008-01	LEVEL WIND GUARD
60	2YM-049-01	WORM SHAFT ASSEMBLY
62	2YS-147-03	SPOOL ASSEMBLY

ReelSchematic

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SALTWATER REEL SEASPIRIT SA248R/C-ft / SA348R/C-ft




Key NO.	Parts No.	Parts name
66-71	2YT-201-02	SPOOL TOTAL ASSEMBLY
1	2E2-006-01	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-434-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-04	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2Z1-023-05	814-4 BALL BEARING
12	2E3-048-01	CAST CONTROL NUT
13	2W5-029-01	CAST CONTROL SPACER
14	2E9-005-01	O RING
15	2S3-022-04	CASTING BUTTON
16	2E1-009-01	A30-100 SCREW
17	2YF-084-06	RIGHT SIDE COVER ASSEMBLY
18	2Q3-099-01	ANTI-REVERSE RATCHET SET
19	2A2-069-01	CLUTCH CAM
20	2E1-014-01	B40-100 SCREW
21	2Z2-017-01	BUSHING
22	2F8-072-01	ANTI-REVERSE RATCHET SET
23	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
24	2F6-068-01	HOLDING PLATE
25	2E1-036-01	B26-040 SCREW
26	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
27	2W2-045-01	KEY WASHER
28	2W1-170-03	082-300 WASHER
29	2W3-025-01	EARED WASHER
30	2W2-046-01	KEY WASHER
31	2G1-059-01	DRIVE GEAR
32	2W1-173-01	081-140 WASHER
33	2M3-079-01	DRIVE SHAFT
34	2Q3-081-01	ONE-WAY CLUTCH SPRING
35	2YF-082-01	ANTI-REVERSE RATCHET A
36	2YA-026-01	ANTI-REVERSE RATCHET B
37	2W1-169-01	061-120 WASHER
38	2E5-028-01	E4.0 RETAINER
39	2YF-085-01	COUNTER ASSEMBLY
40	2E1-016-02	B26-080 SCREW
41	2E1-020-02	B22-055 SCREW
42	2F6-073-04	BODY SPACER
43	2E1-066-01	A20-100 SCREW
44	2G2-076-01	PINION GEAR
45	2Q1-080-01	YOKE SPRING
46	2A2-068-01	PINION YOKE
47	2F6-067-01	YOKE PLATE
48	2P4-011-01	LEVEL WIND GUIDE
49	2Q2-009-01	CLICK PAWL SPRING
50	2A4-055-01	ANTI-REVERSE PAWL
51	2P1-036-01	ANTI-REVERSE PAWL PIN
52	2G3-054-01	COUNTER GEAR A
53	2C1-084-01	COUNTER GEAR COLLAR
54	2YB-140-03	BODY ASSEMBLY
55	2E5-013-01	E3.0 RETAINER
56	2W1-046-01	051-068 WASHER
57	2G3-050-01	COUNTER GEAR
58	2C2-074-01	WORM SHAFT BUSHING
59	2E3-014-01	LINE GUIDE NUT
60	2W1-100-01	020-068 WASHER
61	2M5-005-01	LINE GUIDE PIN
62	2YR-061-01	LINE GUIDE ASSEMBLY
63	2C4-006-01	LEVEL WIND GUARD
64	2W1-087-01	060-080 WASHER
65	2YM-047-01	WORM SHAFT ASSEMBLY
66	2YS-142-02	SPOOL ASSEMBLY
67	2Z1-035-05	917-5 BALL BEARING
68	2W1-097-01	059-100 WASHER
69	2F3-052-01	CLICK GEAR
70	2G3-049-01	SPOOL GEAR
71	2E5-006-01	E2.5 RETAINER
72	2W5-015-01	CAST CONTROL SPACER
73	2E2-007-01	B30M-100 SCREW
74	2G3-053-01	IDLE GEAR
75	2E3-049-01	IDLE GEAR SHAFT
76	2F6-069-01	RETAINER
77	2E1-048-01	B22-080 SCREW
78	2F2-020-01	CLICK SPRING
79	2F4-019-01	CLICK PAWL
80	2F5-216-18	LEFT SIDE COVER
81	2W5-040-01	CLICK SWITCH WASHER
82	2F7-006-01	CLICK SWITCH
83	2E3-050-05	SIDEPLATE HOLDING NUT
SA348R/C-ft	SPECIAL PARTS	
66-71	2YT-246-03	SPOOL TOTAL ASSEMBLY
48	2P4-011-02	LEVEL WIND GUIDE
54	2YB-141-04	BODY ASSEMBLY
63	2C4-008-01	LEVEL WIND GUARD
65	2YM-049-01	WORM SHAFT ASSEMBLY
66	2YS-147-03	SPOOL ASSEMBLY

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SALTWATER REEL SEASPIRIT SA248R/C-ft / SA348R/C-ft




Key NO.	Parts No.	Parts name
66-71	2YT-201-02	SPOOL TOTAL ASSEMBLY
1	2E2-006-01	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-434-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-04	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2Z1-023-05	814-4 BALL BEARING
12	2E3-048-01	CAST CONTROL NUT
13	2W5-029-01	CAST CONTROL SPACER
14	2E9-005-01	O RING
15	2S3-022-04	CASTING BUTTON
16	2E1-009-01	A30-100 SCREW
17	2YF-084-06	RIGHT SIDE COVER ASSEMBLY
18	2Q3-099-01	ANTI-REVERSE RATCHET SET
19	2A2-069-01	CLUTCH CAM
20	2E1-014-01	B40-100 SCREW
21	2Z2-017-01	BUSHING
22	2F8-072-01	ANTI-REVERSE RATCHET SET
23	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
24	2F6-068-01	HOLDING PLATE
25	2E1-036-01	B26-040 SCREW
26	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
27	2W2-045-01	KEY WASHER
28	2W1-170-03	082-300 WASHER
29	2W3-025-01	EARED WASHER
30	2W2-046-01	KEY WASHER
31	2G1-059-01	DRIVE GEAR
32	2W1-173-01	081-140 WASHER
33	2M3-079-01	DRIVE SHAFT
34	2Q3-081-01	ONE-WAY CLUTCH SPRING
35	2YF-082-01	ANTI-REVERSE RATCHET A
36	2YA-026-01	ANTI-REVERSE RATCHET B
37	2W1-169-01	061-120 WASHER
38	2E5-028-01	E4.0 RETAINER
39	2YF-085-01	COUNTER ASSEMBLY
40	2E1-016-02	B26-080 SCREW
41	2E1-020-02	B22-055 SCREW
42	2F6-073-04	BODY SPACER
43	2E1-066-01	A20-100 SCREW
44	2G2-076-01	PINION GEAR
45	2Q1-080-01	YOKE SPRING
46	2A2-068-01	PINION YOKE
47	2F6-067-01	YOKE PLATE
48	2P4-011-01	LEVEL WIND GUIDE
49	2Q2-009-01	CLICK PAWL SPRING
50	2A4-055-01	ANTI-REVERSE PAWL
51	2P1-036-01	ANTI-REVERSE PAWL PIN
52	2G3-054-01	COUNTER GEAR A
53	2C1-084-01	COUNTER GEAR COLLAR
54	2YB-140-03	BODY ASSEMBLY
55	2E5-013-01	E3.0 RETAINER
56	2W1-046-01	051-068 WASHER
57	2G3-050-01	COUNTER GEAR
58	2C2-074-01	WORM SHAFT BUSHING
59	2E3-014-01	LINE GUIDE NUT
60	2W1-100-01	020-068 WASHER
61	2M5-005-01	LINE GUIDE PIN
62	2YR-061-01	LINE GUIDE ASSEMBLY
63	2C4-006-01	LEVEL WIND GUARD
64	2W1-087-01	060-080 WASHER
65	2YM-047-01	WORM SHAFT ASSEMBLY
66	2YS-142-02	SPOOL ASSEMBLY
67	2Z1-035-05	917-5 BALL BEARING
68	2W1-097-01	059-100 WASHER
69	2F3-052-01	CLICK GEAR
70	2G3-049-01	SPOOL GEAR
71	2E5-006-01	E2.5 RETAINER
72	2W5-015-01	CAST CONTROL SPACER
73	2E2-007-01	B30M-100 SCREW
74	2G3-053-01	IDLE GEAR
75	2E3-049-01	IDLE GEAR SHAFT
76	2F6-069-01	RETAINER
77	2E1-048-01	B22-080 SCREW
78	2F2-020-01	CLICK SPRING
79	2F4-019-01	CLICK PAWL
80	2F5-216-18	LEFT SIDE COVER
81	2W5-040-01	CLICK SWITCH WASHER
82	2F7-006-01	CLICK SWITCH
83	2E3-050-05	SIDEPLATE HOLDING NUT
SA348R/C-ft	SPECIAL PARTS	
66-71	2YT-246-03	SPOOL TOTAL ASSEMBLY
48	2P4-011-02	LEVEL WIND GUIDE
54	2YB-141-04	BODY ASSEMBLY
63	2C4-008-01	LEVEL WIND GUARD
65	2YM-049-01	WORM SHAFT ASSEMBLY
66	2YS-147-03	SPOOL ASSEMBLY

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SALTWATER REEL SEASPIRIT SA458R / SA558R



Key NO.	Parts No.	Parts name
62-67	2YT-311-02	SPOOL TOTAL ASSEMBLY
1	2E2-006-01	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-434-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-04	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2Z1-023-05	814-4 BALL BEARING
12	2E3-048-01	CAST CONTROL NUT
13	2W5-029-01	CAST CONTROL SPACER
14	2E9-005-01	O RING
15	2S3-022-04	CASTING BUTTON
16	2E1-009-01	A30-100 SCREW
17	2F5-295-09	RIGHT SIDE COVER
18	2Q3-099-01	ANTI-REVERSE RATCHET SET
19	2A2-069-01	CLUTCH CAM
20	2E1-014-01	B40-100 SCREW
21	2F8-072-01	ANTI-REVERSE RATCHET SET
22	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
23	2F6-092-01	HOLDING PLATE
24	2E1-036-01	B26-040 SCREW
25	2Z2-017-01	BUSHING
26	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
27	2W2-054-01	KEY WASHER
28	2W3-030-01	EARED WASHER
29	2W2-053-01	KEY WASHER
30	2W1-192-02	090-340 WASHER
31	2G1-088-01	DRIVE GEAR
32	2W1-173-01	081-140 WASHER
33	2M3-079-01	DRIVE SHAFT
34	2Q3-081-01	ONE-WAY CLUTCH SPRING
35	2YF-082-01	ANTI-REVERSE RATCHET A
36	2YA-026-01	ANTI-REVERSE RATCHET B
37	2W1-169-01	061-120 WASHER
38	2E5-028-01	E4.0 RETAINER
39	2E1-020-02	B22-055 SCREW
40	2F6-090-03	BODY SPACER
41	2G2-103-01	PINION GEAR
42	2Q1-080-01	YOKE SPRING
43	2A2-068-01	PINION YOKE
44	2F6-091-01	CLUTCH PAWL
45	2P4-013-01	LEVEL WIND GUIDE


Key NO.	Parts No.	Parts name
46	2E1-066-01	A20-100 SCREW
47	2Q2-009-01	CLICK PAWL SPRING
48	2A4-064-01	ANTI-REVERSE PAWL
49	2P1-036-01	ANTI-REVERSE PAWL PIN
50	2YB-168-03	BODY ASSEMBLY
51	2E5-013-01	E3.0 RETAINER
52	2W1-046-01	051-068 WASHER
53	2G3-050-01	COUNTER GEAR
54	2C2-074-01	WORM SHAFT BUSHING
55	2E3-014-01	LINE GUIDE NUT
56	2W1-100-04	020-068 WASHER
57	2M5-005-01	LINE GUIDE PIN
58	2YR-063-01	LINE GUIDE ASSEMBLY
59	2C4-019-01	LEVEL WIND GUARD
60	2W1-087-03	060-080 WASHER
61	2YM-058-01	WORM SHAFT ASSEMBLY
62	2YS-207-02	SPOOL ASSEMBLY
63	2Z1-035-05	917-5 BALL BEARING
64	2W1-097-01	059-100 WASHER
65	2F3-052-01	CLICK GEAR
66	2G3-075-01	SPOOL GEAR
67	2E5-006-01	E2.5 RETAINER
68	2W1-097-01	059-100 WASHER
69	2W5-015-01	CAST CONTROL SPACER
70	2E1-048-01	B22-080 SCREW
71	2F2-020-01	CLICK SPRING
72	2F4-019-01	CLICK PAWL
73	2F5-294-17	LEFT SIDE COVER
74	2W5-040-01	CLICK SWITCH WASHER
75	2F7-006-01	CLICK SWITCH
76	2E2-018-03	B30M-080 SCREW
77	2G3-076-01	SPOOL GEAR
78	2E3-049-01	IDLE GEAR SHAFT
79	2F6-093-01	RETAINER
80	2E3-058-03	SIDEPLATE HOLDING NUT
81	2E2-043-01	X50M-400 SCREW
82	2E3-022-01	ROD CLAMP BOLT
83	2F6-029-01	ROD CLAMP
84	2E3-023-01	WING NUT
SA558R	SPECIAL PARTS	
62-67	2YT-313-02	SPOOL TOTAL ASSEMBLY
45	2P4-013-02	LEVEL WIND GUIDE
50	2YB-169-03	BODY ASSEMBLY
59	2C4-019-02	LEVEL WIND GUARD
61	2YM-060-01	WORM SHAFT ASSEMBLY
62	2YS-209-02	SPOOL ASSEMBLY

ReelSchematic

Please order by parts number,not key number
Bitte,Best:-Nr.angeben(Nicht " key " -nr.)
Veuillez indiquer le numero de la pièce(Non " key " no.)

WARRANTY QUALITY

SALTWATER REEL SEASPIRIT SA458R /C-ft / SA558R/C-ft



Key NO.	Parts No.	Parts name
66-71	2YT-311-02	SPOOL TOTAL ASSEMBLY
1	2E2-006-01	B26M-050 SCREW
2	2F6-043-01	ROTOR NUT HOLDING PLATE
3	2E3-027-01	HANDLE NUT
4	2YH-434-01	HANDLE TOTAL ASSEMBLY
5	2W2-044-01	KEY WASHER
6	2YD-046-04	STAR DRAG LEVER ASSY
7	2L3-025-01	CLICK LEAF SPRING
8	2W2-043-01	KEY WASHER
9	2F8-060-01	CLICK LEAF SPRING HOLDER
10	2L1-007-01	SPRING WASHER
11	2Z1-023-05	814-4 BALL BEARING
12	2E3-048-01	CAST CONTROL NUT
13	2W5-029-01	CAST CONTROL SPACER
14	2E9-005-01	O RING
15	2S3-022-04	CASTING BUTTON
16	2E1-009-01	A30-100 SCREW
17	2YF-107-05	RIGHT SIDE COVER ASSEMBLY
18	2Q3-099-01	ANTI-REVERSE RATCHET SET
19	2A2-069-01	CLUTCH CAM
20	2E1-014-01	B40-100 SCREW
21	2F8-072-01	ANTI-REVERSE RATCHET SET
22	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
23	2F6-092-01	HOLDING PLATE
24	2E1-036-01	B26-040 SCREW
25	2Z2-017-01	BUSHING
26	2A4-026-01	ONE-WAY CLUTCH INNER TUBE
27	2W2-054-01	KEY WASHER
28	2W3-030-01	EARED WASHER
29	2W2-053-01	KEY WASHER
30	2W1-192-02	090-340 WASHER
31	2G1-088-01	DRIVE GEAR
32	2W1-173-01	081-140 WASHER
33	2M3-079-01	DRIVE SHAFT
34	2Q3-081-01	ONE-WAY CLUTCH SPRING
35	2YF-082-01	ANTI-REVERSE RATCHET A
36	2YA-026-01	ANTI-REVERSE RATCHET B
37	2W1-169-01	061-120 WASHER
38	2E5-028-01	E4.0 RETAINER
39	2YF-085-01	COUNTER ASSEMBLY
40	2E1-016-02	B26-080 SCREW
41	2E1-020-02	B22-055 SCREW
42	2F6-089-03	BODY SPACER
43	2E1-066-01	A20-100 SCREW
44	2G2-103-01	PINION GEAR
45	2Q1-080-01	YOKE SPRING
46	2A2-068-01	PINION YOKE
47	2F6-091-01	CLUTCH PAWL
48	2P4-013-01	LEVEL WIND GUIDE
49	2Q2-009-01	CLICK PAWL SPRING
50	2A4-064-01	ANTI-REVERSE PAWL
51	2P1-036-01	ANTI-REVERSE PAWL PIN
52	2C1-084-01	COUNTER GEAR COLLAR
53	2G3-077-01	COUNTER GEAR A
54	2YB-168-03	BODY ASSEMBLY
55	2E5-013-01	E3.0 RETAINER
56	2W1-046-01	051-068 WASHER
57	2G3-050-01	COUNTER GEAR
58	2C2-074-01	WORM SHAFT BUSHING
59	2E3-014-01	LINE GUIDE NUT
60	2W1-100-04	020-068 WASHER
61	2M5-005-01	LINE GUIDE PIN
62	2YR-063-01	LINE GUIDE ASSEMBLY
63	2C4-019-01	LEVEL WIND GUARD
64	2W1-087-03	060-080 WASHER
65	2YM-058-01	WORM SHAFT ASSEMBLY
66	2YS-207-02	SPOOL ASSEMBLY
67	2Z1-035-05	917-5 BALL BEARING
68	2W1-097-01	059-100 WASHER
69	2F3-052-01	CLICK GEAR
70	2G3-075-01	SPOOL GEAR
71	2E5-006-01	E2.5 RETAINER
72	2W1-097-01	059-100 WASHER
73	2W5-015-01	CAST CONTROL SPACER
74	2E1-048-01	B22-080 SCREW
75	2F2-020-01	CLICK SPRING
76	2F4-019-01	CLICK PAWL
77	2F5-294-17	LEFT SIDE COVER
78	2W5-040-01	CLICK SWITCH WASHER
79	2F7-006-01	CLICK SWITCH
80	2E2-018-03	B30M-080 SCREW
81	2G3-076-01	SPOOL GEAR
82	2E3-049-01	IDLE GEAR SHAFT
83	2F6-093-01	RETAINER
84	2E3-058-03	SIDEPLATE HOLDING NUT
85	2E2-043-01	X50M-400 SCREW
86	2E3-022-01	ROD CLAMP BOLT
87	2F6-029-01	ROD CLAMP
88	2E3-023-01	WING NUT
SA558R/C-ft	**SPECIAL PARTS**	
66-71	2YT-313-02	SPOOL TOTAL ASSEMBLY
48	2P4-013-02	LEVEL WIND GUIDE
54	2YB-169-03	BODY ASSEMBLY
63	2C4-019-02	LEVEL WIND GUARD
65	2YM-060-01	WORM SHAFT ASSEMBLY
66	2YS-209-02	SPOOL ASSEMBLY