



Key No.	Part No.	Description
1	SE324-1	Assembly - Frontcover
2	SE310	Assembly - Spinnerhead
3	SE034	Spool Clip
4	SE040-2	Spool Washer (Steel)
5	SE108-2	Drag Washer (Plastic)
6	SE321-1	Assembly - Spool
7	SE108-1	Drag Washer (Plastic)
8	SE040-1	Spool Washer (Steel)
9	SE027	Clutch Ring
10	KE126	Screw
11	SE126	Screw
12	SE032	Drag Wheel
13	SE054	Drag Screw

Key No.	Part No.	Description
14	SE301	Assembly - Body
15	SE017	Center Bushing
16	SE070	Washers (Plastic)
17	SE315	Assembly - Centershaft
18	SE009	Thumbstop
19	SE023-1	Backcover
20	KE026	Crank Bushing
21	SE308	Assembly - Crankshaft
22	KE060	Anti Reverse Pawl
23	SE061	Anti Reverse Actuator
24	KZ318-5	Assembly - Handle
25	AZ003	Crank Nut

PLEASE ORDER BY PART NUMBER

Rev. 2/92

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581