
www.reelschematic.com

ZEBCO PS220



PS220

KEY NO.	PART NO.	DESCRIPTION	PRICE
1	HW001	FRAME	5.41
2	GX4151	WORM SHAFT	5.73
3	GX4158	WORM GEAR GUARD	3.44
4	HW347	LINE GUARD	1.55
5	GX4202	LINE GUIDE PAWL	1.55
6	GX4204	LINE GUIDE CARRIER SCR	1.66
7	GX4159	CARRIER GUIDE	1.61
8	GX4160	FRAME FIXED PIN	1.37
9	HW009	THUMB BAR	1.96
10	HW323	LEFT SIDE COVER ASSY.	7.16
11	HW026	CONTROL DIAL	3.61
12	GX4250	DIAL FRICTION RING	.52
13	HW321	SPOOL ASSY.	10.04
14	GX4261	MAGNET RETAINER SUPPORT	.85
15	GX4301	MAGNET RETAINER SPRING	.80
16	GX4108	SPOOL COVER ASSY	3.61
19	GX4257	MAGNET PLATE ASSY	11.46
20	GX4602	MAGNET PLATE SCREW	1.19
21	HW310	SET PLATE	7.47
22	GX4405	LINK	1.14
23	GX4406	THUMB BAR CAM	.92
24	GX4401	PINION YOKE	1.09
25	GX4403	PINION YOKE SPR	.85
26	GX4402	RELEASE SLIDER	2.12
27	GX4502	SPOOL REL. SPRING	.85
28	GX4656	RELEASE SLIDER SCREW	.85
29	GX4150	OSCILLATOR GEAR	2.93
30	GX4109	FRAME SCREW WSHR	.46
32	GX4655	CONTROL ELEMENT	1.14
33	GX4652	CRANK SHAFT	3.44
36	GX4651	DRIVE GEAR	3.55
37	GX4659	DRAG WASHER "B"	1.37
38	GX4653	DRAG WASHER "D"	1.72
39	GX4451	ANTI-REVERSE	1.72
40	GX4256	PINION GEAR ASSY	2.64
41	HW024	RIGHT SIDE COVER	8.50
42	GX4452	ANTI-REVERSE PAWL	.85
44	GX4259	SPOOL TENSION KN. ASSY	1.90
45	GX4352	RIGHT SIDE CVR SCR	1.09
A46	GX4662A	THICK WAVE WASHER	1.34
B46	GX4662B	THIN WAVE WASHER	1.24
47	GX4663	STAR DRAG	6.59
48	GX4660	HANDLE WASHER	1.14
49	HW318	HANDLE ASSY.	5.92
50	GX4702	HANDLE NUT	.92
51	GX4703	HANDLE NUT LOCK	.85
52	GX4704	HANDLE NUT LOCK SCR	.39
53	GX4104	FRAME SCREW	1.43
54	GX4302	SPOOL TNSN. KN. WSHR.(FL)	.46
55	GX4506	LINK SCREW	.69
56	GX4556	CLICK CLAW	.85
57	GX4258	SPOOL TENSION KN. RING	.85
58	GX4254	RIGHT SIDE CVR BUSHING	2.07
59	GX4105	SET PLATE SHAFT WSHR	.46
60	GX4657	CRANK SHAFT E-CLIP	.46
61	GX4664	SET PLATE SHAFT	1.14
62	GX4665	SHAFT CLIP-E	.46
63	GX4308	SPOOL TEN. KN. WSHR (RB)	.46
64	GX4304	SPOOL TEN. KN. WSHR (BG)	.46

PS220J

KEY NO.	PART NO.	DESCRIPTION	PRICE
1	JW001	FRAME	5.41
2	JW072	WORM SHAFT	5.73
3	JW016	WORM SHAFT GUARD	3.44
4	JW347	LINE GUARD	1.55
5	JW006	LINE GUIDE PAWL	1.55
6	JW007	LINE GUIDE PAWL SCREW	1.66
7	JW061	STABILIZER BAR	1.61
8	JW094	FRAME FIXED PIN	1.37
9	JW009	THUMB BAR	1.96
10	JW323	LEFT SIDE COVER ASSY.	7.16
11	JW026	CONTROL DIAL	3.61
12	JW101	O-RING CAST CONTROL	.52
13	JW321	SPOOL ASSY.	10.04
14	JW028	SLIDE CAM	.85
15	JW071	SLIDE CAM SPRING	.80
16	JW351	SPOOL COVER	3.61
19	JW330	MAGNET PLATE ASSY.	11.46
20	JW076	MAGNET PLATE SCREW	1.19
21	JW310	SET PLATE	7.47
22	JW036	LINK	1.14
23	JW050	THUMB BAR CAM	.92
24	JW029	PINION YOKE	1.09
25	JW040	PINION YOKE SPRING	.85
26	JW039	RELEASE SLIDER	2.12
27	JW102	TRIP SPRING	.85
28	JW057	RELEASE SLIDER SCREW	.85
29	JW088	LEVEL WIND GEAR	2.93
30	GX109	WASHER-THUMB SCREW	.45
32	JW063	TRIP RATCHET	1.14
33	JW008	DRIVE SHAFT	3.44
36	JW012	DRIVE GEAR	3.55
37	JW059	DRAG DISC	1.37
38	JW045	DRAG WASHER	1.72
39	JW091	ANTI-REVERSE RATCHET	1.72
40	JW311	PINION GEAR ASSY.	2.64
41	JW024	RIGHT SIDE COVER	8.50
42	JW363	ANTI-REVERSE PAWL	.85
44	JW333	CAST CONTROL CAP ASSY.	1.90
45	GX4352	RIGHT SIDE CVR SCR	1.09
A46	JW046A	THICK WAVE WASHER	1.34
B46	JW046B	THIN WAVE WASHER	1.24
47	JW358	DRAG KNOB ASSY.	6.59
48	GX4660	HANDLE WASHER	1.14
49	JW318	HANDLE ASSY.	5.92
50	GX4702	HANDLE NUT	.92
51	GX4703	HANDLE NUT LOCK	.85
52	GX4704	HANDLE NUT LOCK SCR	.39
53	JW374	THUMB SCREW ASSY.	.40
54	JW032	SPOOL TENSION KNOB	.46
55	JW100	LINE SCREW	.69
56	JW108	CLICK CLAW	.85
57	JW105	TENSION KNOB O-RING	.85
58	JW038	CRANK SHAFT BUSHING	2.07
59	JW064	SHIM CRANKSHAFT	.46
60	GX4657	CRANK SHAFT E-CLIP	.46
61	JW002	SET PLATE SHAFT	1.14
62	GX4665	SHAFT CLIP-E	.46
63	JW062	CAST CONTROL CUSHION	.46
64	JW038	SPOOL TN. KN. WSHR.-BG.	.46