




BRUNSWICK CORPORATION
 CONSUMER DIVISION
 POST OFFICE BOX 270
 TULSA, OKLAHOMA 74101

ZEBCO PARTS LIST AND ORDER BLANK

MODEL XBL77 SPINNING REEL

PLEASE ORDER BY PART NUMBER, NOT KEY NUMBER.



IF REQUIRED REPAIRS CANNOT BE MADE AT YOUR NEAREST FACTORY APPROVED SERVICE STATION, YOU MAY ORDER THE FOLLOWING REPLACEMENT PARTS DIRECT FROM THE FACTORY OR RETURN REEL TO FACTORY.

Your Order No. _____ Date _____

Charge To _____ Ship To _____

Address _____ Address _____

City & State _____ City & State _____

DEFECTIVE PARTS REPLACED AT FACTORY ONLY

KEY NO.	DESCRIPTION	PART NUMBER		QUANTITY	PRICE	EXTENSION
		old	new			
1	Drag Knob	32001	SX-32		\$1.50	
2	Stopper Spring	28004	EX-28		.10	
3	Drag Washer A	26001A	EX-53		.15	
4	Spool Spring	28007	EX-30		.30	
5	Drag Washer B	26001	EX-54		.15	
6	Drag Washer C	27001	EX-45		.10	
7	Spool Assembly	0206001	HX-21		4.24	
8	Click	33027	HX-40		.15	
9	Click Spring	28083	HX-34		.15	
10	Click Screw	19054	HX-31		.10	
11	Spool Click Assembly	0213007	JX-33		.95	
12	Rotor Nut	18001	HX-6		.15	
13	Bail Arm Folding Lever Screw	19003	BX-48		.20	
14	Bail Arm Lever Spring	28096	SX-42		.20	
15	Bail Arm Lever	15059	SX-7		.65	
16	Rotor	05024	SX-9		4.60	
17	Bail Arm Cam A Screw	19001	HX-16		.55	
18	Bail Arm Lever	15058	SX-43		.70	

KEY NO.	DESCRIPTION	PART NUMBER		QUANTITY	PRICE	EXTENSION
		old	new			
19	Bail Arm Nut	18005	BX-19		\$.15	
20	Bail Arm Roller Washer	27021	CX-17		.10	
21	Bail Arm Roller	25009	DX-4		.35	
22	Bail Arm Spring	28097	SX-49		.20	
23	Bail Arm Assembly w/Cam B	29030	SX-10-A		2.70	
24	Bail Arm Cam B Screw	19002	HX-14		.30	
25	Oilless Bush Holding Screw	020001	SX-25		.05	
26	Bearing Holder	17002	HX-26		.35	
27	Ball Bearing	38001	IX-27		3.05	
28	Pinion Gear Washer	27070	SX-12		.10	
29	Pinion Gear	09028	SX-11		3.75	
30	Main Shaft Assembly	0212077	SX-15-A		1.85	
31	Handle Retaining Screw	21011	NX-3		.50	
32	Nylon Washer	27037	PX-5		.10	
33	Main Body	03027	SX-1-A		6.15	
34	Anti-Reverse Lever Screw	21001	BX-51		.10	L
35	Anti-Reverse Lever	15057	SX-52		.15	
36	Anti-Reverse Lever Cam	14038	SX-36		.40	
37	Anti-Reverse Spring	28099	SX-51		.20	
38	Main Gear	08027	SX-8		.85	
39	Oscillating Slider A	11015	SX-66		.25	
40	Oscillation Slider Assembly	0211013	SX-64		1.20	
41	Oilless Bushing	38005	SX-63		.50	
42	Anti-Reverse Claw Screw	19065	SX-48		.25	
43	Anti-Reverse Claw	33030	SX-35		.30	
44	Anti-Reverse Claw Spring	28098	SX-37		.20	
45	Side Plate	04030	SX-24-A		1.90	
46	Side Plate Screw	20013	JX-72		.10	✓
47	Handle Assembly	0207034	PX-18-A		6.75	

AMOUNT

TO