




BRUNSWICK CORPORATION
CONSUMER DIVISION
 POST OFFICE BOX 270,
 TULSA, OKLAHOMA 74101

Canadian Prices 25% Higher

ZEBCO PARTS LIST AND ORDER BLANK

MODEL XR60 SPINNING REEL

PLEASE ORDER BY PART NUMBER, NOT KEY NUMBER



IF REQUIRED REPAIRS CANNOT BE MADE AT YOUR NEAREST FACTORY APPROVED SERVICE STATION, YOU MAY ORDER THE FOLLOWING REPLACEMENT PARTS DIRECT FROM THE FACTORY OR RETURN REEL TO FACTORY.

Your Order No. _____ Date _____
 Charge To _____ Ship To _____
 Address _____ Address _____
 City & State _____ City & State _____

DEFECTIVE PARTS REPLACED AT FACTORY ONLY

KEY NO.	DESCRIPTION	PART NO.		QUANTITY	PRICE	EXTENSION
		OLD	NEW			
1	Drag Knob Assembly	0232001	HX-32		\$.85	
2	Stopper Spring	28004	EX-28		.10	
3	Drag Washer A	26001A	EX-53		.15	
4	Spool Spring	28007	EX-30		.30	
5	Drag Washer B	26001	EX-54		.15	
6	Drag Washer	27001	EX-45		.10	
7	Spool	0206001	HX-21		4.24	
8	Spool Click	0213001	HX-33		.90	
9	Main Shaft Assembly	0212002	HX-15-A		1.65	✓
10	Spool Click Claw	33027	HX-40		.15	
11	Spool Click Spring	28083	HX-34		.15	
12	Spool Click Screw	19054	HX-31		.10	
13	Bail Arm Assembly W/Cam B	0229001	HX-10		1.75	✓
14	Bail Arm Roller	25001	CX-4		.35	
15	Bail Arm Cam A Screw	19001	HX-16		.55	
16	Bail Arm Nut	18005	BX-19		.15	
17	Bail Arm Roller Washer	27021	DX-6		.10	
18	Bail Arm Cam A	15008	HX-7		.30	
19	Bail Arm Spring	28006	HX-49		.15	
20	Bail Arm Cam B Screw	19002	HX-14		.30	

(Continued on Reverse Side)

KEY NO.	DESCRIPTION	PART NO.		QUANTITY	PRICE	EXTENSION
		OLD	NEW			
21	Bail Arm Lever Screw	19003	BX-38		\$.20	
22	Bail Arm Lever Spring	28001	HX-42		.15	
23	Bail Arm Lever	15002	HX-43		.20	
24	Rotor Nut	18001	HX-6		.15	
25	Rotor	05001	HX-9-A		2.05	
26	Oilless Bush Holding Screw	20001	FX-25		.10	
27	Oilless Bushing Holder	17002	HX-26		.35	
28	Oilless Bushing	38014	HX-27		.30	
29	Pinion Gear	09002	HX-11		.35	
30	Main Body	03001	HX-1-A		2.05	
31	Side Plate Screw A	20018	HX-73		.10	
32	Side Plate Screw B	20003	BX-72		.10	
33	Side Plate	04001A	HX-24-A		.95	
34	Oscillating Slider	11001	HX-64		.40	
35	Oscillating Slider Pin	23002	HX-66		.15	
36	Oscillating Slider Collar	17001	HX-62		.10	
37	Main Gear Assembly	0208002	HX-8-A		1.15	
38	Master Gear Adjusting Washer	27002	HX-77		.10	
39	Anti-Reverse Claw Screw	19003	BX-48		.20	
40	Anti-Reverse Claw	33001	HX-35		.15	
41	Anti-Reverse Claw Spring	28005	HX-37		.10	
42	Anti-Reverse Lever Cam	14002	HX-36		.20	
43	Spring Washer	27003	BX-55		.10	
44	Anti-Reverse Lever	15001	BX-52		.30	
45	Anti-Reverse Lever Screw	21001	BX-51		.10	
46	Handle Assembly	0207001	HX-18-A		3.60	✓