




BRUNSWICK CORPORATION
CONSUMER DIVISION
 POST OFFICE BOX 270,
 TULSA, OKLAHOMA 74101

ZEBCO PARTS LIST AND ORDER BLANK

MODEL XRL80 SPINNING REEL

PLEASE ORDER BY PART NUMBER, NOT KEY NUMBER



IF REQUIRED REPAIRS CANNOT BE MADE AT YOUR NEAREST FACTORY APPROVED SERVICE STATION, YOU MAY ORDER THE FOLLOWING REPLACEMENT PARTS DIRECT FROM THE FACTORY OR RETURN REEL TO FACTORY.

Your Order No. _____ Date _____
 Charge To _____ Ship To _____
 Address _____ Address _____
 City & State _____ City & State _____

DEFECTIVE PARTS REPLACED AT FACTORY ONLY

KEY NO.	DESCRIPTION	PART NO.		QUANTITY	PRICE	EXTENSION
		OLD	NEW			
1	Drag Knob Assembly	0232005	KX-32		\$1.10	
2	Drag Washers Retainer	39050	KX-28		.30	
3	Drag Washer A	26010A	KX-53		.20	
4	Drag Washer B	26012	KX-54		.30	
5	Drag Washer C	26011	KX-45		.35	
6	Drag Washer D	26010	KX-68		.20	
7	Spool Spring	28035	KX-30		.35	
8	Spool	06014	KX-21		4.73	
9	Spool Click Spring	28038	KX-34		.15	
10	Spool Click Claw	33009	KX-33		.15	
11	Spool Click Screw	19019	KX-31		.15	
12	Main Shaft Assembly	0212060	NX-15-A	5 6	X 2.00	✓
13	Bail Arm Lever Screw	19003	BX-48		.20	
14	Bail Arm Lever Spring	28039	KX-42		.15	
15	Bail Arm Lever	15029	NX-43		X .30	
16	Bail Arm Cam B Screw	19024	KX-14		.50	
17	Bail Arm Assembly	0229013	NX-10-A	X	X 2.05	L
18	Rotor Nut	18001	HX-6		.15	
19	Rotor	05006A	NX-9-A		2.95	
20	Bail Arm Spring	28069	NX-49		.30	
21	Bail Arm Cam A Screw	21021	NX-16		.95	
22	Bail Arm Nut Assembly	0219022	NX-19		.35	
23	Bail Arm Roller Washer	27032	NX-17		.25	

(Continued on Reverse Side)

KEY NO.	DESCRIPTION	PART NO.		QUANTITY	PRICE	EXTENSION
		OLD	NEW			
24	Bail Arm Roller Assembly	0225007	NX-4		X \$.35	
25	Oilless Bush, Holding Screw	20032	NX-25		.15	
26	Oilless Bush, Holder	30009	NX-26		.50	
27	Oilless Bushing	38003	NX-27		.30	
28	Pinion Gear Collar	17019	NX-12		.45	
29	Anti-Reverse Ratchet Gear	48001	NX-13		.50	
30	Pinion Gear	09023	NX-11		2.35	
31	Handle Retainer Nut	21011	NX-3		Z .50	
32	Handle Retainer Washer	39064	NX-5		X .10	
33	Main Body	03016	NX-1-A		3.25	
34	Anti-Reverse Cam Spring	28045	NX-37		.15	
35	Anti-Reverse Assembly	0215016	NX-52		.30	
36	Anti-Reverse Cam	14014	NX-36		.20	
37	Anti-Reverse Cam Spring Pin	23022	NX-40		.20	
38	Oscillating Bull Gear	10004	KX-61		.30	
39	Oscillating Bull Gear Screw	21005	GX-63		.15	
40	Oscillating Slider Collar	17013	KX-62		.10	
41	Oscillating Slider	11005	KX-64		.40	
42	Oscillating Slider Screw	20020	KX-65		.10	
43	Anti-Reverse Claw	39065	NX-35		.20	
44	Anti-Reverse Claw Spring	28087	NX-39		.20	
45	Anti-Reverse Claw Screw	19048	NX-38		.20	
46	Oscillating Pinion Gear	10008	NX-60		.20	
47	Main Gear Assembly	0208015	NX-8-A		2.70	
48	Main Gear Adjusting Washer	27022	JX-77		.10	✓
49	Oilless Bushing	38008	NX-63		.30	
50	Side Plate	04021A	NX-24-A		1.10	
51	Side Plate Screw A	20013	JX-72		X .10	✓
52	Side Plate Screw B	20018	HX-73		.10	
53	Handle Assembly	020718	NX-18-A		6.85	✓