


# FIN-NOR®

LEGENDARY TACKLE SINCE 1933

## Lethal LTL16II



# FIN-NOR®

LEGENDARY TACKLE SINCE 1933

## Lethal LTL16II

Fin-Nor Lethal LTL16II Trolling Reel Part List

Key No.	Description	Qty.	LTL16II	Key No.	Description	Qty.	LTL16II
1	Screw	4	LF057-01	45	Handle Nut	1	AM003-01
2	Brake Shoe	4	RF044-01	46	Handle Arm Assembly	1	JM318-02
3	Bait Click Ratchet Assembly	1	JM329-01	47	Spacer	1	JM160-01
4	E-Clip	1	DF092-01	48	Handle Washer	1	JM054-01
5	Spacer	1	DF081-02	49	Adjustment Washer	1	DF035-03
6	Drag Spring	4	JF046-01	50	Rubber Seal	1	CM172-01
7	Washer	1	CF121-01	51	Ball Bearing	2	CF017-02
8	Ball Bearing	1	KF017-02	52	Gear Side Cover Assembly	1	JM324-04
9	Spool Shaft Pin	1	JM093-01	53	Locating Collar	2	JM118-01
10	Spool Shaft	1	JM015-01	54	Screw	2	NF125-01
11	Spool	1	JM021-01	55	E-Clip	3	NX092-01
12	Ball Bearing	1	CF117-01	56	Anti Reverse Pawl	2	DF063-02
13	Collar	2	BF094-01	57	Spring	2	JM096-01
14	Spring	1	CF040-01	58	Spacer	1	AM081-01
15	Drag Disc	1	JM059-01	59	Crank Shaft	1	JM008-01
16	Screw	4	QW053-07	60	Coil Spring - Upper	1	AM070-01
17	Drag Plate Assembly	1	KM348-01	61	Drive Gear - High	1	JM012-01
18	Ball Bearing	1	VF017-02	62	Spacer	1	LF160-02
19	Pre Set Knob	1	JM029-01	63	Drive Gear - Low	1	KM012-01
20	Spring	1	JM040-01	64	Shift Shaft	1	AM146-01
21	Click Spring	1	JM114-01	65	Coil Spring - Lower	1	VF070-01
22	Click Pawl	1	JM098-01	66	Link	1	LF036-02
23	Rubber Ring	1	JM105-01	67	Screw	1	MF053-01
24	Drag Cam A	1	JM028-01	68	Dust Cover - A	1	AM038-01
25	Drag Cam B Assembly	1	JM353-01	69	External Ring	1	LF075-01
26	Bushing	1	DF017-02	70	Screw	2	CF107-01
27	Drag Lever	1	JM055-01	71	Gear Cover	1	JM143-01
28	Drag Lever Washer	1	BM038-01	72	Frame Assembly	1	JM301-01
29	Click Pawl	1	CM098-01	73	Screw	1	RF053-01
30	Click Spring	1	KM114-01	74	Click Spring	1	RF022-02
31	Cover	1	CM161-01	75	Plam Side Cover Assemly	1	JM323-01
32	Screw	1	DW107-01	76	Bait Click Lever	1	RF109-02
33	Washer	6	JM035-01	77	Washer	1	RF081-01
34	Screw	3	RF057-01	78	Bait Click Pawl	1	JM109-01
35	Handle Nut Screw	1	JM076-01	79	Retainer	1	RF020-01
36	Shift Knob Holder	1	AM159-02	80	Screw	2	RF125-01
37	Shift Button	1	AM062-02	81	Rod Clamp	1	RF154-01
38	Washer	1	AM035-01	82	Nut	2	JF003-01
39	Shift Knob	1	AM158-02	83	O-Ring	2	RF105-01
40	Dust Cover - B	1	BM035-01	84	Nut	2	RF161-01
41	Trip Holder	1	BM159-01	85	Wrench Driver	1	CM113-01
42	Plate	2	JM104-01	86	Ball Bearing	1	CF117-02
43	Coil Spring	2	JM070-01	87	Screw	3	RF057-02
44	Handle Nut Retainer	1	AM034-01	88	Adjustment Washer	2	PM035-01