


# FIN-NOR®

LEGENDARY TACKLE SINCE 1933

## Santiago 25

FIN-NOR SA25 2SPEED



# FIN-NOR®

LEGENDARY TACKLE SINCE 1933

## Santiago 25

### Fin\_Nor Santiago Trolling Reels - 25

Key No.	Description	Part No.	Key No.	Description	Part No.
		25			25
1	Cosmetic Cover Screw	HX107-03	50	Bait Click Spring	LF110-01
2	Cosmetic Cover	LF145-01	51	Ball Bearing	LF017-01
3	Frame Assembly	NF301-01	52	Preset Screw	LF019-01
4	Harness Lug Screw	JF050-01	53	Cam Follower	LF153-01
5	Harness Lug Pad	KF155-01	54	Cam Pin	LF093-01
6	Harness Lug	JF151-01	55	Cam	LF028-01
8	Reel Foot Gasket	LF155-01	56	Washer	LF035-03
9	Reel Foot	LF106-01	58	Gear Side Cover Assembly	NF324-01
10	Reel Foot Screw	LF125-01	59	Side Cover Screw	LF053-01
11	Anti Reverse Pawl	LF063-01	60	Bait Click Lever	VF109-01
12	Anti Reverse Pawl Spring	LF052-01	61	Bait Click Pawl Pin	WF100-01
13	Anti Reverse Pawl Screw	LF050-01	62	Drag Lever Washer	LF035-01
14	Ball Bearing	MF017-01	63	Quadrant Spacer	MF094-01
15	Spool Cover Screw	LF057-01	64	Quadrant	LF152-01
16	Spool Cover	LF051-01	65	Quadrant Screw	LF123-01
17	Spool Shaft Screw	LF107-02	66	Drag Lever Assy	LF355-01
18	Spool Shaft Washer	MF038-01	67	Washer	LF035-02
19	Drag Plate Assembly -"B"	LF348-01	68	Front Housing Cover Kit include	LF499-01
20	Drag Plate Pin	LF100-01		68A - Front Housing Cover	LF099-01
21	Drag Compression Spring	LF040-01		68B - Washer	LF038-01
22	Drag Washer Screw	LF107-01		68C - Pre Set Knob Click Pawl	PW098-01
23	Drag Washer	LF045-01		68D - Pre Set Knob Click Spring	YW114-01
24	Drag Plate Assembly -"A"	MF348-01		68E - Preset Knob	LF029-01
25	Drag Plate Pin	LF100-01		68F - Washer	LF038-01
26	Ball Bearing	LF017-01		68G - E-Clip	LF092-01
27	Spool	NF021-01	71	Front Housing Cover Screw	MF050-01
28	Line Ting Screw	NF125-01	73	Link Spring	LF070-01
29	Bearing Spacer	MF160-03	74	Link Spring Holder	MF081-01
30	Pressure Release Spring	MF040-01	75	E-Clip	QW120-01
31	Pressure Release Spring Holder	LF041-01	76	Handle Collar	LF081-01
32	Ball Bearing	LF017-01	77	Handle Assembly	LF318-01
33	Bait Click Plate	LF113-01	78	Handle Nut	MF003-01
34	Bait Click Plate Screw	MF107-01	79	Handle Nut Retainer	LF034-01
35	Low Speed Pinion Gear	LF011-01	80	Shift Spring	MF070-01
36	Spool Shaft	NF015-01	81	Shift Holder	LF104-01
37	Pinion Gear Pin	MF093-01	82	Shift Spring Holder	MF159-01
38	Drag Adjusting Washer	LF032-00	83	Shift Button	MF062-01
39	Drag Disc Spring	LF046-01	84	Shift Knob	LF158-01
40	Retaining Ring	LF075-01	85	Washer	MF035-01
41	Low Speed Drive Gear	MF012-01	86	Shift Knob Holder	LF159-01
42	Gear Spacer	LF160-01	87	Shift Knob Holder Screw	MF076-01
43	Link Retainer Screw	MF053-01	88	Bait Click Lever Spring	JF071-01
44	Link	LF036-01	89	Bait Click Lever Cap	VF115-01
45	High Speed Drive Gear	DF012-01	101	Rod Clamp Nut	LF003-01
46	Link Spring	LF070-01	102	O-Ring	LF101-01
47	Link Shaft	LF146-01	103	Rod Clamp	LF154-01
48	Crank Shaft	LF008-01	104	Rod Clamp Bolt	MF125-01
49	Bait Click Pawl	LF114-01	105	Rod Clamp Pad	MF155-01