DAIWA

BAITCASTING REEL

Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

FUEGO CT 100H/100HS-100XS



Key No.	Part No.	Part Name
1	H93-0401	SET PLT SCREW
2	E16-7101	BRAKE DIAL SPRING
3	J21-3703	BRAKE ADJ KNOB
4	B33-9801	BRAKE DIAL RETAINER
5	F63-7701	BRAKE DIAL WAHSER
6	H66-3401	BRAKE CLICK SPRING
7	H93-0130	LEFT SIDE PLATE
8	H91-5501	BRAKE DIAL RETAINER
9	G93-9301	FRONT PLATE SCREW
10	H93-0502	MAGNET HOLDER
11	375-7406	SPACER
12	375-7411	SPACER
13	G18-5101	SPACER
14	G51-1503	BALL BEARING
15	F03-2201	BEARING RETAINER
16-24	Z02-2784	SPOOL ASSEMBLY
25	J33-7912	FRAME
26	J24-4013	FRONT COVER
27	H84-2803	SCREW
28	J33-5001	CLUTCH LEVER
29	H91-5601	CLUTCH LEVER PLT
30	H91-5701	CLUTCH LEVER PLT
31	J43-7001	STABILIZER BAR
32	H70-4101	RETAINER
33	H91-0601	COLLAR
34	H92-8801	SPRING
35	J05-5201	PIN
36	B86-1704	BALL BEARING
37	J24-2801	PLATE A
38	H29-4101	SCREW
39	J24-3201	CLUTCH CAM SPRING
40	J22-1401	CLUTCH TRIP LEVER
41	J24-2601	CLUTCH CAM PLATE
42	H15-9201	WASHER
43	352-2501	SCREW
44	H65-0101	CLUTCH CAM PLATE
45	B03-2904	SCREW
46	H92-9001	YOKE
47	H58-2001	PINION YOKE SPRING
48	H91-3901	PINION GEAR
49	H18-0501	BEARING RETAINER
50	G43-1102	BALL BEARING
51	J21-2155	RIGHT SIDE PLATE
52	B05-5201	O'RING
53	J21-3101	SPACER
54	B17-5503	CAP RUBBER WASHER
55	H21-3601	CAST CONTROL CAP
56	G04-0820	SIDE PLATE SCREW
57	G04-0828	SIDE PLATE SCREW
58	320-5901	RETAINER
59	B41-1703	WASHER

Key No.	Part No.	Part Name
58	320-5901	RETAINER
59	B41-1703	WASHER
60	G72-0001	WORM SHAFT BEARING
61	J47-2101	LEVEL WIND
62	121-4212	LINE GUIDE PAWL
63	373-1303	WASHER
64	F40-2801	PAWL CAP
65	J43-2701	LEVEL WIND GUARD
66	J24-3602	WORM SHAFT
67	G72-0001	WORM SHAFT BEARING
68	H91-0501	WORM GEAR
69	B33-9801	RETAINER
70	G09-9801	WASHER
71	320-8002	RETAINER
72	B35-8607	BALL BEARING
73	H92-8901	PLATE B
74	E13-4509	SCREW
75	H91-2701	DRIVE SHAFT GEAR
76	H91-1601	DRIVE SHAFT
77	H92-9401	A/R RATCHET
78	J08-5101	DRIVE SHAFT WASHER
79	H91-3102	DRIVE GEAR
80	H45-2602	DRAG WASHER
81	H91-3201	KEY WASHER
82	J37-7801	GEAR SHAFT COLLAR
83	G81-9801	ROLLER CLUTCH
84	B86-1704	BALL BEARING
85	B55-3801	WASHER
86	F02-8203	CLICK LEAF SPRING HOLDER
87	F03-2401	BRAKE CLICK SPRING
88	150-8901	SPRING WASHER
89	H92-9501	WASHER
90	H91-2001	NUT
91	J01-1901	SPRING
92	H91-1901	STAR DRAG
93	F57-6601	HANDLE COLLAR
94	J47-2201	HANDLE ASSEMBLY
95	H72-3701	HANDLE NUT
96	J21-3502	HANDLE CAP
97	G04-0803	HANDLE CAP SCREW

FGCT100HS SPECIAL PARTS

Key No.	Part No.	Part Name
48	J00-4201	PINION GEAR
51	J21-2156	RIGHT SIDE PLATE
79	J00-4002	DRIVE GEAR

FGCT100XS SPECIAL PARTS

Key No.	Part No.	Part Name
48	J00-9801	PINION GEAR
51	J21-2157	RIGHT SIDE PLATE
79	J00-9902	DRIVE GEAR