
www.reelschematic.com

Daiwa
COMMITTED TO TOTAL QUALITY

SPINCASTING REEL 206RL



KEY NO. 3 ~ 5
6-B08-2801 **ROTOR ASSEMBLY**

KEY NO. 11 ~ 13
6-B08-1501 **MAIN SHAFT ASSEMBLY**

Key No.	Parts No.	Parts Name
1	B08-3201	Front cover
2	B08-3101	Rotor nut
* 3	B08-2901	Rotor
* 4	180-3811	Pick up pin
* 5	142-4501	Pick up pin spring
6	320-3601	Spool retainer
7	373-4412	Spool washer
8	B08-2601	Spool
9	373-4412	Spool washer
10	381-4711	Shaft metal
11	B08-1601	Main shaft
12	B08-1701	Pinion gear
13	144-0701	Main shaft spring
14	B08-2401	Drag adjusting plate
15	B08-1301	Body
16	342-2401	Drag adjusting dial
17	B08-1801	Push button
18	353-2521	Drag adjusting screw
19	501-8501	Handle screw holder
20	363-8511	Handle screw A
21	B03-4802	Handle screw cap
22	637-4801	Drive gear shaft holder
23	B08-2001	Drive gear
24	370-5100	Drive gear washer
25	637-4801	Drive gear shaft holder
26	B08-2101	Body cover
27	B09-1401	Anti-reverse cam spring
28	461-7601	Anti-reverse cam
29	111-8501	Anti-reverse claw
30	144-5111	Anti-reverse claw spring
31	351-7701	Anti-reverse claw screw
32	541-3132	Anti-reverse lever
33	351-4701	Anti-reverse lever screw
34	351-7801	Body cover screw (short)
35	B08-2201	Body cover screw (long)
36	071-0507	Drive gear shaft
37	746-5201	Handle
38	160-8001	Handle washer
39	353-5301	Handle screw B

*Not sold separately. See Rotor Assembly.