
www.reelschematic.com

Daiwa
COMMITTED TO TOTAL QUALITY

GS9000



Key No.	Parts No.	Parts Name
1.	E33-9002	Drag knob
2.	E35-4901	Spool assembly
3.	E14-6503	Spool washer
4.	E12-2301	Click leaf spring holder
5.	B74-7701	Spool click leaf spring
6.	371-2800	Main shaft washer
7.	E35-0201	Main shaft assembly
8.	E33-3801	Rotor nut holding plate
9.	351-1804	Rotor nut holding plate screw
10.	B43-7603	Rotor nut
11.	E34-9702	Rotor assembly
12.	E26-5901	Bail trip cover
13.	351-6106	Bail trip cover screw
14.	B21-1305	Line roller screw
15.	375-4301	Lock washer
16.	E33-3601	Line roller
17.	B44-3401	Line roller bushing
18.	E34-9801	Bail
19.	E33-3402	Bail arm screw
20.	E32-6701	Bail spring shaft
21.	E31-3901	Bail spring washer
22.	E26-5601	Bail spring
23.	320-5901	Bail arm screw retainer
24.	E35-0101	Line guard roller shaft
25.	E32-6801	Line guard roller
26.	E26-6901	Roller shaft nut
27.	E26-5901	Bail spring cover
28.	351-6106	Bail spring cover screw
29.	B67-8401	Bearing retainer
30.	L01-1702	Bearing retainer screw
31.	372-7603	Bearing washer
32.	637-6101	Ball bearing
33.	E34-8801	Spacer
34.	E34-8901	Spacing sleeve A
35.	637-6101	Ball bearing
36.	E26-2801	Spacing sleeve B
37.	E26-2701	Anti-reverse ratchet
38.	E34-8701	Pinion gear
39.	E35-4501	Body
40.	E32-7801	Anti-reverse cam spring
41.	E26-2304	Anti-reverse lever

Key No.	Parts No.	Parts Name
42.	E35-0401	Water shield
43.	E35-0502	Rear cover
44.	E24-8102	Rear cover screw
45.	E26-3102	Oscillating slider
46.	E26-4101	Oscillating pawl
47.	E26-4201	Oscillating pawl bush
48.	375-0800	Oscillating pawl washer
49.	E26-4301	Oscillating slider cover
50.	352-1502	Oscillating slider cover screw
51.	320-5901	Worm shaft gear retainer
52.	E34-9201	Worm shaft gear
53.	E18-6801	Worm shaft bush
54.	E26-3201	Worm shield cover
55.	E26-3301	Worm shaft
56.	B41-1700	Worm shaft washer
57.	E26-3501	Worm shaft collar
58.	E26-3601	Worm shaft retainer
59.	E34-8401	Anti-reverse pawl plate
60.	E34-8501	Anti-reverse pawl
61.	E26-2101	Anti-reverse pawl collar
62.	E26-2202	Anti-reverse pawl spring A
63.	B83-5002	Anti-reverse pawl screw
64.	E26-4501	Anti-reverse pawl spring B
65.	E35-3101	Drive gear
66.	B27-0700	Drive gear washer
67.	637-6101	Ball bearing
68.	E35-4701	Left side cover
69.	B00-9702	Side cover screw A
70.	B00-9701	Side cover screw B
71.	E15-8601	Side cover screw C
72.	363-8611	Handle collar
73.	E33-4802	Handle screw
74.	501-8401	Handle screw cap
75.	E35-4601	Right side cover
76.	B00-9702	Side cover screw A
77.	B00-9701	Side cover screw B
78.	E15-8601	Side cover screw C
79.	E35-4801	Handle assembly