
www.reelschematic.com

Daiwa
COMMITTED TO TOTAL QUALITY

SPINNING REEL **UL7**



Key No. 1-8
F00-6501 Spool assembly

Key No.	Parts No.	Parts Name
1	6-E32-2001	Drag knob
2	6-170-4001	Drag washer retainer
3	6-E32-5201	Key washer
4	6-E32-5101	Drag washer
5	6-F00-6401	Spool
6	6-B07-5301	Click pawl
7	6-144-1211	Click spring
8	6-320-5901	Click retainer
9	6-E32-5001	Spool washer
10	6-E32-0801	Main shaft assembly
11	6-481-2601	Oscillating slider
12	6-E15-0201	Oscillating slider screw
13	6-342-4001	Rotor nut
14	6-E09-7601	Rotor plate
15	6-E31-9401	Rotor
16	6-E31-9801	Bail trip lever
17	6-E31-9701	Bail trip cover
18	6-E24-8102	Bail trip cover screw
19	6-352-2503	Line roller screw
20	6-E31-9501	Bail arm
21	6-E31-9601	Bail arm screw
22	6-B55-4301	Line roller washer
23	6-250-3921	Line roller
24	6-B45-1501	Line roller bushing
25	6-E31-9901	Bail
26	6-E31-9601	Bail trip cam screw

Key No.	Parts No.	Parts Name
27	6-E32-0201	Bail spring
28	6-E31-9701	Bail spring cover
29	6-E24-8102	Bail spring cover screw
30	6-B12-8701	Rotor washer
31	6-E32-4901	Bearing retainer A
32	6-B93-3001	Bearing retainer screw
33	6-E18-2801	Ball bearing
34	6-E11-4201	Anti-reverse ratchet
35	6-E32-3401	Pinion gear
36	6-E31-8701	Body assembly
37	6-E31-9001	Anti-reverse lever
38	6-E31-9101	Anti-reverse lever spring
39	6-E15-3101	Anti-reverse pawl washer
40	6-E31-9201	Anti-reverse pawl
41	6-E03-3001	Anti-reverse pawl collar
42	6-E31-9301	Anti-reverse pawl spring A
43	6-B00-8601	Anti-reverse pawl screw
44	6-E32-0401	Anti-reverse pawl spring B
45	6-E32-0301	Drive gear
46	6-E32-0601	Oscillating support
47	6-375-8500	Drive gear washer
48	6-E32-1001	Side cover
49	6-E13-0502	Side cover screw
50	6-E32-1301	Handle assembly
51	6-B92-4901	Handle lock washer
52	6-E03-5502	Handle lock screw